

[Manuals.plus](#) /

› [Sami](#) /

› Sami RS 2902 10-Band Portable Radio User Manual

Sami RS 2902

Sami RS 2902 10-Band Portable Radio User Manual

Model: RS 2902

INTRODUCTION

Thank you for purchasing the Sami RS 2902 10-Band Portable Radio. This compact and versatile radio is designed for high-quality reception across multiple frequency bands, making it ideal for on-the-go listening. Please read this manual carefully to ensure proper use and maintenance of your device.



Figure 1: Sami RS 2902 Portable Radio. This image shows the radio's front panel, including the speaker grille, tuning dial, band selector, and extended telescopic antenna.

PACKAGE CONTENTS

Ensure all items are present in the package:

- Sami RS 2902 Portable Radio
- Hand Strap (pre-attached or included separately)
- User Manual (this document)

Note: AAA batteries are not included and must be purchased separately.

SETUP

1. Battery Installation

1. Locate the battery compartment cover on the back of the radio.
2. Slide or unclip the cover to open the compartment.
3. Insert two (2) AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

2. Attaching the Hand Strap

If the hand strap is not pre-attached, thread the loop of the strap through the designated eyelet on the side of the radio and secure it.

OPERATING INSTRUCTIONS

1. Powering On/Off

Locate the Power switch, typically on the side or top of the radio. Slide it to the "ON" position to power on the radio and to "OFF" to power it off.

2. Selecting a Band (FM/AM/SW)

The Sami RS 2902 supports 10 bands: FM, AM, and SW (Shortwave) bands 1 through 8. Use the band selector switch, usually a slider or button, to choose your desired frequency band.



Figure 2: Sami RS 2902 Portable Radio highlighting key features. This image shows the radio with visual indicators for 10 radio bands, pocket size, hand strap, tuning light, and battery requirements.

3. Tuning to a Station

Extend the telescopic antenna for optimal reception, especially for FM and Shortwave bands. Rotate the "TUNE" dial to scan for radio stations. The tuning light will illuminate when a strong signal is detected, indicating a clear reception.

4. Adjusting Volume

Use the "VOLUME" dial or slider to increase or decrease the audio output.

MAINTENANCE

- **Cleaning:** Wipe the radio with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.

- **Battery Care:** Remove batteries if the radio will not be used for an extended period to prevent leakage.
- **Storage:** Store the radio in a cool, dry place away from direct sunlight and extreme temperatures.
- **Antenna Care:** Handle the telescopic antenna gently to avoid bending or breaking.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Radio does not turn on.	Batteries are dead or incorrectly inserted.	Replace batteries with new ones, ensuring correct polarity.
Poor reception or static.	Weak signal, antenna not extended, or interference.	Extend the antenna fully. Try repositioning the radio. Tune slowly to find a clearer signal.
No sound.	Volume is too low or muted.	Increase the volume.

SPECIFICATIONS

Feature	Detail
Model	RS 2902
Dimensions (H x W x D)	117 x 27 x 73 mm (approximately 4.6 x 1.1 x 2.9 inches)
Weight	160 g (approximately 0.35 lbs)
Color	Silver
Radio Bands	10 Bands (FM, AM, SW 1-8)
Power Source	2 x AAA Batteries (not included)
Special Features	High-quality reception, Tuning light, Hand strap, Pocket size
Water Resistance	Water resistant (<i>Note: This typically implies splash resistance, not submersion. Avoid exposing the device to excessive moisture.</i>)

WARRANTY AND SUPPORT

Sami products are manufactured to high-quality standards. For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official Sami website. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance, you may contact Sami customer service through their official channels. You can find more information about Sami products on their Amazon store page: [Sami Official Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question