

RCF Sub 8006-AS

RCF Sub 8006-AS Active Dual 18-inch Subwoofer Instruction Manual

Model: Sub 8006-AS

1. INTRODUCTION

Thank you for choosing the RCF Sub 8006-AS Active Dual 18-inch Subwoofer. This professional-grade subwoofer is designed to deliver powerful and accurate low-frequency reproduction for various sound reinforcement applications. This manual provides essential information for the safe and efficient setup, operation, and maintenance of your RCF Sub 8006-AS. Please read this manual thoroughly before using the product.

2. SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, do not expose this apparatus to rain or moisture. Do not remove cover. No user-serviceable parts inside. Refer servicing to qualified service personnel.

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- This product is heavy. Exercise caution when lifting or moving to prevent injury.

3. PACKAGE CONTENTS

Verify that all items are present and in good condition upon unpacking. If any items are missing or damaged, contact your dealer immediately.

- RCF Sub 8006-AS Active Dual 18-inch Subwoofer
- Power Cable (Powercon type)
- Instruction Manual (this document)

4. PRODUCT OVERVIEW

The RCF Sub 8006-AS is a high-performance active subwoofer featuring dual 18-inch woofers with 4-inch voice coils, designed for robust and extended low-frequency output.

Key Features:

- Active 2x18" subwoofer with 4" voice coil
- Integrated amplifier for optimal performance
- Robust construction for professional use
- Multiple connectivity options (XLR, Powercon, Bluetooth)
- Onboard controls for sound adjustment

Component Identification:



Figure 4.1: Front view of the RCF Sub 8006-AS subwoofer, showcasing the protective grille and RCF logo. This image displays the overall robust design of the unit.



Figure 4.2: Front view with grille removed, revealing the dual 18-inch woofers. This illustrates the powerful speaker configuration responsible for deep bass.



Figure 4.3: Rear panel of the subwoofer, showing the amplifier module, input/output connectors (XLR, Powercon), and control knobs. This is where all audio and power connections are made, and settings are adjusted.




Figure 4.4: Top view of the subwoofer, highlighting the integrated handles for transport and the pole mount socket for attaching a satellite speaker.

5. SETUP

5.1 Placement

Proper placement is crucial for optimal sound performance and safety.

- **Stable Surface:** Place the subwoofer on a flat, stable, and level surface capable of supporting its significant weight (approximately 120 lbs).
- **Ventilation:** Ensure adequate space around the rear amplifier panel for proper ventilation to prevent overheating. Do not block ventilation openings.
- **Room Acoustics:** Experiment with placement within the room to achieve the best bass response. Corner placement often enhances bass, but can also lead to muddiness.
- **Pole Mount:** If using the integrated pole mount for a satellite speaker, ensure the pole and speaker are securely seated and stable.

5.2 Connections

Always ensure the subwoofer is powered off before making any connections.

1. **Audio Input (XLR):** Connect your audio source (e.g., mixer, audio interface) to the XLR input(s) on the rear panel using high-quality XLR cables. The Sub 8006-AS supports both stereo and mono input configurations.
2. **Audio Output (XLR):** Use the XLR output(s) to send the processed audio signal to full-range speakers or other subwoofers.

3. **Power Connection (Powercon):** Connect the provided Powercon power cable to the Powercon inlet on the rear panel, then plug the other end into a grounded AC power outlet. Ensure the power source matches the voltage requirements specified on the unit.
4. **Bluetooth (Optional):** For wireless audio streaming, activate Bluetooth on your source device and pair it with the Sub 8006-AS. Refer to the operating section for detailed Bluetooth pairing instructions.

5.3 Initial Power On

Once all connections are secure:

1. Ensure the volume/gain control on the subwoofer is set to its minimum position.
2. Power on your audio source devices first.
3. Flip the power switch on the RCF Sub 8006-AS to the "ON" position.
4. Slowly increase the volume/gain on the subwoofer to the desired listening level.

6. OPERATING INSTRUCTIONS

6.1 Onboard Controls

The rear panel features various controls to fine-tune the subwoofer's performance. (Refer to Figure 4.3 for visual reference).

- **Gain/Volume:** Adjusts the overall output level of the subwoofer.
- **Crossover Frequency:** Sets the upper frequency limit for the subwoofer, determining where it hands off to full-range speakers.
- **Phase Switch:** Allows you to invert the phase of the subwoofer's output (0° or 180°) to ensure proper alignment with other speakers in your system.
- **EQ Presets/Modes:** Some models may include preset EQ settings for different applications (e.g., "Deep," "Punch," "Live"). Consult the specific model's detailed manual for available options.

6.2 Bluetooth Connectivity

To connect a Bluetooth device:

1. Ensure the subwoofer is powered on.
2. Activate Bluetooth on your source device (smartphone, tablet, etc.).
3. Search for available Bluetooth devices. The subwoofer should appear as "RCF Sub 8006-AS" or similar.
4. Select the subwoofer to pair. A confirmation sound or indicator light may signal a successful connection.
5. Once paired, you can stream audio wirelessly to the subwoofer.

Note: Bluetooth is primarily for convenience and may not be suitable for critical professional audio applications where wired connections are preferred for stability and audio quality.

7. MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe down the exterior surfaces. Do not use abrasive cleaners, solvents, or waxes.
- **Ventilation:** Regularly check that the ventilation openings on the amplifier panel are free from dust and debris. Use a soft brush or compressed air to clear them if necessary.
- **Storage:** If storing the subwoofer for an extended period, ensure it is in a dry, temperature-controlled environment, away from direct sunlight and extreme temperatures. Cover the unit to protect it from dust.
- **Inspection:** Periodically inspect power cables and audio cables for any signs of damage. Replace damaged cables immediately.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected Power outlet not active Power switch off	Ensure Powercon cable is securely connected to both subwoofer and outlet. Test the outlet with another device. Flip the power switch to "ON".
No sound output	Audio input cable not connected or faulty Source device not playing or volume too low Subwoofer gain/volume set too low Incorrect crossover settings	Check XLR input connections and cables. Verify audio is playing from the source and its volume is adequate. Increase the subwoofer's gain/volume control. Adjust crossover frequency to an appropriate range (e.g., 80-120 Hz).
Distorted sound	Input signal too high (clipping) Subwoofer gain set too high Incorrect phase setting	Reduce the output level from your audio source. Lower the subwoofer's gain/volume control. Toggle the phase switch (0°/180°) to find the setting that provides the fullest bass.
Bluetooth connection issues	Device out of range Subwoofer not in pairing mode Interference	Move the Bluetooth device closer to the subwoofer. Ensure Bluetooth is active on the subwoofer (if applicable) and your device. Try re-pairing the device.

If the problem persists after trying these solutions, please contact RCF customer support or a qualified service technician.

9. SPECIFICATIONS

Feature	Detail
Model Name	Sub 8006-AS
Speaker Type	Active Subwoofer
Woofer Diameter	Dual 18 Inches
Voice Coil	4 Inches
Speaker Amplification Type	Active
Speaker Maximum Output Power	2500 Watts
Connectivity Technology	Powercon, XLR
Wireless Communication Technology	Bluetooth
Audio Output Mode	Stereo, Mono
Control Method	Touch (Onboard Controls)

Feature	Detail
Mounting Type	Tabletop Mount (with pole mount socket)
Item Weight	120 Pounds (approx. 54.4 kg)
Is Waterproof	FALSE (Not waterproof)
Manufacturer	RCF
ASIN	B01HNASAG0
Date First Available	January 16, 2015

Note: Specifications are subject to change without notice.

10. WARRANTY AND SUPPORT

10.1 Limited Warranty

The RCF Sub 8006-AS is covered by a **Limited Warranty**. The terms and conditions of this warranty are provided separately with your purchase or can be found on the official RCF website. Please retain your proof of purchase for warranty claims. This warranty typically covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper installation.

10.2 Customer Support


For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact RCF customer support through their official website or your authorized dealer.


- **RCF Official Website:** www.rcf.it (for support contact information and product registration)
- **Authorized Dealer:** Contact the retailer from whom you purchased the product.




© 2023 RCF. All rights reserved. Information in this manual is subject to change without notice.

Related Documents - Sub 8006-AS

	RCF HDL15-AS Active Flyable High Power Subwoofer Owner Manual This owner's manual provides detailed information for the RCF HDL15-AS Active Flyable High Power Subwoofer. It covers safety precautions, product features, technical specifications, installation, rigging, and array design for professional audio and touring applications.
---	--

 OWNER MANUAL HDL 6-A HDL 12-AS ACTIVE LINE ARRAY MODULE ACTIVE SUBWOOFER ARRAY MODULE RCF	RCF HDL 6-A and HDL 12-AS Owner Manual Comprehensive owner's manual for RCF HDL 6-A Active Line Array Module and HDL 12-AS Active Subwoofer Array Module, covering setup, safety, rigging, software, and specifications.
 OWNER MANUAL SUB 15-AX SUB 18-AX PROFESSIONAL SUBWOOFERS RCF	RCF SUB 15-AX and SUB 18-AX Professional Subwoofers Owner's Manual This manual provides detailed information on the RCF SUB 15-AX and SUB 18-AX professional subwoofers, covering safety precautions, product description, rear panel features, display operation, connections, troubleshooting, and specifications. It includes guidance on proper usage, maintenance, and installation for these high-power active subwoofers.
 OWNER MANUAL HDL 30-A HDL 38-AS ACTIVE TWO-WAY LINE ARRAY MODULE ACTIVE SUBWOOFER ARRAY MODULE RCF	RCF HDL 30-A and HDL 38-AS Owner Manual Comprehensive owner's manual for RCF HDL 30-A Active Two-Way Line Array Module and HDL 38-AS Active Subwoofer Array Module, covering safety, installation, rigging, software, and specifications for professional sound reinforcement.
 OWNER MANUAL MANUALE D'USO EVOX 12 PROFESSIONAL ACTIVE TWO-WAY ARRAY RCF	RCF EVOX 12 Professional Active Two-Way Array Owner Manual Comprehensive owner's manual for the RCF EVOX 12 portable active sound system, detailing safety precautions, product description, installation guide, rear panel connections, technical specifications, and dimensions.
 OWNER MANUAL MANUALE D'USO SUB 8008-AS PROFESSIONAL ACTIVE SUBWOOFER RCF	RCF SUB 8008-AS Professional Active Subwoofer Owner's Manual Comprehensive owner's manual for the RCF SUB 8008-AS professional active subwoofer, detailing safety precautions, technical specifications, setup, and troubleshooting.




[\[pdf\]](#) User Manual Owner's Manual Installation Guide

SUB 8006 AS 8005 8004 RCF 8004AS Active High Power Subwoofer User Manual cdn1 soniccircus |||

OWNER MANUAL **SUB 8006-AS** SUB 8005-AS HIGH OUTPUT ACTIVE
SUBWOOFERS SUB 8004-AS LANGUAGE ENGLISH 4 ITALIANO 11 3 ENGLISH
SAFETY PRECAUTIONS 1. All the precautions, in particular the safety ones, must be
read with special attention, as they provide important information. 2. POWER
SUPPLY...

lang:en **score:41** filesize: 654.71 K page_count: 20 document date: 2015-03-13




[\[pdf\]](#) User Manual Owner's Manual Installation Guide

SUB 8006 AS 8005 8004 RCF Manual webshop giantsound hu custom image data aktiv hangfalak |||

OWNER MANUAL **SUB 8006-AS** SUB 8005-AS HIGH OUTPUT ACTIVE
SUBWOOFERS SUB 8004-AS LANGUAGE ENGLISH 4 ITALIANO 11 3 ENGLISH
SAFETY PRECAUTIONS 1. All the precautions, in particular the safety ones, must be
read with special attention, as they provide important information. 2. POWER
SUPPLY...

lang:en **score:41** filesize: 864.59 K page_count: 20 document date: 2014-10-05




[\[pdf\]](#) User Manual Owner's Manual Installation Guide Instructions Accessories


Untitled sub 8006 as manual acueexpress 2022 09 |||

OWNER MANUAL **SUB 8006-AS** SUB 8005-AS HIGH OUTPUT ACTIVE
SUBWOOFERS SUB 8004-AS LANGUAGE ENGLISH 4 ITALIANO 11 2 1 Read
these instructions. 2 Keep these instructions. 3 Heed all warnings. 4 Follow all
instructions. 5 Do not use this apparatus near water. 6 Clean only with dry cloth...


lang:en **score:39** filesize: 607.71 K page_count: 20 document date: 2025-01-04




[\[pdf\]](#) User Manual Owner's Manual Installation Guide Instructions Accessories
SUB 8004AS Manual markertek Attachments Manuals RCF |||
OWNER MANUAL **SUB 8006-AS** SUB 8005-AS HIGH OUTPUT ACTIVE
SUBWOOFERS SUB 8004-AS LANGUAGE ENGLISH 4 ITALIANO 11 2 1 Read
these instructions. 2 Keep these instructions. 3 Heed all warnings. 4 Follow all
instructions. 5 Do not use this apparatus near water. 6 Clean only with dry cloth...
lang:en score:36 filesize: 668.4 K page_count: 20 document date: 2019-03-08



[\[pdf\]](#) User Manual Owner's Manual Installation Guide Instructions Accessories
SUB 8006AS Manual markertek Attachments Manuals RCF |||
OWNER MANUAL **SUB 8006-AS** SUB 8005-AS HIGH OUTPUT ACTIVE
SUBWOOFERS SUB 8004-AS LANGUAGE ENGLISH 4 ITALIANO 11 2 1 Read
these instructions. 2 Keep these instructions. 3 Heed all warnings. 4 Follow all
instructions. 5 Do not use this apparatus near water. 6 Clean only with dry cloth...
lang:en score:36 filesize: 668.4 K page_count: 20 document date: 2019-03-08




[\[pdf\]](#) User Manual Owner's Manual Installation Guide Instructions Accessories Catalog
SUB 8006 AS 8005 8004 9 Do not defeat the safety purpose of polarized or grounding type plug A has
two blades with one wider than other User Manual soundpro catalog documents The manual is to be
considered an integral part this product and must accompany it when changes ownership as a reference
for correct installation use well precautions 733689 bhphotovideo lit files 10307410 USER MANUAL rcf c
document library get file uuid 364aa34d d6cb 40d9 a30a 10df60b86c8f groupId 20195 f5cc4508 1866
4841 ab82 6b95cd11b62b
OWNER MANUAL **SUB 8006-AS** SUB 8005-AS HIGH OUTPUT ACTIVE
SUBWOOFERS SUB 8004-AS LANGUAGE ENGLISH 4 ITALIANO 11 2 1 Read
these instructions. 2 Keep these instructions. 3 Heed all warnings. 4 Follow all
instructions. 5 Do not use this apparatus near water. 6 Clean only with dry cloth...
lang:en score:33 filesize: 679.8 K page_count: 20 document date: 2018-07-18



[RCF HDL20-A and HDL10-A Active Line Array Modules Owner Manual](#)

Comprehensive owner's manual for RCF HDL20-A and HDL10-A active line array modules, detailing safety, installation, operation, and technical specifications for professional audio systems.

lang:en **score:32** filesize: 2.35 M page_count: 44 document date: 2019-03-08




[\[pdf\] User Manual Owner's Manual Installation Guide](#)

HDL20 A HDL10 2 giorni fa — Before connecting and using this product please read instruction manual carefully keep it on hand for future reference The is to be 10307833 USER MANUAL ENG ITA HDL 10 rcf en products detail hdl a p id dvel frontend web portlet ProductDownloadsPortlet lifecycle state normal mode view resource ProductFileEntry cacheability cacheLevelPage productCode STP0125 profileId 404609 |||

OWNER MANUAL MANUALE D USO HDL20-A ACTIVE LINE HDL10-A ARRAY MODULES ENGLISH LANGUAGE ENGLISH 3 ... ked on top of RCF subwoofers using the HDL fly bar. HDL 20-A compatible Subwoofers: - SUB 8004-AS - **SUB 8006-AS** - HDL 18-AS HDL 10-A compatible Subwoofers: - SUB 8004-AS - **SUB 8006-AS** - HDL 15-AS HDL...

lang:en **score:32** filesize: 1.77 M page_count: 48 document date: 2024-04-18




[\[pdf\] User Manual Owner's Manual Installation Guide Instructions Accessories](#)

SUB8004 8005 8006 AS MANUAL arispro ru RCF SUB 8004 купить Сабвуферы оптом в Москве Arispro |||

OWNER MANUAL **SUB 8006-AS** SUB 8005-AS HIGH OUTPUT ACTIVE SUBWOOFERS SUB 8004-AS 1 Read these instructions. 2 Keep these instructions. 3 Heed all warnings. 4 Follow all instructions. 5 Do not use this apparatus near water. 6 Clean only with dry cloth. 7 Do not block any ventilation openin...

lang:en **score:31** filesize: 420.28 K page_count: 10 document date: 2018-11-01



[pdf] User Manual Owner's Manual Installation Guide Instructions Accessories
303SB8004A RCF SUB 8004AS Active 18 Powered Subwoofer 2500 Watt Black Each CRUTCHFIELD
COM HNEWBERRY owner s manual powered PA subwoofer — 2500W peak at Crutchfield
crutchfieldonline ImageBank v20241022172000 Manuals 303 |||


OWNER MANUAL **SUB 8006-AS** SUB 8005-AS HIGH OUTPUT ACTIVE
SUBWOOFERS SUB 8004-AS 1 Read these instructions. 2 Keep these instructions.
3 Heed all warnings. 4 Follow all instructions. 5 Do not use this apparatus near water.
6 Clean only with dry cloth. 7 Do not block any ventilation openin...
lang:en score:31 filesize: 398.14 K page_count: 11 document date: 2024-10-22



[pdf] Specifications
RCF SUB 8006 AS United States308579fast images static thomann de pics atg atgdata document specs
308579 |||
SUB 8006-AS ACTIVE SUBWOOFER DESCRIPTION The **SUB 8006-AS** is the
largest and most powerful active sub woofer in the professional series. Featuring two
18 transducers, with 4 inside/outside voice coils, this cabinet is designed to delivery a
serious amount of low frequency. It is a direct radiating...
lang:en score:30 filesize: 429.73 K page_count: 3 document date: 2013-02-18



[pdf] Specifications Datasheet
SUB 8006 AS RCF 8006AS Active High Power Subwoofer Specification Sheet cdn1 soniccircus |||
DATASHEET **SUB 8006-AS** ACTIVE HIGH POWER SUBWOOFER DESCRIPTION
The **SUB 8006-AS** is the largest and most powerful active sub woofer in the
professional series. Featuring two 18 transducers, with 4 inside/outside voice coils,
this cabinet is designed to delivery a serious amount of low frequency. Powe...
lang:en score:30 filesize: 1.06 M page_count: 3 document date: 2018-03-30



[\[pdf\]](#) User Manual Owner's Manual Installation Guide

SUB 8004 8005 8006 AS Manual rcf it 80 de DE c document library get file p l id 8957959 folderld

3513515 name DLFE 23306 en US 11575049 IT

OWNER MANUAL **SUB 8006-AS** SUB 8005-AS HIGH OUTPUT ACTIVE

SUBWOOFERS SUB 8004-AS LANGUAGE ENGLISH 4 ITALIANO 11 3 ENGLISH

SAFETY PRECAUTIONS 1. All the precautions, in particular the safety ones, must be read with special attention, as they provide important information. 2. POWER SUPPLY...

lang:en **score:29** filesize: 868.94 K page_count: 20 document date: 2014-03-20



[\[pdf\]](#) Specifications Datasheet

Data Sheet RCF Bin SUB 8006 AS Speaker Artistic Solutions SPECSHEET ENG artisticsolutions co uk

2022 11 |||

DATASHEET **SUB 8006-AS** ACTIVE HIGH POWER SUBWOOFER DESCRIPTION

The **SUB 8006-AS** is the largest and most powerful active sub woofer in the professional series. Featuring two 18 transducers, with 4 inside/outside voice coils, this cabinet is designed to delivery a serious amount of low frequency. Powe...

lang:en **score:29** filesize: 5.34 M page_count: 6 document date: 2022-10-18



[\[pdf\]](#)


en SUB 8006 AS spec sheet rcf it 80 c document library get file uuid 2f133ed3 7ecd 4020 b555

1b2e42b01360 groupld 216492

SUB 8006-AS ACTIVE SUBWOOFER DESCRIPTION The **SUB 8006-AS** is the

largest and most powerful active sub woofer in the professional series. Featuring two 18 transducers, with 4 inside/outside voice coils, this cabinet is designed to delivery a serious amount of low frequency. It is a direct radiating...

lang:en **score:28** filesize: 431.99 K page_count: 3 document date: 2012-06-25



[pdf] User Manual Owner's Manual Installation Guide

RCF HDL 10 A Array Loudspeaker Modules User Manual ManualsBot manualsbot 2024 06 |||

OWNER MANUAL MANUALE D USO HDL20-A ACTIVE LINE HDL10-A ARRAY MODULES ENGLISH LANGUAGE ENGLISH 3 ... ked on top of RCF subwoofers using the HDL fly bar. HDL 20-A compatible Subwoofers: - SUB 8004-AS - **SUB 8006-AS** - HDL 18-AS HDL 10-A compatible Subwoofers: - SUB 8004-AS - **SUB 8006-AS** - HDL 15-AS HDL...

lang:en score:28 filesize: 4.1 M page_count: 44 document date: 2020-02-05



[pdf]

en SUB 8006 AS spec sheet service rcf it 80 c document library get file p l id 6700703 folderId 4259617 name DLFE 22610 |||

SUB 8006-AS ACTIVE SUBWOOFER DESCRIPTION The **SUB 8006-AS** is the largest and most powerful active sub woofer in the professional series. Featuring two 18 transducers, with 4 inside/outside voice coils, this cabinet is designed to delivery a serious amount of low frequency. It is a direct radiating...

lang:en score:28 filesize: 443.22 K page_count: 3 document date: 2013-06-14



[pdf] Specifications Datasheet


RCF SUB 8006 AS Active Subwoofer Loudspeaker @ Commercial Audio Solutions File 1656581484

commercialaudiosolutions fileuploader d 0 file custom upload |||

DATASHEET **SUB 8006-AS ACTIVE HIGH POWER SUBWOOFER DESCRIPTION**

The **SUB 8006-AS** is the largest and most powerful active sub woofer in the professional series. Featuring two 18 transducers, with 4 inside/outside voice coils, this cabinet is designed to delivery a serious amount of low frequency. Powe...


lang:en score:28 filesize: 5.43 M page_count: 6 document date: 2020-08-05



[\[pdf\]](#) User Manual Owner's Manual Installation Guide Instructions Accessories

Untitled sub 8004 as manual acueexpress 2022 09 |||


OWNER MANUAL **SUB 8006-AS** SUB 8005-AS HIGH OUTPUT ACTIVE SUBWOOFERS SUB 8004-AS LANGUAGE ENGLISH 4 ITALIANO 11 2 1 Read these instructions. 2 Keep these instructions. 3 Heed all warnings. 4 Follow all instructions. 5 Do not use this apparatus near water. 6 Clean only with dry cloth... lang:en **score:28** filesize: 607.71 K page_count: 20 document date: 2025-01-04



[\[pdf\]](#) User Manual Owner's Manual Installation Guide Instructions Accessories

ManuelRCF SUB 8004 AS Decibel SA10307410 user manual sub as 24341decibel ch upfiles documents 10307410 24341 RCF 8006 8005 Owner s ManualManuelRCF Active PA Subwoofer 5000 Watts 2x18 zZoundsRCF USER MANUAL AS10307410 24341cf3 zzounds media d8fdbbae1837c053ce3c152697e1a227decibel RCFRCF ManualManuelNon usare solventi alcool benzina o altre sostanze volatili per la pulitura delle parti esterne NOTE IMPORTANTI Prima di collegare ed utilizzare questo RCF 24341rcf it en products product detail p id dvel rcf frontend web portlet ProductInformationPortlet lifecycle 2 state normal mode view resource ProductFileEntry cacheability cacheLevelPage productCode STP0132 profileId 214926cf3 |||


OWNER MANUAL **SUB 8006-AS** SUB 8005-AS HIGH OUTPUT ACTIVE SUBWOOFERS SUB 8004-AS LANGUAGE ENGLISH 4 ITALIANO 11 2 1 Read these instructions. 2 Keep these instructions. 3 Heed all warnings. 4 Follow all instructions. 5 Do not use this apparatus near water. 6 Clean only with dry cloth... lang:en **score:28** filesize: 679.8 K page_count: 20 document date: 2018-07-18



[\[pdf\]](#) User Manual Owner's Manual Installation Guide

RCF HDL 10 A Musikhaus Thomann 327168 images static thomann de pics atg atgdata document manual |||

OWNER MANUAL HDL20-A ACTIVE LINE HDL10-A ARRAY MODULES ENGLISH LANGUAGE ENGLISH 3 ENGLISH SA ... p of RCF subwoofers with the dedicated accessories. HDL 20-A compatible Subwoofers: - SUB 8004-AS - **SUB 8006-AS** - HDL 18-AS HDL 10-A compatible Subwoofers: - SUB 8004-AS - **SUB 8006-AS** - HDL 15-AS 20 ... lang:en **score:27** filesize: 12.31 M page_count: 24 document date: 2013-11-06




[\[pdf\]](#) User Manual Owner's Manual Installation Guide

Uživatelský manuál EN RCF HDL 10 A ePRODANCE cz Manual HDL20A eprodance user documents related files |||

OWNER MANUAL HDL20-A ACTIVE LINE HDL10-A ARRAY MODULES ENGLISH LANGUAGE ENGLISH 3 ENGLISH SA ... p of RCF subwoofers with the dedicated accessories. HDL 20-A compatible Subwoofers: - SUB 8004-AS - **SUB 8006-AS** - HDL 18-AS HDL 10-A compatible Subwoofers: - SUB 8004-AS - **SUB 8006-AS** - HDL 15-AS 20 ...

lang:en **score:27** filesize: 12.33 M page_count: 24 document date: 2013-09-23



[\[pdf\]](#) Specifications

SUB 8006 AS Thomann The is the largest and most powerful active sub woofer in s efficiently tuned cabinet houses two RCF Precision back 308579 images thomann de pics atg atgdata document specs **SUB 8006-AS** ACTIVE SUBWOOFER DESCRIPTION The **SUB 8006-AS** is the largest and most powerful active sub woofer in the professional series. Featuring two 18 transducers, with 4 inside/outside voice coils, this cabinet is designed to delivery a serious amount of low frequency. It is a direct radiating...

lang:en **score:27** filesize: 429.73 K page_count: 3 document date: 2013-02-18




[\[pdf\]](#) User Manual Quick Start Guide

Lucio Boiardi Serri Microsoft RCF DX 1616 купить Контроллеры оптом в Москве Arispro USER MANUAL arispro ru |||

PROJECT FEATURES DX 1616 PROJECT MATRIX AUDIO PROCESSOR DX 1616 GP 1 Rev1 TABLE OF CONTENTS 1. GENERAL INFORMATIONS 3 1.1 GETTING STARTED

lang:tl **score:27** filesize: 1.14 M page_count: 12 document date: 2017-12-01




[\[pdf\]](#) User Manual Owner's Manual Installation Guide

303HDL20A RCF HDL 20A Active 2 way Dual 10 Line Array 1400 Watt Black Each CRUTCHFIELD COM
HNEWBERRY 20 A owner s manual dual line array module — 1400W peak at Crutchfield
crutchfieldonline ImageBank v20250416165000 Manuals 303 |||

OWNER MANUAL MANUALE D USO HDL20-A ACTIVE LINE HDL10-A ARRAY
MODULES ENGLISH SAFETY PRECAUTIONS ... ked on top of RCF subwoofers
using the HDL fly bar. HDL 20-A compatible Subwoofers: - SUB 8004-AS - **SUB
8006-AS** - HDL 18-AS HDL 10-A compatible Subwoofers: - SUB 8004-AS **SUB
8006-AS** - HDL 15-AS HDL...

lang:en **score:26** filesize: 1.46 M page_count: 23 document date: 2025-04-16




[\[pdf\]](#) User Manual Owner's Manual Installation Guide

303HDL10A RCF HDL 10A Active 2 way Dual 8 Line Array 1400 Watt Black Each CRUTCHFIELD COM
HNEWBERRY 10 A owner s manual White dual line array module — 1400W peak at Crutchfield
crutchfieldonline ImageBank v20250416160800 Manuals 303 |||

OWNER MANUAL MANUALE D USO HDL20-A ACTIVE LINE HDL10-A ARRAY
MODULES ENGLISH SAFETY PRECAUTIONS ... ked on top of RCF subwoofers
using the HDL fly bar. HDL 20-A compatible Subwoofers: - SUB 8004-AS - **SUB
8006-AS** - HDL 18-AS HDL 10-A compatible Subwoofers: - SUB 8004-AS **SUB
8006-AS** - HDL 15-AS HDL...

lang:en **score:26** filesize: 1.46 M page_count: 23 document date: 2025-04-16




[\[pdf\]](#) User Manual Owner's Manual

HDL 28 A ARISpro RU 2021 01 21 — Before rigging the system carefully read this manual RCF Easy
Shape Designer is a temporary software useful for setup of array mechanics MANUAL arispro ru |||

OWNER MANUAL HDL 28-A ACTIVE TWO-WAY LINE ARRAY MODULE 1.
INTRODUCTION The demands of modern sound reinforcement systems are higher
than ever before. Besides pure performance - high sound pressure levels, constant
directivity and sound quality other aspects are important for rental and producti...

lang:en **score:26** filesize: 6.42 M page_count: 32 document date: 2019-02-20



[\[pdf\]](#) User Manual Owner's Manual Installation Guide

10307302 USER MANUAL HDL 20 A rcf it 80 c document library get file uuid 848b99ea 2b9c 473e b604 8ad722b7b8ae groupId 20195

OWNER MANUAL MANUALE D USO HDL20-A ACTIVE LINE HDL10-A ARRAY MODULES ENGLISH LANGUAGE ENGLISH 3 ... ked on top of RCF subwoofers using the HDL fly bar. HDL 20-A compatible Subwoofers: - SUB 8004-AS - **SUB 8006-AS** - HDL 18-AS HDL 10-A compatible Subwoofers: - SUB 8004-AS -**SUB 8006-AS** - HDL 15-AS HDL...

lang:en **score:26** filesize: 2.38 M page_count: 44 document date: 2018-10-26




[\[pdf\]](#) Specifications Datasheet

Untitled sub 8006 as SpecSheet acueexpress 2022 09 |||

DATASHEET **SUB 8006-AS** ACTIVE HIGH POWER SUBWOOFER DESCRIPTION

The **SUB 8006-AS** is the largest and most powerful active sub woofer in the professional series. Featuring two 18 transducers, with 4 inside/outside voice coils, this cabinet is designed to delivery a serious amount of low frequency. Powe...

lang:en **score:25** filesize: 292.77 K page_count: 6 document date: 2025-01-04




[\[pdf\]](#) User Manual Owner's Manual

RCF HDL 36 AS lietošanas instrukcija RealPro 10307631 user manual hdl as realpro lv sites default files |||

OWNER MANUAL HDL 28-A HDL 36-AS ACTIVE TWO-WAY LINE ARRAY MODULE ACTIVE SUBWOOFER ARRAY MODULE 1. INTRODUCTION The demands of modern sound reinforcement systems are higher than ever before. Besides pure performance - high sound pressure levels, constant directivity and sound quality other aspec...

lang:en **score:25** filesize: 16.77 M page_count: 34 document date: 2019-09-18



[pdf] User Manual Owner's Manual Installation Guide Accessories

HDL20 A HDL10 HDL loudspeakers can be stacked on top of RCF subwoofers with the dedicated accessories 20 compatible Subwoofers SUB 8004 AS 8006 18 10 static makemusic tn manuals Speakers |||

OWNER MANUAL HDL20-A ACTIVE LINE HDL10-A ARRAY MODULES ENGLISH LANGUAGE ENGLISH 3 ENGLISH SA ... p of RCF subwoofers with the dedicated

accessories. HDL 20-A compatible Subwoofers: - SUB 8004-AS - **SUB 8006-AS** - HDL 18-AS HDL 10-A compatible Subwoofers: - SUB 8004-AS - **SUB 8006-AS** - HDL 15-AS 20 ...

lang:en score:25 filesize: 12.32 M page_count: 24 document date: 2014-03-19




[pdf] Specifications Datasheet

SUB 8006 AS Spec Sheet soundpro content product documents

DATASHEET **SUB 8006-AS** ACTIVE HIGH POWER SUBWOOFER DESCRIPTION

The **SUB 8006-AS** is the largest and most powerful active sub woofer in the professional series. Featuring two 18 transducers, with 4 inside/outside voice coils, this cabinet is designed to delivery a serious amount of low frequency. Powe...

lang:en score:25 filesize: 5.43 M page_count: 6 document date: 2020-01-30




[pdf] User Manual Specifications Catalog

SUB 9007 ASThe housing of the AS match RCF D Line HDL 50 and 20 array systems enabling stacked matched a perfect combination FeaturesSPECSHEET ENG ASmarket av ru image catalog rcf manual SPECSHEET |||

SUB 9007-AS ACTIVE HIGH POWER SUBWOOFER Description The SUB 9007-AS is one of the most powerful 2x21 subwoofers in the field of live sound. Featuring two, high power, hyper-vented 21 neodymium woofers with 4.0 inside-outside voice coils, this cabinet deliver a serious amount of low frequencies....


lang:en score:25 filesize: 2.48 M page_count: 3 document date: 2024-12-20



[\[pdf\]](#) User Manual Owner's Manual Installation Guide

RCF NX L 44A Thomann Polska 398791 images static thomann de pics atg atgdata document manual |||
OWNER MANUAL NX L44-A PROFESSIONAL ACTIVE TWO-WAY ARRAY N X
ENGLISH LANGUAGE ENGLISH 3 ITAL ... 60347 STACKING KIT 2X NXL 44-A Pole
mount accessory for stacking NXL44 on SUB 8004-AS, SUB 8005-AS, **SUB 8006-AS**,
SUB 9007-AS or M20 pole mount . INSTALLATION ACCESSORIES STACKING 2 x
NXL 44-A Dual ...

lang:en **score:25** filesize: 290.22 K page_count: 20 document date: 2016-09-15




[\[pdf\]](#) User Manual Owner's Manual Installation Guide

SUB 8004 8006 AS Manual shop proklang de WebRoot Sage Shops ProklangErfurt Webshop 5139 B24A
C2D8 9A14 664C 0A0C 05EA 194F |||

OWNER MANUAL **SUB 8006-AS** HIGH OUTPUT ACTIVE SUB 8004-AS
SUBWOOFERS LANGUAGE ENGLISH 4 ITALIANO 11 3 ENGLISH SAFETY
PRECAUTIONS 1. All the precautions, in particular the safety ones, must be read
with special attention, as they provide important information. 2. POWER SUPPLY
FROM MAINS a. T...

lang:en **score:25** filesize: 842.54 K page_count: 20 document date: 2014-01-28




[\[pdf\]](#) User Manual Owner's Manual

RCF HDL 30 A lietotāja rokasgrāmata B NEW! RealPro hdl a manual 10307581 revb realpro lv sites
default files |||

OWNER MANUAL HDL 30-A ACTIVE TWO-WAY LINE ARRAY MODULE 1.
INTRODUCTION The demands of modern sound reinforcement systems are higher
than ever before. Besides pure performance - high sound pressure levels, constant
directivity and sound quality other aspects are important for rental and producti...

lang:en **score:25** filesize: 5.52 M page_count: 32 document date: 2017-08-07



[\[pdf\]](#) User Manual Owner's Manual Installation Guide Specifications
OWNER MANUAL MANUALE D USO to wear ear plugs or protective earphones See the manual
technical specifications know maximum sound pressure level IMPORTANT NOTES To prevent
occurrence of noise on line signal cables use screened only and avoid putting them close Equipment that
produces high intensity electromagnetic fields Power A1y8BHAQorL Manual HDL 20 A 10 RevI 10307302
images na ssl amazon I rcf id 80 c document library get file p l id 5903307 folderId 6158866 name DLFE
21709 9941487 uuid 59780354 3fdf 4685 bd9d a998e64ae831 groupId 216492
OWNER MANUAL MANUALE D USO HDL20-A ACTIVE LINE HDL10-A ARRAY
MODULES ENGLISH LANGUAGE ENGLISH 3 ... p of RCF subwoofers with the
dedicated accessories. HDL 20-A compatible Subwoofers: - SUB 8004-AS - **SUB
8006-AS** - HDL 18-AS HDL 10-A compatible Subwoofers: - SUB 8004-AS -**SUB
8006-AS** - HDL 15-AS 20 ...
lang:en **score:25** filesize: 1.53 M page_count: 44 document date: 2015-07-01



[\[pdf\]](#) Specifications Datasheet
SUB 8006 AS specsheet fra sub as 31810 decibel ch upfiles documents |||
DATASHEET **SUB 8006-AS** SUBWOOFER ACTIF FORTE PUISSANCE
DESCRIPTION Le **SUB 8006-AS** est le subwoofer actif plus gros et le plus puissant
de la gamme professionnelle. quipe de deux transducteurs 18 avec bobines mobiles 4
inside/outside, l enceinte est conue pour produire d immenses basses frquences. ...
lang:fr **score:25** filesize: 5.35 M page_count: 6 document date: 2023-08-23



[\[pdf\]](#) Specifications Datasheet
CVR SUB 8006 specsheet fra cvr sub 93030 decibel ch upfiles documents |||
DATASHEET CVR SUB 8006 HOUSSE DE PROTECTION DESCRIPTION Housse
avec rembourrage **SUB 8006-AS**. Elle possde un tissu extrieur en polyester trs solide,
avec rembourrage en mousse de caoutchouc et fermetures clair avec renforts Velcro.
CARACTRISTIQUES Tissu extrieur : Polyester 600D sur base PVC Tissu...
lang:en **score:24** filesize: 559.78 K page_count: 2 document date: 2022-03-31



B24A C2D8 9A14 664C 0A0C 05EA 194F |||

lang:en score:24 filesize: 440.78 K page_count: 3 document date: 2015-02-09




name DLFE 36603 ru RU

lang:en score:24 filesize: 6.79 M page_count: 32 document date: 2017-09-22



lang:en score:23 filesize: 1.8 M page count: 44 document date: 2025-01-04




[\[pdf\]](#) User Manual Owner's Manual Installation Guide

Untitled 10307302 USER MANUAL HDL 20 A acueexpress 2022 09 |||

OWNER MANUAL MANUALE D USO HDL20-A ACTIVE LINE HDL10-A ARRAY MODULES ENGLISH LANGUAGE ENGLISH 3 ... ked on top of RCF subwoofers using the HDL fly bar. HDL 20-A compatible Subwoofers: - SUB 8004-AS - **SUB 8006-AS** - HDL 18-AS HDL 10-A compatible Subwoofers: - SUB 8004-AS **SUB 8006-AS** - HDL 15-AS HDL...

lang:en **score:23** filesize: 1.8 M page_count: 44 document date: 2025-01-04



[\[pdf\]](#) User Manual Owner's Manual

10307631 USER MANUAL HDL 28 A rcf it 80 c document library get file uuid 5a39542e 90d6 45c7 957d

5a1970d9e489 groupId 20195 a73aa39a c417 4e01 a52e afca5dc6d104

OWNER MANUAL HDL 28-A ACTIVE TWO-WAY LINE ARRAY MODULE 1.

INTRODUCTION The demands of modern sound reinforcement systems are higher than ever before. Besides pure performance - high sound pressure levels, constant directivity and sound quality other aspects are important for rental and producti...

lang:en **score:23** filesize: 7.03 M page_count: 32 document date: 2018-10-03