

[Manuals.plus](#) /

› [Tramontina](#) /

› Tramontina Non-Stick Frying Pan with Silicone Handle Instruction Manual (Model 20888/028)

Tramontina 20888/028

Tramontina Non-Stick Frying Pan with Silicone Handle Instruction Manual

Model: 20888/028

PRODUCT OVERVIEW

The Tramontina Non-Stick Frying Pan, Model 20888/028, is designed for versatile cooking in both domestic and professional kitchens. This 28 cm, 2.4-liter frying pan features a durable aluminum construction with a 3-layer PFOA-free non-stick interior coating, ensuring excellent food release and easy cleaning. It is equipped with a comfortable, stay-cool silicone handle and is compatible with all hob types, including induction, electric, gas, and ceramic glass.



Image: Tramontina Non-Stick Frying Pan, 28 cm, shown with its retail packaging.

SETUP AND FIRST USE

Before using your Tramontina frying pan for the first time, follow these steps to ensure optimal performance and longevity of the non-stick coating:

1. **Initial Cleaning:** Wash the frying pan thoroughly with a soft sponge and mild soap or detergent. Rinse well and dry completely.
2. **Seasoning the Pan:** After drying, lightly grease the entire internal non-stick surface with cooking oil or fat.
3. **Heating:** Heat the greased pan on a low to medium heat setting for one to two minutes.
4. **Cooling and Re-cleaning:** Allow the pan to cool down completely. Once cool, wash it again with a soft sponge and mild soap or detergent.
5. Your frying pan is now ready to be used with or without grease, always on low or medium heat.

OPERATING INSTRUCTIONS

The Tramontina frying pan is designed for efficient cooking on various heat sources.

- **Heat Settings:** Always use low to medium heat for cooking. High heat can damage the non-stick coating and is generally unnecessary due to the pan's efficient heat distribution.
- **Hob Compatibility:** This frying pan is suitable for all hob types, including induction, electric, gas, and ceramic glass cooktops. The stainless steel induction plate on the bottom ensures compatibility with induction surfaces.
- **Utensils:** To protect the non-stick coating, use only silicone, nylon, or wooden utensils when stirring, flipping, or serving food from the pan. Avoid metal utensils, which can scratch the surface.
- **Oven Use:** This frying pan is **not suitable for oven use** due to its silicone handle, which is designed to stay cool on the stovetop but cannot withstand oven temperatures.



Image: Tramontina Non-Stick Frying Pan containing sautéed vegetables, demonstrating typical use.

MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your non-stick frying pan.

- **Dishwasher Safe:** The frying pan is dishwasher safe for convenient cleaning.
- **Hand Washing:** For hand washing, use warm water, mild dish soap, and a soft sponge or cloth. Avoid abrasive cleaners, scouring pads, or steel wool, as these can damage the non-stick surface.
- **Stubborn Food Residue:** If food residue is stubborn, soak the pan in warm, soapy water for a short period before cleaning.
- **Storage:** When storing, place a soft cloth or pan protector between pans if stacking to prevent scratches to the non-stick coating.

TROUBLESHOOTING

This section addresses common concerns regarding non-stick frying pans.

- **Food Sticking:** If food begins to stick, ensure you are using a small amount of cooking oil or fat, especially if the pan has not been seasoned recently. Avoid overheating the pan. Re-seasoning the pan as per the "Setup and First Use" instructions can help restore non-stick properties.
- **Uneven Heating on Induction:** Ensure the pan is centered on the induction hob. Some induction cooktops may require a specific pan size for optimal performance. If the pan has been dropped or damaged, its base might be warped, affecting induction contact.
- **Scratches on Non-Stick Surface:** Scratches are typically caused by metal utensils or abrasive cleaning. Always use silicone, nylon, or wooden utensils and soft sponges for cleaning. Minor scratches generally do not affect the pan's performance or safety.

SPECIFICATIONS

Feature	Detail
Model Number	20888/028
Brand	Tramontina
Material	Aluminium, Silicone, Stainless Steel
Capacity	2.4 Liters
Diameter	28.9 cm
Height	9.9 cm
Length (with Handle)	47.8 cm
Weight	1.06 Grams
Non-Stick Coating	3-layer, PFOA-free
Handle Material	Silicone (Soft Touch)
Hob Compatibility	Induction, Electric, Gas, Ceramic Glass

Oven Safe	No
Dishwasher Safe	Yes
Maximum Temperature	260 Degrees Celsius (Stovetop use only)




Image: Technical diagram illustrating the dimensions (diameter, height, length with handle) of the frying pan.

WARRANTY INFORMATION

This Tramontina frying pan comes with a **90-day warranty** against manufacturing defects. This warranty covers defects in materials and workmanship under normal household use. It does not cover damage resulting from misuse, abuse, accidents, alterations, or commercial use. Please retain your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For further assistance, questions, or concerns regarding your Tramontina Non-Stick Frying Pan, please refer to the retailer

where the product was purchased or visit the official Tramontina website for contact information. Ensure you have your model number (20888/028) and proof of purchase available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question