

CHARGEWORX CX9014BK

Chargeworx CX9014BK Wireless Stereo Bluetooth Headset User Manual

Model: CX9014BK

INTRODUCTION

Welcome to your new Chargeworx CX9014BK Wireless Stereo Bluetooth Headset. This manual provides detailed instructions for setting up, operating, and maintaining your headset to ensure optimal performance and longevity. Please read this manual thoroughly before using your device.

PACKAGE CONTENTS

- Chargeworx CX9014BK Wireless Stereo Bluetooth Headset
- USB Charging Cable
- User Manual

PRODUCT OVERVIEW

Headset Components



The image above displays the Chargeworx CX9014BK Wireless Stereo Bluetooth Headset. It features a flexible neckband design with retractable earbuds for convenient storage. Key controls for power, volume, and playback are located on the neckband. The headset is black with subtle blue accents on the control buttons.

Key Features

- **Wireless Bluetooth Connectivity:** Seamlessly connect to your devices.

- **Vibrant Call Alert:** Notifies you of incoming calls with a vibration.
- **Up to 10 Hours Talk Time:** Extended battery life for calls and music playback.
- **Noise Reduction:** Enhances audio clarity during calls and music listening.
- **Premium Sound Quality:** Delivers clear and rich audio experience.
- **Magnetic Earbud Storage:** Keeps earbuds secure and tangle-free when not in use.
- **Text to Speech:** Converts text messages into spoken words (device dependent).
- **Voice Activated Dialing:** Initiate calls using voice commands (device dependent).
- **Music and Phone Controls:** Manage playback and calls directly from the headset.
- **Automatic Reconnection:** Automatically pairs with previously connected devices upon power-on.
- **Rechargeable Battery:** Convenient charging via standard USB.

SETUP

1. Charging the Headset

Before first use, fully charge the headset to ensure optimal battery performance.

1. Connect the small end of the USB charging cable to the charging port on the headset.
2. Connect the larger end of the USB charging cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The LED indicator will illuminate during charging and change color or turn off when fully charged.
4. Charging typically takes approximately 2-3 hours for a full charge.

2. Pairing with a Bluetooth Device

To connect your headset to a smartphone or other Bluetooth-enabled device:

1. Ensure the headset is turned off.
2. Press and hold the Power button on the headset until the LED indicator flashes rapidly (e.g., blue and red alternately), indicating pairing mode.
3. On your device, enable Bluetooth and search for new devices.
4. Select "Chargeworx CX9014BK" (or a similar name) from the list of available devices.
5. If prompted for a passcode, enter "0000".
6. Once paired, the LED indicator will flash slowly or turn solid blue, and you may hear an audible confirmation.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Press and hold the Power button until the LED indicator flashes blue and you hear a power-on tone.
- **Power Off:** Press and hold the Power button until the LED indicator flashes red and you hear a power-off tone.

Call Management

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for approximately 2 seconds.

- **Redial Last Number:** Double-press the Multi-function button.
- **Voice Activated Dialing:** Press and hold the Multi-function button until you hear a prompt, then speak your command (requires device support).
- **Vibrant Call Alert:** The headset will vibrate to notify you of an incoming call.

Music Playback

- **Play/Pause:** Press the Multi-function button once.
- **Next Track:** Press the Volume Up button for approximately 2 seconds.
- **Previous Track:** Press the Volume Down button for approximately 2 seconds.
- **Volume Up:** Press the Volume Up button briefly.
- **Volume Down:** Press the Volume Down button briefly.

Text to Speech

When enabled on your connected device, the headset can read out incoming text messages. Refer to your device's settings for Text to Speech configuration and activation.

MAINTENANCE

Cleaning

Wipe the headset with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the headset in water.

Storage

Store the headset in a cool, dry place away from direct sunlight and extreme temperatures. The magnetic earbuds help keep the cables tidy and prevent tangling.

Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Charge the headset regularly, even if not in use for extended periods, to maintain battery health.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Solution
Headset does not power on.	Ensure the battery is charged. Connect to a power source and try again.
Cannot pair with device.	Ensure headset is in pairing mode (flashing blue/red LED). Make sure Bluetooth is enabled on your device and it's within range. Forget previous pairings on your device and try again.
No sound or poor sound quality.	Check volume levels on both headset and connected device. Ensure headset is properly paired. Move closer to your device to avoid interference.

Problem	Solution
Disconnections during use.	Ensure your device is within the Bluetooth range (typically 10 meters/33 feet). Avoid obstacles between the headset and device.

SPECIFICATIONS

Technical Details

- **Model Number:** CX9014BK
- **Connectivity:** Wireless Bluetooth
- **Talk Time:** Up to 10 hours
- **Material:** Faux Leather (neckband)
- **Weight:** 3.8 Ounces (approx. 107.7 grams)
- **Color:** Black (based on product image)
- **Special Features:** Noise Reduction, Text to Speech, Voice Activated Dialing, Magnetic Earbud Storage, Vibrant Call Alert

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Chargeworx website for the most up-to-date information.