

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Jojospring](#) /

› [Jojospring Elisa 4-Light Flushmount Chandelier Instruction Manual](#)

Jojospring L331-TD-635

Jojospring Elisa 4-Light Flushmount Chandelier

Model: L331-TD-635

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Jojospring Elisa 4-Light Antique Black and Crystal Flushmount Chandelier. Please read all instructions carefully before beginning installation and retain this manual for future reference.

The Elisa chandelier features an antique black finish with crystal accents, designed for indoor use only. Assembly of crystal components is required.

SAFETY INFORMATION

- **WARNING:** Risk of electric shock. Disconnect power at the circuit breaker or fuse box before installation or servicing.
- All wiring connections must be in accordance with local and national electrical codes (NEC). Consult a qualified electrician if you are unfamiliar with proper electrical wiring.
- This fixture is intended for indoor use only. Do not expose to water or moisture.
- Ensure the mounting surface can support the weight of the fixture.
- Do not exceed the maximum wattage specified for the bulbs.
- Handle crystal components with care to prevent breakage.

PACKAGE CONTENTS

Verify that all components are present before discarding packaging materials.

- Mounting Bracket
- Fixture Canopy (Antique Black)
- Crystal Strands and Pendants
- Mounting Hardware (screws, wire nuts)
- Instruction Manual



Figure 1: Front view of the Jojospring Elisa 4-Light Flushmount Chandelier with crystal details.

SETUP AND INSTALLATION

Estimated Installation Time: 60-90 minutes (requires assembly of crystal components).

1. Prepare for Installation

1. Turn off power at the main circuit breaker or fuse box.
2. Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches.
3. Review the package contents list to ensure all parts are present.

2. Install Mounting Bracket

1. Attach the mounting bracket to the junction box in the ceiling using the provided screws. Ensure the bracket is securely fastened.

3. Wiring Connections

1. Connect the fixture's black wire to the house's black (hot) wire using a wire nut.
2. Connect the fixture's white wire to the house's white (neutral) wire using a wire nut.
3. Connect the fixture's ground wire to the house's ground wire (bare copper or green) and to the mounting bracket using a ground screw.
4. Carefully tuck all wires into the junction box.

4. Mount the Fixture Canopy

1. Align the fixture canopy with the mounting bracket and secure it using the decorative nuts or screws provided.



Figure 2: Chandelier dimensions as depicted in the image, showing approximately 13.8 inches width and 9.2 inches height. Refer to specifications for exact product dimensions.

5. Assemble Crystal Components

The crystal components are typically attached using small metal rings or hooks. Refer to the diagram (if provided with physical product) for specific placement.

1. Carefully attach each crystal strand and pendant to the designated holes on the fixture frame.
2. Ensure all crystals are securely fastened to prevent them from falling.



Figure 3: Detailed view of the crystal arrangement on the chandelier.

6. Install Light Bulbs

1. Insert four (4) Candelabra (E12) bulbs (not included) into the sockets.
2. Do not exceed the maximum wattage of 60 watts per bulb. Halogen bulbs are recommended.

7. Restore Power

1. Once installation is complete, restore power at the circuit breaker.
2. Test the fixture to ensure proper operation.

OPERATING INSTRUCTIONS

The Jojospring Elisa Chandelier is operated via a standard wall switch (not included) connected to the fixture's electrical circuit. Ensure the wall switch is in the "ON" position to illuminate the chandelier.

- **To Turn On:** Flip the connected wall switch to the "ON" position.
- **To Turn Off:** Flip the connected wall switch to the "OFF" position.

MAINTENANCE

Cleaning

- Always disconnect power before cleaning.
- To clean the fixture, wipe with a soft, dry cloth.
- For crystal components, a soft, damp cloth with a mild glass cleaner can be used. Avoid harsh chemicals or abrasive cleaners, as they may damage the finish or crystals.
- Ensure the fixture is completely dry before restoring power.

Bulb Replacement

- Turn off power at the circuit breaker before replacing bulbs.
- Allow bulbs to cool completely before touching them.
- Unscrew the old bulb and screw in a new Candelabra (E12) bulb, ensuring it does not exceed 60 watts.
- Restore power and test.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	<ul style="list-style-type: none">• Power is off at the circuit breaker.• Loose wiring connection.• Bulb is faulty or not properly seated.• Wall switch is off.	<ul style="list-style-type: none">• Check circuit breaker and turn power on.• Verify all wiring connections are secure (with power off).• Replace bulb or ensure it is screwed in tightly.• Turn wall switch to "ON" position.
Flickering light.	<ul style="list-style-type: none">• Loose bulb.• Incorrect bulb type or wattage.• Loose wiring.	<ul style="list-style-type: none">• Tighten bulb.• Ensure correct E12, 60W max bulbs are used.• Check wiring connections (with power off).

SPECIFICATIONS

Model Number	L331-TD-635
Brand	Jojospring
Fixture Dimensions	15 inches (Diameter) x 9.1 inches (Height)
Material	Crystal, Iron
Finish	Antique Black (black finish with a light brush of brown)
Crystal Color	Clear
Number of Lights	4
Bulb Type	Candelabra (E12)

Max Wattage per Bulb	60 Watts
Voltage	120 Volts
Light Source Type	Halogen (recommended)
Installation Type	Semi Flush Mount
Indoor/Outdoor Usage	Indoor use only
Certifications	ETL/cETL listed
Item Weight	8.8 pounds (approx. 4 kg)

WARRANTY INFORMATION

This Jojospring product is covered by a manufacturer's warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your purchase or contact Jojospring customer support directly.

CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or need to report missing/damaged parts, please contact Jojospring customer support. Have your model number (L331-TD-635) and purchase information ready when contacting support.

Contact information for Jojospring can typically be found on their official website or on the product packaging.