Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Disney /
- > Kid Trax Dodge Police Car Ride-On (Model KT1111WM) Instruction Manual

Disney KT1111WM

Kid Trax Dodge Police Car Ride-On (Model KT1111WM) Instruction Manual

For Model: KT1111WM

IMPORTANT SAFETY INFORMATION

WARNING: This product can expose you to chemicals including lead and lead compounds, which is known to the State of California to cause cancer, and birth defects or other reproductive harm. For more information, please visit www.P65Warnings.ca.gov. Always ensure children are supervised during operation. Read all instructions before use.

PRODUCT OVERVIEW

The Kid Trax Dodge Police Car Ride-On (Model KT1111WM) is a 12-volt battery-powered two-seater toy vehicle designed for children aged 3-7 years, with a maximum weight limit of 120 lbs. This vehicle features authentic flashing lights, siren sounds, realistic engine sound effects, and a working megaphone PA system. It includes real working car doors, functional side mirrors, a vinyl seat cover, and chromestyle rims, tailpipes, and headlights.



Figure 1: Front three-quarter view of the Kid Trax Dodge Police Car Ride-On.

WHAT'S IN THE BOX

- Electric Ride On Vehicle
- 12V Rechargeable Battery
- Wall Charger
- Assembly Hardware (as required)

ASSEMBLY AND SETUP

Detailed assembly instructions are provided in the separate assembly guide included with your product. Please follow all steps carefully.

- 1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging materials until assembly is complete.
- 2. Wheel Installation: Attach wheels according to the assembly guide, ensuring all fasteners are securely tightened.
- 3. Steering Wheel Attachment: Secure the steering wheel to the steering column.
- 4. Battery Connection: Connect the 12V rechargeable battery as instructed. Ensure proper polarity.
- 5. **Initial Charge:** Before first use, fully charge the battery for the recommended duration (typically 18 hours). Refer to the "Charging the Battery" section for details.



Figure 2: The Kid Trax Dodge Police Car Ride-On with two children, demonstrating its two-seater capacity.

CHARGING THE BATTERY

The vehicle is powered by a 12V rechargeable battery. Use only the provided wall charger.

- 1. Locate the Direct Connect charging system port on the vehicle.
- 2. Plug the wall charger into a standard electrical outlet.
- 3. Connect the charger to the vehicle's charging port.
- 4. Allow the battery to charge for the recommended time (typically 18 hours for the first charge, and 8-12 hours for subsequent charges). Do not overcharge.
- 5. The electric battery charge indicator will show the current battery level.



Figure 3: The Direct Connect charging port for the 12V battery.

OPERATING INSTRUCTIONS

Familiarize yourself with the controls before operating the vehicle.

- Power On/Off: Use the main power switch to turn the vehicle on or off.
- **Driving:** Press the foot pedal to engage the motor. Release the pedal to brake.
- Speed Selection: The vehicle offers forward speeds of 2.5 MPH and a top speed of 5 MPH. A reverse speed of 2.5 MPH is also available. Select the appropriate speed setting for the driver's skill level and environment.
- Steering: Use the steering wheel to control direction.
- Working Doors: The vehicle features real working doors for easy entry and exit.
- Lights & Sounds: Activate flashing lights and siren sounds using the designated buttons.
- Megaphone PA System: Use the working megaphone PA system for interactive play.
- FM Radio & MP3 Jack: The vehicle includes a working FM radio and an MP3 auxiliary jack for audio playback.



Figure 4: Interior view highlighting the dashboard controls and seating area.

MAINTENANCE

- Cleaning: Wipe the vehicle with a damp cloth. Do not use abrasive cleaners or submerge in water.
- Battery Care:
 - o Charge the battery after each use.
 - If storing for extended periods, charge the battery monthly to prolong its lifespan.
 - Do not store the battery in extreme temperatures.
- Tire Inspection: Regularly check the Power Trax rubber traction strip tires for wear and damage.
- General Inspection: Periodically inspect all nuts, bolts, and fasteners to ensure they are tight.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|------------------------------|---|--|
| Vehicle does not move | Battery is low or not connected; Thermal fuse tripped; Loose wire connection. | Charge battery; Allow vehicle to cool down; Check all connections. |
| Vehicle runs slowly | Battery is low; Overloaded vehicle; Operating on rough terrain. | Charge battery; Reduce load; Operate on smooth surfaces. |
| Lights or sounds not working | Loose wire connection; Damaged component. | Check connections; Contact customer support for replacement parts. |

SPECIFICATIONS

• Model Number: KT1111WM

• Battery: 12 Volt Rechargeable

Recommended Age: 36 months - 7 years
 Maximum Weight Capacity: 120 lbs

• Speeds: Forward 2.5 MPH, Forward 5 MPH, Reverse 2.5 MPH

• Product Dimensions: 23 x 33 x 60 inches

• Item Weight: 73 pounds

• Manufacturer: Pacific Cycle, Inc. (Dropship)

WARRANTY AND CUSTOMER SUPPORT

For warranty information, replacement parts, or technical assistance, please refer to the warranty card included with your product or contact the manufacturer directly.

Manufacturer: Pacific Cycle, Inc.

For customer support, please visit the Disney Store on Amazon or the Kid Trax official website.



Related Documents - KT1111WM




6V Frozen 2 Quad Ride On - User Manual and Safety Guidelines

This document provides essential safety guidelines, vehicle care instructions, battery information, and assembly steps for the Disney Frozen 6V Quad Ride On toy, model KL-40052.




Disney Stitch Bumper Car 6V Electric Ride-On Owner's Manual & Safety Guide

Comprehensive owner's manual for the Disney Stitch Bumper Car 6V Electric Ride-On (Model 43610617). Includes maintenance, safety warnings, troubleshooting, charging instructions, and assembly guide.



Interactive Banshee Hatchling: Setup and Operation Guide

Comprehensive instruction sheet for the Interactive Banshee Hatchling toy, detailing setup, activation, interaction modes, and battery information. Learn how to bring your Banshee to life.



Disney Program Seeker Droid SW423 Instructions

Official instruction guide for the Disney Program Seeker Droid SW423, detailing its components, controls, and FCC compliance information.



Disney Remote Control Trackless Train Instruction Manual

Comprehensive instructions for operating the Disney Remote Control Trackless Train, covering independent mode, follow-me mode, try-me mode, technical specifications, and safety warnings.



<u>Disney Stitch RC Surfing Stitch Toy - Instructions and Operation</u>

Guide for the Disney Stitch RC Surfing Stitch toy, covering battery installation, charging, simultaneous use, and important safety warnings. Learn how to operate your Stitch RC vehicle.