

Vileda B01HTTQ6A2

Vileda Easy Wring and Clean Turbo Microfibre Mop and Bucket Set User Manual

Model: B01HTTQ6A2

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your Vileda Easy Wring and Clean Turbo Microfibre Mop and Bucket Set. Please read this manual carefully before first use to ensure proper and safe operation of the product.

IMPORTANT SAFETY INFORMATION

- Keep out of reach of children and pets.
- Do not use the product for purposes other than its intended use of floor cleaning.
- Ensure the bucket is placed on a stable, flat surface during use to prevent tipping.
- Avoid overfilling the bucket to prevent spillage.
- Exercise caution when operating the foot pedal to prevent injury.
- Do not use harsh chemicals or abrasive cleaners on the product components.

PACKAGE CONTENTS

Verify that all components are present in the package:

- Vileda Easy Wring and Clean Turbo Bucket
- Telescopic Mop Handle (multiple sections)
- Mop Head Frame
- Microfibre Mop Head



Image: The complete Vileda Easy Wring and Clean Turbo Mop and Bucket Set, showing the red and grey bucket with a foot pedal, and the mop with its telescopic handle and white and red microfiber head.

SETUP INSTRUCTIONS

1. **Assemble the Mop Handle:** Screw the sections of the telescopic mop handle together clockwise until securely fastened.
2. **Attach the Mop Head Frame:** Connect the assembled handle to the mop head frame by screwing it in clockwise.
3. **Attach the Microfibre Mop Head:** Align the microfibre mop head with the mop head frame and press firmly until it clicks into place. Ensure all plastic clips are engaged.
4. **Adjust Handle Length:** Twist the telescopic handle to unlock, extend to your desired length, and twist again to lock.

OPERATING INSTRUCTIONS

Filling the Bucket

- Fill the bucket with water and your preferred floor cleaning solution up to the indicated maximum fill line.

Mopping

1. Dip the microfibre mop head into the water in the bucket, ensuring it is fully saturated.
2. Place the wet mop head into the wringer basket.
3. Press the foot pedal repeatedly to spin the wringer basket. The more times you press the pedal, the drier the mop head will become.
4. Remove the mop head from the wringer and begin cleaning your floor.
5. For optimal cleaning, ensure the mop head is damp, not soaking wet.



Image: A foot pressing the pedal on the Vileda bucket, demonstrating the "Pedal Power for Wetness Control" feature, with a gauge showing wet to dry levels.



Image: A man standing in a living room, holding the Vileda mop next to the bucket, illustrating the "Easy Spin & Dry with Pedal" functionality.

**REACHES IN
CORNERS**



Image: The triangular mop head positioned perfectly into a room corner, demonstrating its ability to reach tight spaces.

**+ 20%
PARTICLE PICKUP**



Image: A close-up view of the Vileda microfiber mop head, highlighting its texture and design for effective particle pickup, indicating its efficiency in cleaning.

MAINTENANCE

Cleaning the Microfibre Mop Head

- The microfibre mop head is machine washable. To remove, gently pull the mop head away from the frame.
- Wash the mop head at a maximum temperature of 60°C (140°F) with similar colors.
- Do not use bleach or fabric softener, as these can damage the microfibres.
- Air dry the mop head; do not tumble dry.



Image: Hands detaching the microfibre mop head from its frame, with a washing machine in the background, indicating its machine washable feature.

Cleaning the Bucket

- After each use, empty the bucket and rinse it thoroughly with clean water.
- Wipe the bucket dry or allow it to air dry to prevent mildew and odors.
- Periodically clean the wringer mechanism to remove any accumulated debris.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Mop head not wringing dry enough.	Not enough pedal presses; wringer mechanism clogged.	Press the foot pedal more times. Check and clean the wringer basket for debris.
Mop head detaches during use.	Mop head not securely attached to the frame.	Ensure all plastic clips on the mop head are firmly engaged with the frame.
Telescopic handle slips or won't lock.	Handle not twisted securely; internal mechanism dirty.	Twist the handle firmly to lock. If issue persists, clean the internal locking mechanism.
Bucket leaks.	Overfilled bucket; crack in bucket.	Do not fill past the maximum fill line. Inspect the bucket for damage; if cracked, replace the bucket.

SPECIFICATIONS

- **Model:** B01HTTQ6A2
- **Brand:** Vileda
- **Color:** Grey/Red
- **Material (Bucket):** Plastic
- **Handle Material:** Plastic (Telescopic)

- **Head Material:** Microfiber
- **Mop Head Washable:** Yes, machine washable up to 60°C


WARRANTY AND SUPPORT

For information regarding warranty coverage or product support, please refer to the documentation provided with your purchase or visit the official Vileda website. Keep your proof of purchase for warranty claims.

Vileda Official Website: www.vileda.com

Vileda Official Website: www.vileda.com

Related Documents

FAQ's Frequently Asked Questions Can I use the Vileda Mop for the carpet? You can use the mop for the carpet, but it is not recommended to use it on the carpet for the first time. Can I use the mop for the carpet? You can use the mop for the carpet, but it is not recommended to use it on the carpet for the first time. Can I use the mop for the carpet? You can use the mop for the carpet, but it is not recommended to use it on the carpet for the first time.	Vileda Ultramax Mop: Frequently Asked Questions Find answers to common questions about the Vileda Ultramax Complete Mop and Bucket Set, including cleaning instructions, suitable surfaces, and set contents.
	Vileda Looper/Looper One Electrical Spray Mop User Manual Comprehensive user manual for the Vileda Looper and Looper One electrical spray mops, covering assembly, operation, charging, safety, and warranty information.
	Vileda VR 102 / VR ONE Robot Vacuum Cleaner User Guide Comprehensive user and care guide for the Vileda VR 102 and VR ONE robotic vacuum cleaners. Learn about product features, setup, charging, maintenance, troubleshooting, and warranty.
	Vileda Steam Mop User Manual and Safety Guide Comprehensive guide for the Vileda Steam Mop, covering assembly, operation, safety precautions, troubleshooting, and maintenance. Learn how to effectively use the steam mop for hygienic cleaning of floors and carpets.

Documents - Vileda – B01HTTQ6A2

[illegible]

[Comprehensive Product Catalog - Home & Kitchen Appliances](#)

Explore a wide range of home and kitchen products, including robotic vacuums, espresso machines, kitchen appliances, and more, with detailed descriptions and pricing.

lang:en score:23 filesize: 936.75 K page count: 16 document date: 2018-09-19

[illegible]

[\[pdf\]](#) User Manual

Domča GL NAME SUBCATDESC ASIN EAN Merkandi Kokido EV81CBX EU Limpiafondos Manual

Vektro X 400 con bater  a recargable 1 189 95 Furniture Foam Mattresses B076VB5HSM 17home
merkandi products

GL NAME Lawn and Garden Lawn and Garden Furniture Home Home Lawn and
Garden Home Home Lawn and Garde ... BAKQ Pots Planters B007HOGTOS Storage
/ Cans / Containers B017NZO3MU Non Electric Floorcare **B01HTTQ6A2** Non Electric
Floorcare **B01HTTQ6A2** Non Electric Floorcare **B01HTTQ6A2** Art Furniture ...
lang:en score:23 filesize: 471.09 K page_count: 6 document date: 2019-07-01

[Catálogo de Electrodomésticos y Productos para el Hogar | Ofertas y Precios](#)

Explore un extenso catálogo de electrodomésticos, electrónica y artículos para el hogar de marcas líderes como Cecotec, Philips, Bosch, Rowenta y más. Encuentre aspiradoras robot, robots de cocina, cafeteras, planchas de vapor y una gran variedad de productos para su hogar con especificaciones detalladas y precios competitivos.

lang:de score:19 filesize: 1.09 M page_count: 18 document date: 2019-06-28

[\[pdf\]](#) User Manual

Domča GL NAME SUBCATDESC ASIN EAN Merkandi Espresso Manual B0786JNB62 4060449034284

Beem 03428 Siebträ    germaschine 1110SR Elements of Coffee Tea 1450 W 19 b 78kitchen merkandi
products

GL NAME SUBCATDESC ASIN Kitchen Espresso Fully Automatic B077ZK2K9D
Kitchen Espresso Fully Au ... es B00UZ8UD86 886468361415 Shoes Boots
B01MT02QJ3 887350956429 Home Cleaning Tools Supplies **B01HTTQ6A2**
4023103194113 Home Cleaning Tools Supplies **B01HTTQ6A2** 4023103194113
Home Food Bev...

lang:en score:19 filesize: 900.33 K page_count: 12 document date: 2019-08-07

lang:en score:16 filesize: 1.11 M page count: 84 document date: 2018-12-08

[illegible][illegible]

lang:en score:15 filesize: 1.19 M page_count: 36 document date: 2019-06-06

[illegible]lang:en score:15 filesize: 1.43 M page_count: 20 document date: 2019-07-04

A detailed catalog featuring a wide range of consumer products including personal care appliances, electronics, furniture, home goods, and more. Each listing provides product name, category, and pricing details.

lang:en score:12 filesize: 1.56 M page_count: 26 document date: 2019-03-06

Domča GL NAME SUBCATDESC ASIN EAN Merkandi Marcato PastaSet MâșĂ°quina para Pasta

Manual con Accesorios Incluido Acero Cromado Plata 20 X 1 82 85 PC Mice B01BH9E4SG

5707119025942 106home merkandi products

GL NAME Home Pet Products Home Office Product PC Home Office Product Home
Home Pet Products Home PC ... lbs B0748N23WS 8718696695265 Measuring Tools
B001492TD2 4006501021458 Cleaning Tools Supplies **B01HTTQ6A2**
4023103194113 Drinkware Coffee Tea CuBp0s01S2AHES 630870039680 Candles
B003O69FMG 75...

lang:de score:12 filesize: 1.48 M page_count: 49 document date: 2019-06-10