

[Manuals.plus](#) /

› [Braven](#) /

› Braven 105 Wireless Portable Bluetooth Speaker User Manual

Braven B105CYE

Braven 105 Wireless Portable Bluetooth Speaker User Manual

Model: B105CYE

INTRODUCTION

The Braven 105 is a compact, disc-shaped wireless portable Bluetooth speaker designed for on-the-go use. It features a durable, waterproof construction and comes with a versatile elastic strap and action mount accessory for various attachment options. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Braven 105 speaker.



Image: The Braven 105 speaker in blue with yellow accents, showcasing its compact, disc-shaped design.

WHAT'S IN THE BOX

Your Braven 105 package should contain the following items:

- Braven 105 Bluetooth Speaker
- Charger (USB cable)
- Action Mount/Stand Accessory



Image: The included action mount accessories, consisting of a black stand and a clip mount, designed to enhance the speaker's versatility.

SAFETY INFORMATION

Please read and follow these safety guidelines to ensure proper use and longevity of your Braven 105 speaker:

- Do not attempt to disassemble or modify the speaker.
- Avoid exposing the speaker to extreme temperatures (hot or cold).
- Ensure the charging port cover is securely closed before exposing the speaker to water to maintain its waterproof rating.
- Use only the provided charger or a certified equivalent.
- Keep the speaker away from open flames or heat sources.
- Do not submerge the speaker beyond 1 meter (3.3 feet) for more than 30 minutes.

SETUP

1. Charging the Speaker

Before first use, fully charge your Braven 105 speaker. The internal rechargeable battery provides up to 8 hours of continuous wireless playtime.

1. Locate the charging port on the side of the speaker, usually protected by a waterproof cover.
2. Open the cover and connect the provided USB charging cable to the speaker and a compatible USB power source (e.g., computer USB port, wall adapter).
3. The LED indicator will show charging status (refer to the speaker's specific LED behavior for full charge indication, typically solid green or off when fully charged).
4. Once charging is complete, securely close the waterproof cover to protect the port.

2. Bluetooth Pairing

To connect your Braven 105 to a Bluetooth-enabled device:

1. Power on the Braven 105 speaker by pressing and holding the Power button (usually the middle button on the side) until you hear an audible cue or see the LED indicator light up.
2. The speaker will automatically enter pairing mode, indicated by a flashing LED (e.g., blue flashing light).
3. On your device (smartphone, tablet, computer), go to the Bluetooth settings.
4. Search for available devices and select "BRAVEN 105" from the list.
5. Once connected, the LED indicator will typically turn solid blue, and you may hear a confirmation tone.
6. If prompted for a passcode, enter "0000".



Image: A side view of the Braven 105 speaker, highlighting the accessible power and volume control buttons.

3. Attaching the Action Mount/Stand

The Braven 105 comes with a versatile action mount accessory for various mounting options.

- **Using the Stand:** Align the speaker with the stand accessory and slide it into place until it clicks securely. This allows the speaker to stand upright on flat surfaces.
- **Using the Strap:** The integrated elastic strap can be used to hang the speaker or attach it to objects like handlebars or poles.
- **Using the Clip Mount:** The clip mount can be attached to the speaker's rear mounting point, allowing it to be clipped onto various surfaces or integrated with other action camera accessories.



Image: The Braven 105 speaker securely placed on its dedicated black stand, ready for tabletop use.

OPERATING INSTRUCTIONS

Power On/Off

- **To Power On:** Press and hold the Power button (middle button) for approximately 2-3 seconds.
- **To Power Off:** Press and hold the Power button for approximately 2-3 seconds until the LED indicator turns off.

Volume Control

- **Increase Volume:** Press the '+' button.
- **Decrease Volume:** Press the '-' button.

Bluetooth Connection Management

- The speaker will automatically attempt to reconnect to the last paired device when powered on.
- To pair with a new device, ensure Bluetooth is off on the previously connected device, or put the speaker into pairing mode manually (refer to your speaker's specific instructions, often by holding the power button longer or a dedicated Bluetooth button if available).

Speakerphone Functionality

The Braven 105 features a built-in speakerphone with noise-canceling technology.

- **Answer Call:** Press the Power button once when a call comes in.
- **End Call:** Press the Power button once during a call.
- **Reject Call:** Press and hold the Power button for 2 seconds when a call comes in.

Waterproof Usage

The Braven 105 has an IPX7 waterproof rating, meaning it can be submerged in up to 1 meter (3.3 feet) of water for up to 30 minutes.

- Always ensure the charging port cover is completely sealed before exposing the speaker to water.
- Do not expose the speaker to saltwater or chlorinated water for extended periods without rinsing with fresh water afterward.
- The speaker is designed for temporary submersion, not continuous underwater use.



Image: The Braven 105 speaker, shown resisting water spray, highlighting its IPX7 waterproof design suitable for outdoor and wet environments.

MAINTENANCE

- **Cleaning:** Use a soft, damp cloth to clean the speaker. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** After exposure to water, ensure the speaker is thoroughly dry before charging or opening any ports.
- **Storage:** Store the speaker in a cool, dry place when not in use. Avoid prolonged exposure to direct sunlight or extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in constant use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is drained.	Charge the speaker using the provided USB cable.
Cannot pair with Bluetooth device.	Speaker is not in pairing mode; device's Bluetooth is off; speaker is already connected to another device.	Ensure speaker is in pairing mode (flashing LED). Turn off and on Bluetooth on your device. Disconnect from other devices.

Problem	Possible Cause	Solution
No sound or low volume.	Volume on speaker or device is too low; speaker is not connected.	Increase volume on both the speaker and your connected device. Re-establish Bluetooth connection.
Sound distortion at high volume.	Volume is too high.	Reduce the volume on the speaker or your connected device.
Speaker unexpectedly shuts down.	Low battery.	Recharge the speaker.

SPECIFICATIONS

Model Number: B105C YE

Connectivity: Bluetooth

Water Resistance: IPX7 (submersible up to 1 meter for 30 minutes)

Playtime: Up to 8 hours

Power Output: 10 Watts

Dimensions: 3.8 x 3.8 x 1.3 inches (9.65 x 9.65 x 3.3 cm)

Weight: 7 ounces (198 grams)

Power Source: Battery Powered (1 Lithium Ion battery required)

Included Components: Bluetooth Speaker, Charger, Action Mount/Stand

UPC: 817729013156

WARRANTY AND SUPPORT

Braven products are designed for durability and performance. For specific warranty details and support, please refer to the warranty card included with your product or visit the official Braven website. You can also find frequently asked questions and contact information for customer service there.

For the latest information and support, please visit:www.braven.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question