

[Manuals.plus](#) /

› [upbright](#) /

› UpBright 12V DC Adapter User Manual for Moderno Kids Porsche Style Ride-On Toy Cars

upbright D.C.12V Moderno Kids Porsche Style

UpBright 12V DC Adapter User Manual

Model: D.C.12V Moderno Kids Porsche Style

Your professional power adapter provider

PRODUCT OVERVIEW

This UpBright 12V DC Adapter is designed to provide reliable power for various D.C.12V ride-on toy cars, including Moderno Kids Porsche Style models. It functions as a power supply cord and battery charger, ensuring your child's ride-on toy is ready for use.



Image: UpBright 12V DC Adapter, featuring its barrel tip connector, designed for compatibility with various 12V ride-on toy cars.

The adapter is specifically designed with a barrel round plug tip and **is not** a 2-prong connector. Please verify compatibility with your specific ride-on toy car model before use.

SETUP INSTRUCTIONS

1. **Verify Compatibility:** Ensure your ride-on toy car requires a 12V DC power supply with a barrel round plug tip. This adapter is compatible with models such as:
 - D.C.12V LED Edition Convertible Porsche Style 12 Volt Kids Ride on Car SX-158
 - Premium Convertible Porsche Style 12 Volt Ride on Car
 - Sports Cars Kids Luxury Pink Ride On Toys Porsche Boxster Style 12 Volt Power Wheels B014 Moderno

- D.C.12V Porsche Panamera Style Ride On Toy Car
- Kids Ride On RideOn Toy 12 Volt Porsche Boxster Style Battery Powered Wheels
- Porsche Style Kids Ride On Car 12 Volt Battery Power LED Wheels MKSX158
- Tonka Dump Truck & Spiderman Dune Buggy Surge SUV Ride On Toy
- D.C.12V Moderno Electric Kids Ride On Toy Car 12 Volt Battery Power Wheels MKSX158
- Porsche Boxster Style 12 Volt Battery Power Kids Ride-On Car Passian Speed
- Dynacraft Spider-Man Dune Buggy 12 Volt Powered Ride On Model 20654915 8802-12

2. **Connect to Toy Car:** Insert the barrel plug tip of the adapter firmly into the DC input port of your ride-on toy car.
3. **Connect to Power Source:** Plug the other end of the adapter (car lighter plug) into a 12V DC auto vehicle, boat, RV, or camper lighter socket.
4. **Initiate Charging:** Once connected, the adapter will begin supplying power to the toy car's battery.

OPERATING INSTRUCTIONS

The UpBright 12V DC Adapter is designed for straightforward operation. Once properly connected to a 12V DC power source and the compatible ride-on toy car, it will automatically begin to charge the toy's battery or provide direct power if the toy is designed to operate while plugged in.

- Ensure the power source is active and providing 12V DC.
- Monitor the toy car's charging indicator (if available) to determine charging status.
- Disconnect the adapter from both the power source and the toy car once charging is complete or when the toy is not in use.

MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your UpBright 12V DC Adapter.

- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cleaning:** Use a soft, dry cloth to clean the adapter. Do not use liquid cleaners or solvents.
- **Handling:** Avoid bending or crimping the power cord excessively. Do not pull the cord to disconnect the adapter; always grasp the plug itself.
- **Inspection:** Periodically inspect the adapter and cord for any signs of damage, such as frayed wires or cracked casing. Discontinue use if damage is found.

TROUBLESHOOTING

If you encounter issues with your UpBright 12V DC Adapter, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Adapter not providing power/charging	◦ Loose connection ◦ Incompatible toy car model ◦ Faulty power source (e.g., car lighter socket) ◦ Damaged adapter	◦ Ensure all connections are secure. ◦ Double-check the toy car's voltage and connector type requirements against the adapter's specifications. ◦ Test the power source with another device if possible. ◦ Inspect the adapter for visible damage. If damaged, discontinue use and replace.
Adapter gets excessively hot	◦ Overload (toy drawing too much current) ◦ Poor ventilation ◦ Internal fault	◦ Ensure the toy car's current draw does not exceed the adapter's 0.5A rating. ◦ Ensure the adapter is in a well-ventilated area. ◦ If overheating persists, discontinue use immediately.

If troubleshooting steps do not resolve the issue, please refer to the Warranty & Support section.

SPECIFICATIONS

Feature	Detail
Brand	UpBright
Model Number	D.C.12V Moderno Kids Porsche Style (Adapter for)
Input Voltage	12 Volts DC (from vehicle lighter socket)
Output Voltage	12 Volts DC
Current Rating	0.5 Amps
Connector Type	Barrel Round Plug Tip (NOT 2-Prong)
Certifications	CECCCRHOS compliant
ASIN	B01HYSGE14

WARRANTY & SUPPORT

UpBright stands behind the quality of its products. This adapter comes with:

- **30-Day Money Back Guarantee:** If you are not satisfied with your purchase, you may return it within 30 days for a full refund.
- **1-Year Service Warranty:** The adapter is covered by a 1-year service warranty from the date of purchase, covering defects in materials and workmanship.

For warranty claims or technical support, please contact UpBright customer service through the retailer where the product was purchased or refer to the contact information provided with your product packaging.

© 2024 UpBright. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.