Hobbywing HWI30203401

Hobbywing Platinum Pro 120A V4 ESC User Manual

Model: HWI30203401

1. Introduction and Overview

The Hobbywing Platinum Pro 120A V4 Electronic Speed Controller (ESC) is a high-performance device designed for 500-550 class helicopters. It provides precise motor control and efficient power delivery, ensuring optimal performance for your aircraft. This manual provides essential information for the proper installation, operation, and maintenance of your ESC.

Key features include a robust 120A continuous current rating, support for 3-6S LiPo input, and a powerful switch-mode BEC adjustable from 5V-8V with 10A/25A continuous/peak output. The ESC also incorporates DEO (Driving Efficiency Optimization) technology for improved efficiency and performance, and it is programmable via a transmitter or an LED program card.

2. Safety Precautions

Always observe the following safety guidelines to prevent injury or damage to the ESC and other components:

- **Read the entire manual:** Familiarize yourself with all instructions before operation.
- **Proper Voltage:** Ensure the input voltage from your battery matches the ESC's specifications (3-6S LiPo). Incorrect voltage can cause severe damage.
- **Polarity:** Always connect the battery with correct polarity. Reverse polarity will instantly damage the ESC.
- **Insulation:** Insulate all exposed wires and connectors to prevent short circuits.
- **Heat:** The ESC can become hot during operation. Allow it to cool before handling. Ensure adequate airflow for cooling during use.
- **Water and Moisture:** Keep the ESC away from water, moisture, and conductive contaminants.
- **Children:** This product is not a toy. Keep out of reach of children. Recommended age for use is 16 years and above.
- **Disposal:** Dispose of electronic components responsibly according to local regulations.

3. Package Contents

Upon opening the package, verify that all components are present and in good condition:

- Hobbywing Platinum Pro 120A V4 ESC
- Cooling Fan (if included with specific model variant)
- Capacitor Module
- Heat Shrink Tubing (various sizes)
- Mounting Screws
- User Manual (this document)




Figure 3.1: The image displays the Hobbywing Platinum Pro 120A V4 ESC, which is a black rectangular unit with cooling fins and "PLATINUM 120A" printed on it. Attached are thick red and black input wires (12AWG) and three black output wires (12AWG) with gold connectors. Also visible are a separate capacitor module, a small black cooling fan, and various pieces of heat shrink tubing and mounting screws. This illustrates the complete package contents.

4. Setup and Installation

Follow these steps for proper installation of the ESC in your aircraft:

1. **Mounting the ESC:** Securely mount the ESC in a location with good airflow to ensure efficient cooling. Use the provided mounting screws or double-sided tape.
2. **Motor Connection:** Connect the three output wires from the ESC to the three phase wires of your brushless motor. The order of connection may affect motor rotation direction; this can be adjusted later if needed.
3. **Battery Connection:** Connect the thick red and black input wires of the ESC to your LiPo battery pack. Ensure correct polarity (red to positive, black to negative). It is recommended to use high-quality connectors capable of handling the required current.
4. **Receiver Connection:** Plug the throttle signal wire (usually white or orange) from the ESC into the throttle channel of your receiver. The BEC output wires (red and black/brown) provide power to the receiver and servos.

5. **Capacitor Module:** If a separate capacitor module is included, connect it to the designated port on the ESC as per the diagram in the full product manual (if available). This helps stabilize voltage.
6. **Cooling Fan:** If using the optional cooling fan, connect it to the fan port on the ESC. Ensure the fan is oriented to draw air across the ESC's heatsink.
7. **Initial Calibration:** Perform throttle range calibration with your transmitter to ensure the ESC recognizes the full throttle range. Refer to the detailed programming guide for specific steps.

5. Operating Instructions

Once installed and calibrated, the ESC is ready for operation. Always perform a pre-flight check before each use.

- **Power On:** Connect the battery to the ESC. The ESC will emit a series of beeps indicating cell count and readiness.
- **Arming:** Ensure the throttle stick on your transmitter is at the lowest position. The ESC will arm, indicated by a specific tone or LED status.
- **Throttle Control:** Gradually increase the throttle to control motor speed. The Platinum Pro ESC features DEO (Driving Efficiency Optimization) technology, which enhances throttle linearity and overall efficiency, providing a smoother and more responsive flight experience.
- **Governor Mode:** For helicopter applications, the ESC supports a highly effective governor mode to maintain constant rotor RPM under varying loads. This can be configured through the programming options.
- **Power Off:** Always disconnect the battery from the ESC after use. Do not rely solely on the transmitter to turn off the system.

6. Maintenance

Proper maintenance extends the lifespan of your ESC and ensures reliable performance:

- **Cleaning:** Regularly inspect the ESC for dirt, dust, or debris. Use a soft brush or compressed air to gently clean the heatsink and fan (if applicable). Avoid using liquids.
- **Connections:** Periodically check all wire connections for looseness or corrosion. Ensure connectors are securely seated.
- **Wire Inspection:** Inspect wires for any signs of fraying, cuts, or damage to the insulation. Replace damaged wires immediately.
- **Storage:** Store the ESC in a cool, dry place away from direct sunlight and extreme temperatures.
- **Firmware Updates:** Check the Hobbywing official website for any available firmware updates for your ESC model. Updates can improve performance and add new features.

7. Troubleshooting

If you encounter issues with your ESC, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
ESC does not power on.	Battery not connected, incorrect polarity, damaged battery, faulty connection.	Check battery connection and polarity. Test battery voltage. Inspect all wires and connectors.

Problem	Possible Cause	Solution
Motor does not spin or stutters.	Incorrect motor wiring, throttle range not calibrated, motor or ESC damaged, low battery voltage.	Verify motor wire connections. Recalibrate throttle range. Check battery charge. Inspect motor and ESC for physical damage.
ESC overheats.	Insufficient cooling, excessive load, incorrect timing settings, damaged motor.	Ensure adequate airflow. Reduce load. Check motor timing settings. Inspect motor for issues.
BEC output issues (receiver/servos not powered).	BEC overload, faulty BEC, incorrect wiring to receiver.	Reduce servo load. Check BEC output wires for damage. Ensure correct connection to receiver.

If the problem persists after attempting these solutions, contact Hobbywing customer support or a qualified technician.

8. Specifications

Detailed technical specifications for the Hobbywing Platinum Pro 120A V4 ESC:

Feature	Specification
Model	Platinum 120A V4 (SKU 30203401)
Application	500-550 Class Helicopter
Input Voltage	3-6S LiPo
Continuous/Peak Current (10s)	120A/150A
BEC Output (Switch-mode)	5V-8V Adjustable (0.1V step), 10A/25A Cont./Peak
Separate Programming Port	Yes (for LCD Program Box/WIFI Express)
Input Wires	Red-12AWG-150mm*1 / Black-12AWG-150mm*1
Output Wires	Black-12AWG-100mm*3
Output Connector	4.0mm Gold Connectors (Female)
Dimensions (LxWxH)	84.3 x 38.2 x 20.4 mm (3.32 x 1.50 x 0.80 inches)
Weight	107g / 3.77oz

9. Warranty and Support

Hobbywing products are manufactured to high standards and undergo rigorous quality control. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Hobbywing website. Keep your proof of purchase for warranty claims.

For technical support, troubleshooting assistance beyond this manual, or inquiries about parts and service, please contact Hobbywing customer support directly through their official website or authorized distributors. Provide your product model

number (HWI30203401) and a detailed description of the issue when seeking support.

Hobbywing Official Website: www.hobbywing.com

© 2024 Hobbywing Technology. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question