

[Manuals.plus](#) /

› [KWANWA](#) /

› KWANWA Digital Alarm Clock KW618W User Manual

KWANWA KW618W

KWANWA Digital Alarm Clock KW618W User Manual

Model: KW618W | Brand: KWANWA

1. INTRODUCTION

Thank you for choosing the KWANWA Digital Alarm Clock. This battery-operated clock features a large 1.2-inch LED display, auto night-mode, three-level LED brightness adjustment, and a convenient snooze function. Designed for simplicity and readability, it is suitable for various settings including bedrooms, offices, and travel. Please read this manual carefully to ensure proper setup and operation.



Front view of the KWANWA Digital Alarm Clock with a red LED display, showing the time 10:30.

2. PRODUCT OVERVIEW

The KWANWA Digital Alarm Clock is designed for ease of use and clear visibility. Its compact size allows for versatile placement, either on a tabletop or wall-mounted.



Battery Powered



Daily Alarm



12 / 24 Hour Mode



Snooze Function



Wall Mount




Adjustable LED Brightness

KWANWA Digital Alarm Clock with dimensions: 5.12 inches wide, 2.56 inches high, and 1.5 inches deep.

Key Components:

- **LED Display:** Large 1.2-inch digits for clear time viewing.
- **Snooze/AL Stop Button:** Located on top for easy access.
- **Control Buttons (Rear):** Time Set, AL Set, Hour (12/24), Min (AL ON/OFF), Reset.
- **Dimmer Switch:** High (H), Medium (M), Low (L) settings.
- **Battery Compartment:** Holds 4 x AA batteries (not included).
- **Wall Mount Hole:** For optional wall installation.

EASY TO OPERATE SIMPLE CLOCK



Detailed view of the KWANWA Digital Alarm Clock's back panel, highlighting control buttons for time setting, alarm setting, 12/24 hour mode, and brightness adjustment.

3. SETUP

3.1 Battery Installation

1. Open the battery compartment cover on the back of the clock.
2. Insert 4 new AA alkaline batteries (not included), ensuring correct polarity (+/-).
3. Close the battery compartment cover securely.

The clock is designed to operate for over 12 months on a single set of batteries with constant display.

BATTERY OPERATED EXTREMELY EASY ALARM CLOCK.

4 AA battery not included



Rear view of the KWANWA Digital Alarm Clock with the battery compartment open, showing space for four AA batteries.

3.2 Initial Time Setting

1. Press the "TIME SET" button. The time digits will flash.
2. Press "HOUR" to adjust the hour.
3. Press "MIN" to adjust the minutes.
4. Press "TIME SET" again to save the time. If no button is pressed for 30 seconds, the setting will save automatically.

4. OPERATING INSTRUCTIONS

4.1 Setting the Alarm

1. Press the "AL SET" button. The alarm time digits will flash.
2. Press "HOUR" to adjust the alarm hour.
3. Press "MIN" to adjust the alarm minutes.

4. Press "AL SET" again to save the alarm time.

4.2 Activating/Deactivating the Alarm

- To activate the alarm, press the "AL ON/OFF" button. An alarm icon will appear on the display.
- To deactivate the alarm, press the "AL ON/OFF" button again. The alarm icon will disappear.

4.3 Snooze Function

- When the alarm sounds, press the large "SNOOZE AL STOP" button on top of the clock to activate snooze. The alarm will pause for 7 minutes.
- You can repeat the snooze function up to 3 times.
- To stop the alarm for the day, press any other button on the back of the clock. The alarm will still sound the next day at the set time.



With alarm going, touch the SNOOZE for 7 minutes



The snooze can be repeated 3 times


KWANWA Digital Alarm Clock demonstrating the snooze function, showing the time before and after a 7-minute snooze.

4.4 12/24 Hour Mode

- Press the "HOUR 12/24" button to switch between 12-hour and 24-hour time formats.

4.5 Adjusting Display Brightness

- Use the "DIM" slider switch on the back of the clock to select High (H), Medium (M), or Low (L) brightness for the LED display.



KWANWA Digital Alarm Clock displaying three brightness levels: High, Medium, and Dim.

4.6 Auto Night-Mode

- The clock automatically dims the display between 8:00 PM and 6:00 AM to conserve battery life and reduce light disturbance during sleep.

5. VERSATILE PLACEMENT

The KWANWA Digital Alarm Clock is designed for flexible placement options:

- **Tabletop:** Its compact design makes it ideal for bedside tables, desks, or shelves.
- **Wall Mount:** A keyhole slot on the back allows for easy wall mounting.



Various usage scenarios for the KWANWA Digital Alarm Clock, including a desk, kitchen, bathroom, tool house, office, office, travel, and living room.

6. MAINTENANCE

6.1 Battery Replacement

- Replace all four AA batteries when the display starts to dim significantly or the clock stops functioning.
- Always use new AA alkaline batteries for optimal performance and battery life.

6.2 Cleaning

- Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.

7. TROUBLESHOOTING

- **Display is dim or blank:** Check battery installation and replace with new batteries if necessary. Ensure the dimmer switch is not set to 'Low' in bright conditions.
- **Alarm does not sound:** Verify that the alarm is activated (alarm icon visible) and the alarm time is set correctly.
- **Incorrect time display:** Reset the time using the "TIME SET" and "HOUR"/"MIN" buttons. If the time accuracy is consistently off, consider replacing batteries.
- **Clock is unresponsive:** Press the "RESET" button on the back of the clock using a pointed object (e.g., a paperclip). This will reset all settings.

8. SPECIFICATIONS

Brand	KWANWA
Model Number	KW618W
Color	White Case-red Led
Display Type	Digital
Power Source	Battery Powered (4 x AA batteries required, not included)
Product Dimensions	5.12"W x 2.56"H
Special Features	Adjustable Brightness, Alarm, Auto Dimmable, Cordless, Night Mode, Large Display, Snooze, 12/24Hr, Portable Size, Wall Mount
Material	Plastic

9. OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Watch a demonstration of the KWANWA Battery Operated Digital Desktop Clock, highlighting its features and ease of use.

10. WARRANTY AND SUPPORT

This product comes with a limited warranty. For customer service or support, please contact KWANWA at kwanwa@shenzhenkwanwa.com.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question