

[Manuals.plus](#) /

› [Mr.Go](#) /

› Mr.Go 12-inch LED Garden Sphere Lamp User Manual

Mr.Go CQ-B30

Mr.Go 12-inch LED Garden Sphere Lamp User Manual

Model: CQ-B30

Brand: Mr.Go

1. INTRODUCTION

Thank you for choosing the Mr.Go 12-inch LED Garden Sphere Lamp. This versatile and durable LED light is designed to enhance any indoor or outdoor space with its vibrant RGB colors and multiple lighting modes. Its robust, waterproof construction and rechargeable battery make it ideal for gardens, patios, poolsides, and home decor. This manual provides essential information for the safe and effective use of your new lamp.



Image: The Mr.Go 12-inch LED Garden Sphere Lamp illuminated in purple, with its remote control visible in the foreground.

2. PACKAGE CONTENTS

Please check the package contents carefully. If any items are missing or damaged, contact customer support.

- 1 x Mr.Go LED Sphere Lamp
- 1 x Remote Control
- 1 x User Manual
- 1 x USB Charging Cable with UK Adapter

3. FEATURES

The Mr.Go LED Garden Sphere Lamp offers a range of features for versatile lighting:

- **Durable Construction:** Made from robust PE plastic, capable of supporting approximately 100 kg, making it safe to sit on.
- **Safe LED Technology:** Utilizes heat-free LEDs, ensuring the lamp remains cool to the touch and safe for children.
- **Vibrant Lighting Options:** Features 16 flexible RGB colors and 4 dynamic lighting modes (Flash, Strobe, Fade,

Smooth) to create various ambiances.

- **IP65 Waterproof Rating:** Designed to withstand rain and snow, making it suitable for outdoor use in gardens, patios, decks, or by pools/ponds.
- **Wireless Remote Control:** A 24-key remote allows for easy adjustment of colors, modes, and brightness from a distance.
- **Rechargeable Battery:** Built-in 1000mAh Li-ion battery provides 8 to 48 hours of continuous light depending on brightness settings, offering portability.
- **Memory Function:** The lamp remembers your last used settings, eliminating the need to reconfigure it each time.
- **Easy Maintenance:** Simple to clean; can be wiped down or rinsed under running water.



Image: Visual representation of the 16 static colors, 4 lighting modes, and 8 brightness settings available with the Mr.Go LED lamp.



ON/OFF/Brightness

- Brightness +
- Brightness -
- Turn on the light
- Turn off the light

16 Colors



4 Light Modes

- FLASH** Colors keep changing automatically
- STROBE** Colors flash like disco light
- FADE** Light colors fade in and out
- SMOOTH** Colors changes in slow-motion

Image: Detailed view of the 24-key remote control, illustrating buttons for power, brightness adjustment, color selection, and mode changes.

4. SETUP

Follow these steps to set up your Mr.Go LED Sphere Lamp:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Charge:** Before first use, fully charge the lamp. Connect the USB charging cable to the lamp's charging port and plug the adapter into a power outlet. The charging indicator (if present) will show charging status. A full charge typically takes 1.5 to 2 hours.
3. **Placement:** Place the lamp in your desired location. Ensure the charging port cover is securely closed if using outdoors to maintain its IP65 waterproof rating.



Rechargeable

Built-in 1000mAh rechargeable Li-on battery
Universal DC5V 1A charging
can work with /without plugging in the adapter



Image: Illustration of the lamp being charged via USB, along with estimated continuous light durations for brightest (7 hours), middle (24+ hours), and weakest (48+ hours) brightness levels.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press the 'ON' button on the remote control to turn the lamp on. Press the 'OFF' button to turn it off. Alternatively, a button on the bottom of the lamp can cycle through settings and power on/off.

5.2 Using the Remote Control

The 24-key remote control provides full functionality:

- **Brightness +/-:** Adjust the light intensity.
- **Color Selection:** Choose from 16 static RGB colors.
- **Light Modes:** Select from 4 dynamic modes:

- *Flash*: Colors change rapidly.
- *Strobe*: Colors flash like a disco light.
- *Fade*: Light colors fade in and out smoothly.
- *Smooth*: Colors change in slow-motion.

5.3 Charging

When the battery is low, connect the lamp to the power adapter using the provided USB cable. The lamp can be used while charging, or unplugged for portable use. Ensure the DC cover is securely sealed after charging, especially for outdoor use.



Image: Two Mr.Go LED sphere lamps providing ambient lighting along a garden path at night.



Image: A family gathered outdoors at night, illuminated by several Mr.Go LED sphere lamps and a cube lamp, creating a cozy atmosphere.

6. MAINTENANCE

Proper maintenance ensures the longevity of your Mr.Go LED Sphere Lamp:

- **Cleaning:** The lamp is easy to clean. Simply wipe it with a damp cloth or rinse it under running water. Avoid using harsh chemicals or abrasive materials.
- **Battery Care:** If storing the lamp for an extended period, recharge the battery at least once a month to prolong its lifespan.
- **Water Protection:** Always ensure the DC charging port cover is securely sealed after charging to prevent water infiltration, especially when used outdoors.



Image: Visual demonstration of the lamp's durability, highlighting its anti-oxidant properties, weatherproof design (shown in snow), and IP65 waterproof rating (shown in rain).

7. TROUBLESHOOTING

Refer to the table below for common issues and their solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	Battery is depleted.	Charge the lamp fully.
	Remote control battery is dead or remote is too far.	Replace remote battery or move closer to the lamp. Use the button on the lamp's base.

Problem	Possible Cause	Solution
Remote control not responding.	Remote battery is low or dead.	Replace the remote control battery.
	Obstruction between remote and lamp.	Ensure a clear line of sight between the remote and the lamp.
Short battery life.	Lamp is used on brightest setting or dynamic modes.	Reduce brightness or use static, dimmer colors for longer battery life.
	Battery not fully charged or old.	Ensure full charge. If battery life significantly degrades over time, it may need replacement (contact support).
Water inside the lamp.	Charging port cover not sealed properly.	Immediately turn off and dry the lamp. Ensure the charging port cover is always securely closed when not charging, especially for outdoor use.

8. SPECIFICATIONS

Detailed specifications for the Mr.Go LED Garden Sphere Lamp:

Specification	Detail
Brand	Mr.Go
Model Number	CQ-B30
Dimensions (L x W x H)	30 x 30 x 29 cm (approx. 12 inches diameter)
Weight	1.2 Kilograms
Material	Polyethylene (PE)
Light Source Type	LED
Color Output	16 RGB Colors
Special Features	Color Changing, Dimmable, Frosted Finish, Rechargeable
IP Rating	IP65 (Waterproof)
Battery Type	1 Lithium-ion (included)
Power Source	Battery Powered
Voltage	240 Volts

9. WARRANTY AND SUPPORT

Mr.Go products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the documentation provided with your purchase or visit the official Mr.Go website.

If you encounter any issues not covered in this manual or require further assistance, please contact Mr.Go customer support through the retailer where you purchased the product or via the contact information available on the official Mr.Go website.

brand channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question