

## Lavazza 18000153

# Lavazza A Modo Mio Jolie Coffee Machine Instruction Manual

Model: 18000153

## INTRODUCTION

This manual provides essential information for the safe and efficient use of your Lavazza A Modo Mio Jolie coffee machine. Please read these instructions carefully before first use and keep them for future reference. The Lavazza A Modo Mio Jolie is a compact espresso machine designed for use with Lavazza A Modo Mio capsules, offering a convenient way to prepare quality coffee.



Image: The Lavazza A Modo Mio Jolie coffee machine in red and black, with a cup of espresso being brewed.

## IMPORTANT SAFETY INSTRUCTIONS

- Always use only Lavazza A Modo Mio capsules with this machine. Using other capsule types may damage the machine and void the warranty.

- Fill the water tank exclusively with cold, fresh drinking water. Never use milk, other liquids, or hot water in the water tank.
- Ensure the machine is placed on a stable, flat surface away from heat sources and water.
- Do not immerse the machine, power cord, or plug in water or any other liquid.
- Unplug the machine from the power outlet before cleaning and when not in use for extended periods.
- Keep the appliance out of reach of children.

## GETTING STARTED (SETUP)

---

### 1. Unpacking

Carefully remove the coffee machine and all accessories from the packaging. Retain the packaging for future transport or storage. Check for any damage to the machine or its components.

### 2. Initial Cleaning

Before first use, wash the water tank, drip tray, and used capsule container with warm water and a mild detergent. Rinse thoroughly and dry all parts.

### 3. Filling the Water Tank

Remove the water tank from the back of the machine. Fill it with fresh, cold drinking water up to the 'MAX' level indicator. Reinsert the water tank firmly into its position.



Image: A close-up view of the transparent water tank, showing it filled with water and ready for use.

### 4. First Use / Priming

1. Ensure the water tank is filled and the machine is plugged into a suitable power outlet.
2. Place an empty cup on the drip tray.
3. Press the ON/OFF button. The button will flash while heating up and become steady when ready (approximately 35 seconds).
4. Without inserting a capsule, lift the lever, then close it. Press the coffee dispensing button. Water will flow into the cup. Let it run until the tank is almost empty.

5. Repeat this process once or twice to thoroughly rinse the internal circuits.

## OPERATION

---

### 1. Turning On the Machine

Plug the machine into a power outlet. Press the ON/OFF button located on the top of the machine. The button will illuminate and flash during the heating phase. Once the button glows steadily, the machine is ready for use.



Image: A close-up of the red power button on the top of the machine, indicating its location.

### 2. Inserting a Capsule

Lift the lever on the front of the machine. Insert one Lavazza A Modo Mio capsule into the capsule compartment. Close the lever firmly until it clicks into place.

### 3. Brewing Coffee

Place a cup on the drip tray. Press the coffee dispensing button. The machine will start brewing. The brewing process will continue until you press the button again to stop it, allowing you to customize the coffee volume.

### 4. Adjusting Coffee Volume

The Lavazza Jolie allows for manual control of coffee volume. Press the coffee dispensing button to start brewing, and press it again to stop when your desired volume is reached. This feature is useful for preparing different coffee styles like espresso or lungo.

### 5. Turning Off the Machine

Press the ON/OFF button to turn off the machine. It is recommended to turn off the machine after each use to save energy.

## MAINTENANCE

---

### 1. Daily Cleaning

After each use, empty and clean the drip tray and the used capsule container. Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.

### 2. Emptying the Used Capsule Container

The used capsule container can hold up to 5 capsules. When full, remove the drip tray and then slide out the capsule container. Dispose of the used capsules and wash the container with warm water and mild detergent.

### 3. Descaling

Over time, mineral deposits can build up inside the machine, affecting performance. Descale your machine

regularly (e.g., every 3-6 months, depending on water hardness). Use a descaling solution specifically designed for coffee machines and follow the product's instructions. Always rinse the machine thoroughly with several cycles of fresh water after descaling.

## TROUBLESHOOTING

- **No coffee dispensed:** Check if the water tank is filled, if a capsule is correctly inserted, and if the machine is heated up (steady light).
- **Water leaking:** Ensure the water tank is properly seated and not overfilled. Check for any cracks in the tank.
- **Coffee is cold:** Allow the machine sufficient time to heat up. Ensure the ON/OFF button light is steady.
- **Machine not turning on:** Verify the power cord is securely plugged into both the machine and the wall outlet. Check the power supply.
- **Coffee flow is slow or blocked:** This may indicate a need for descaling. Perform a descaling cycle as per the instructions.

If problems persist after attempting these solutions, please contact customer support.

## PRODUCT SPECIFICATIONS

Brand	Lavazza
Model Number	18000153
Power	1200 Watts
Voltage	240 Volts
Pressure	10 bar
Water Tank Capacity	0.6 Liters
Dimensions (L x W x H)	12.4 x 21 x 33 cm
Weight	2.6 Kilograms
Material	Acrylonitrile Butadiene Styrene
Capsule Compatibility	Lavazza A Modo Mio capsules only
Special Feature	Removable Water Tank

## WARRANTY INFORMATION

Your Lavazza A Modo Mio Jolie coffee machine is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration. Keep your proof of purchase for any warranty claims.

## CUSTOMER SUPPORT

For further assistance, technical support, or warranty inquiries, please contact Lavazza customer service. You can find additional resources and contact information on the official Lavazza website.



Image: Lavazza customer support logo with the text "È SEMPRE CON TE!" (Always with you!) and a phone number: 011 3020300.

**Telephone:** 011 3020300

Please have your machine's model number (18000153) and purchase details ready when contacting support.