

Dyson 214895-01

Dyson Cinetic Big Ball Animal Canister Vacuum User Manual

Model: 214895-01

INTRODUCTION

This manual provides essential information for the safe and efficient operation and maintenance of your Dyson Cinetic Big Ball Animal Canister Vacuum. Please read thoroughly before first use.

The Dyson Cinetic Big Ball Animal Canister Vacuum is engineered to capture microscopic dust without losing suction. Its unique design eliminates the need for filter washing or replacement, offering a hygienic and convenient cleaning experience.

PRODUCT FEATURES

- **Dyson Cinetic Tips:** 36 Cinetic tips separate microscopic dust, preventing clogging.
- **No Filter Washing/Replacement:** Efficient dust separation means no filters to wash or replace.
- **Self-Rights When Topples:** Designed to pick itself up if it falls over.
- **Hygienic Dirt Ejector:** Expels trapped dust and debris with a single action, avoiding contact.
- **Carbon Fiber Turbine Head:** Combines carbon fiber filaments for fine dust and stiff nylon bristles for ground-in dirt.
- **Ball Technology:** Core components housed within the ball for easy maneuverability.

SETUP

Before operating your Dyson Cinetic Big Ball Animal Canister Vacuum, ensure all components are correctly assembled.

1. Unpacking:

Carefully remove all parts from the packaging. Retain packaging for future storage or transport.





Image: The main Dyson Cinetic Big Ball Animal Canister Vacuum unit, showing the ball-shaped body, clear dustbin, and the hose and wand assembly.

2. **Attaching the Wand and Hose:**

Connect the flexible hose to the main unit's intake port. Then, attach the cleaning head to the end of the wand, and the wand to the hose handle. Ensure all connections click securely into place.



Image: A woman operating the Dyson Cinetic Big Ball Animal Canister Vacuum on a carpeted floor, demonstrating the connected hose, wand, and cleaning head.

3. **Power Connection:**

Extend the power cord from the main unit and plug it into a suitable electrical outlet.

OPERATING INSTRUCTIONS

Your Dyson vacuum is designed for versatile cleaning across various surfaces.

1. **Power On/Off:**

Press the red power button located on the main unit to turn the vacuum on or off.

2. **Floor Type Selection:**

The Carbon Fiber Turbine Head is suitable for both hard floors and carpets. The self-adjusting cleaning head automatically adapts to different floor types.



Image: Close-up of the Carbon Fiber Turbine Head with its bristles visible, positioned on a carpet, illustrating its design for various surfaces.

3. **Maneuverability:**

The Ball Technology allows the main unit to pivot smoothly, following your movements without awkward maneuvers. If the unit topples, it will self-right automatically.



Image: A sequence showing the Dyson Cinetic Big Ball unit tilting and then automatically righting itself, highlighting its stability feature.

4. Using Attachments:

- **Combination Tool:** For general cleaning, converts from a wide nozzle to a brush tool.
- **Stair Tool:** Designed for effective cleaning of stairs and upholstery.
- **Tangle-Free Turbine Tool:** Ideal for removing hair from carpets and upholstery without tangling.
- **Stiff Bristle Brush:** For dislodging stubborn dirt from coarse carpets and high-traffic areas.



Image: The Tangle-Free Turbine Tool being used to clean pet hair from upholstery, showcasing its effectiveness on fabric surfaces.

MAINTENANCE

Regular maintenance ensures optimal performance of your Dyson vacuum.

1. Emptying the Dustbin:

The hygienic dirt ejector allows for quick and clean emptying. Simply press the red button to release the dirt into a trash receptacle without touching it.



Image: A diagram illustrating the hygienic dirt ejector mechanism, showing how trapped dust and debris are pushed out of the clear bin.

2. **Filter Maintenance:**

Your Dyson Cinetic Big Ball Animal vacuum does not require filter washing or replacement due to its advanced Cinetic cyclone technology.



Image: A cutaway view of the Dyson Cinetic Big Ball showing the internal cyclone array, which captures microscopic dust without needing filter maintenance.

SPECIFICATIONS

Feature	Detail
Brand	Dyson
Model Name	Cinetic Big Ball Animal
Model Number	214895-01
Capacity (volume)	0.42 Gallons
Item Weight	17.64 pounds
Product Dimensions	12.1 x 15.7 x 13.7 inches
Noise Level	78 Decibels

Surface Recommendation	Carpet, Hardwood, Bare Floor, Linoleum, All floors
Included Components	Dyson Cinetic Big Ball Canister, Combination tool, Stair tool, Tangle Free Turbine Tool, Stiff bristle Brush

TROUBLESHOOTING

For common issues, please refer to the official Dyson support website or contact customer service. Ensure the dustbin is empty and all connections are secure before troubleshooting.

WARRANTY AND SUPPORT

Your Dyson Cinetic Big Ball Animal Canister Vacuum comes with a**5-year warranty** covering parts and labor. For warranty claims, technical support, or to purchase genuine Dyson parts and accessories, please visit the official Dyson website or contact their customer service.
Official Dyson Store: [Visit the Dyson Store](#)

OFFICIAL PRODUCT VIDEOS

Dyson Cinetic Big Ball Animal Canister Demo

Your browser does not support the video tag.

Video: A detailed demonstration of the Dyson Cinetic Big Ball Animal Canister Vacuum, showcasing its features and operation. This video is provided by Performance Reviews, a seller-type creator.

Dyson Cinetic Big Ball Canister Vacuum (Preview)

Your browser does not support the video tag.

Video: A short preview video highlighting key aspects of the Dyson Cinetic Big Ball Canister Vacuum. This video is provided by Merchant Video, a seller-type creator.