

Invicta 22525

Invicta Men's Gold-Tone Watch Model 22525 Instruction Manual

INTRODUCTION

This manual provides essential information for the proper use, care, and maintenance of your Invicta Men's Gold-Tone Watch, Model 22525. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece. Keep this manual for future reference.

PRODUCT OVERVIEW

The Invicta Model 22525 is a men's chronograph watch featuring a gold-tone stainless steel case, a blue dial, and a blue silicone band. It is powered by a Japanese quartz movement and includes multiple functional subdials.

Key Features:

- **Case:** Gold-tone stainless steel, 49mm diameter x 11mm thick.
- **Dial:** Blue with luminous hands for visibility in low light.
- **Movement:** Japanese quartz movement, VK63A Caliber, ensuring accurate timekeeping.
- **Battery:** SR936SW battery included.
- **Band:** Blue silicone band, 210mm length x 26mm width, with a buckle clasp.
- **Crystal:** Flame Fusion crystal, designed for extra scratch resistance and durability.
- **Crown:** Push/pull crown for time and date adjustments.
- **Bezel:** Uni-directional stainless steel bezel with a blue top ring for tracking elapsed time.
- **Subdials:** Functional 60-minute, 60-second, and 24-hour subdials for chronograph functions.
- **Water Resistance:** 100 meters (330 feet), suitable for recreational surfing, swimming, snorkeling, sailing, and water sports. Not suitable for diving.

Product Visuals:



Front view of the Invicta Model 22525 watch, showcasing the gold-tone case, blue dial, and blue silicone band.



Side view of the watch, highlighting the push/pull crown and chronograph pushers.



Rear view of the watch, displaying the stainless steel case back and the blue silicone strap with buckle.



The Invicta Model 22525 watch as it appears on a wrist, demonstrating its size and fit.



An illustration detailing the watch's crown, unidirectional rotating bezel, 49mm case size, and Flame Fusion crystal.



An illustration highlighting the buckle clasp for easy adjustment and the premium silicone band for comfort.



An illustration explaining the quartz chronograph movement, precise timekeeping, and visible date display.

SETUP INSTRUCTIONS

Setting Time and Date:

1. **Pull the Crown:** Gently pull the crown (located on the right side of the watch case) out to position 2 for date adjustment, or position 3 for time adjustment.
2. **Adjust Date:** In position 2, rotate the crown clockwise or counter-clockwise to set the desired date.
3. **Adjust Time:** In position 3, rotate the crown to move the hour and minute hands. Ensure the 24-hour subdial (if applicable) is correctly synchronized for AM/PM.
4. **Push the Crown Back:** Once the time and date are set, push the crown back firmly into position 1

(normal operating position) to engage the movement and ensure water resistance.

Battery:

Your watch comes with a pre-installed SR936SW battery. If the watch stops running, it may require a battery replacement. It is recommended to have battery replacement performed by a qualified watch technician to maintain water resistance and prevent damage.

OPERATING INSTRUCTIONS

Using the Chronograph:

The chronograph function allows for precise measurement of elapsed time using the subdials.

1. **Start:** Press the upper pusher (button) to start the chronograph. The 60-second subdial hand will begin to move.
2. **Stop:** Press the upper pusher again to stop the chronograph. The elapsed time will be indicated by the 60-second, 60-minute, and 24-hour subdials.
3. **Reset:** With the chronograph stopped, press the lower pusher to reset all chronograph hands to zero.

Using the Uni-directional Bezel:

The uni-directional rotating bezel can be used to track elapsed time, such as dive times or parking meters.

1. Rotate the bezel so that the zero marker aligns with the minute hand at the start of an event.
2. As time passes, the minute hand will indicate the elapsed time against the bezel's scale.

MAINTENANCE

Cleaning:

- Regularly wipe your watch with a soft, dry cloth to remove dust and dirt.
- For the silicone band, you can use a mild soap and water solution, then rinse thoroughly and dry completely.
- Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish or crystal.

Water Resistance Care:

- Always ensure the crown is fully pushed in before exposing the watch to water.
- Do not operate the crown or pushers while the watch is wet or submerged.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.

Storage:

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and extreme temperatures. The original watch box is ideal for storage.

TROUBLESHOOTING

- **Watch Not Running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Incorrect Time/Date:** Refer to the "Setting Time and Date" section to re-adjust.
- **Chronograph Not Resetting to Zero:** This may indicate a need for calibration or service.
- **Condensation Under Crystal:** This suggests a loss of water resistance. Avoid further water exposure and seek professional service immediately.

SPECIFICATIONS

- **Model Number:** 22525
- **Brand Name:** Invicta
- **Display Type:** Analog
- **Watch Movement Type:** Japanese Quartz (VK63A Caliber)
- **Case Material Type:** Stainless Steel (Gold-Tone)
- **Case Diameter:** 49 mm
- **Case Thickness:** 11 mm
- **Crystal:** Flame Fusion (Synthetic Sapphire)
- **Band Material Type:** Silicone
- **Band Color:** Blue
- **Band Width:** 26 mm
- **Band Length:** 210 mm (10.25 Inches)
- **Clasp Type:** Buckle
- **Dial Color:** Blue
- **Water Resistance Depth:** 100 Meters (330 Feet)
- **Power Source:** Battery Powered (1 LR44 battery included)
- **Item Weight:** 0.32 Pounds (approximately 5.12 ounces)
- **Additional Features:** Second Hand, Luminous Hands, Uni-directional Bezel, Chronograph (60min, 60sec, 24hr subdials)

WATER RESISTANCE GUIDELINES

Your Invicta watch Model 22525 is water resistant to 100 meters (330 feet). This rating indicates that the watch is suitable for:

- Splashes and rain
- Showering
- Recreational swimming
- Snorkeling
- Sailing and other water sports

It is NOT suitable for scuba diving or high-impact water activities where water pressure may exceed the rated depth.

MOVEMENT

QUARTZ CHRONOGRAPH

To measure and keep track of different sets of time in addition to the current time on a dial. A true celebration of traditional watchmaking.



TIMEKEEPING

For more precise timekeeping at the simple push of a button



DATE-DISPLAY

Accurately keep track of the date with easily visible date display



Visual guide to water resistance levels, indicating suitability for various water activities up to 100 meters.

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

An official product video showcasing the Invicta Men's Aviator Stainless Steel Quartz Watch with Silicone Strap, Model 22525, demonstrating its design and features.

WARRANTY AND SUPPORT

Your Invicta watch is covered by a manufacturer's warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your purchase or visit the official Invicta website.

For technical support, service, or inquiries not covered in this manual, please contact Invicta customer service through their official channels. Do not attempt to repair the watch yourself, as this may void the warranty and cause further damage.