

[Manuals.plus](#) /

› [Beautyrest](#) /

› Beautyrest Heated Microlight to Sherpa Electric Blanket (Model BR54-0663) Instruction Manual

Beautyrest BR54-0663

Beautyrest Heated Microlight to Sherpa Electric Blanket

Model: BR54-0663

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Beautyrest Heated Microlight to Sherpa Electric Blanket. Please read all instructions carefully before use and retain this manual for future reference.

Your Beautyrest electric blanket features Secure Comfort technology for consistent warmth, virtually zero electromagnetic field emissions, 3 heat settings, and a 2-hour auto shut-off. It is designed for comfort with ultra-soft microlight plush fabric reversing to billowy sherpa, and is machine washable for easy care. The blanket is OEKO-TEX certified, ensuring it is free from harmful substances.



Image: A couple comfortably seated on a couch, sharing the indigo Beautyrest electric blanket, demonstrating its use in a home setting.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of burns, electric shock, fire, or injury, this product must be used in accordance with the following instructions:

- Read all instructions before using this heated blanket.
- Do not use with infants, children, incapacitated persons, paraplegics, quadriplegics, diabetics, persons sensitive to heat, or anyone who cannot clearly understand the instructions and/or operate the controls.
- Do not use on a bed with a water mattress.
- Do not use if the blanket is wet.
- Ensure the controller is not covered or placed under the blanket, pillow, or other items while in use to prevent overheating.
- Keep the cord loose, untwisted, and unpinched to avoid damage.
- Do not lay on top of the blanket to prevent damage to internal coils.

- Do not ball up or fold the blanket while it is turned on.
- Unplug the blanket when not in use.
- Do not use pins or other metallic objects with this blanket.
- Do not use if the power cord or plug is damaged.
- This product is for household use only.



Keep Controller
Uncovered



Keep Blanket
Spread Out Evenly



Keep Cord Loose,
Not Twisted & Pinched

DOS/DON'TS



Don't Lay on
Top of the Blanket to Prevent
Damage to Internal Coils



Don't Ballup Your
Blanket While On



Don't Fold your
Blanket While On

Image: Visual guide illustrating proper usage (keep controller uncovered, blanket spread evenly, cord loose) and improper usage (lying on top, balling up, folding while on) of the electric blanket.

SETUP GUIDE

1. **Unpack:** Carefully remove the electric blanket from its packaging.
2. **Inspect:** Check the blanket and power cord for any signs of damage. Do not use if damaged.
3. **Position:** Lay the blanket flat on your bed or desired surface, ensuring it is spread out evenly without any folds or bunches.

4. **Connect Controller:** Locate the connector on the blanket and the plug on the controller cord. Firmly push the controller plug into the blanket connector until it clicks securely into place. Ensure the connection is tight.
5. **Plug In:** Plug the power cord into a standard 110V-120V AC electrical outlet.



Image: A close-up view of hands connecting the detachable controller cord to the electric blanket, demonstrating the secure plug-in process.

OPERATING INSTRUCTIONS

Your Beautyrest electric blanket features a user-friendly controller with multiple heat settings and an automatic shut-off function.



Image: A detailed view of the electric blanket's controller, showing the "ON/OFF" button and the "HIGH," "MED," and "LO" heat setting indicators.

1. **Power On:** Press the "ON/OFF" button on the controller to turn on the blanket. The indicator light will illuminate.
2. **Adjust Heat Setting:** Use the heat setting button (often labeled with arrows or a toggle) to cycle through the available heat levels:
 - **HIGH:** For rapid heating or maximum warmth.
 - **MED:** For moderate warmth.
 - **LO:** For gentle, continuous warmth.

The corresponding indicator light on the controller will show the selected setting.

3. **Auto Shut-Off:** For safety and energy conservation, the blanket is equipped with a 2-hour auto shut-off feature. The blanket will automatically turn off after approximately two hours of continuous use. To restart, simply press the "ON/OFF" button again.
4. **Power Off:** To turn off the blanket manually, press the "ON/OFF" button. Unplug the blanket from the wall outlet when not in use for extended periods.

Proper care ensures the longevity and performance of your Beautyrest electric blanket. Always follow these instructions carefully.



Image: A visual guide outlining the steps for washing and drying the electric blanket, including hand wash/delicate cycle, cold water, minimal detergent, immediate removal after spin, tumble dry low for 5 minutes, gentle stretch and hang dry, and warnings against using clothespins or ironing.

1. Before Washing:

- Ensure the blanket is unplugged from the wall outlet.
- Detach the controller(s) from the blanket by firmly pulling the connector.

2. Washing Instructions:

- Machine wash on a delicate cycle or hand wash.
- Use cold water and minimal detergent.

- Do not bleach.
- Remove immediately after the spin cycle to prevent creasing.

3. Drying Instructions:

- Tumble dry on medium or low heat for no more than 5 minutes.
- Remove from dryer while still damp.
- Gently stretch the blanket to its original shape and hang to finish drying.
- Do not use clothespins, as they can damage the internal wires.
- Do not iron the blanket.
- Ensure the blanket is completely dry before reconnecting the controller and plugging it in.

4. Storage: When storing, loosely roll or fold the blanket. Avoid tightly folding or placing heavy objects on top, which can damage the internal wiring.

TROUBLESHOOTING

If you experience issues with your electric blanket, please refer to the following common problems and solutions:

Q: Why is my controller light blinking?

A: Unplug the blanket from the wall outlet and then reconnect it, ensuring the controller is properly connected to the blanket. If the issue persists, contact customer support.

Q: Why does my blanket not heat well?

A: Ensure the blanket is powered on and set to the maximum heat level. Allow sufficient time for the blanket to heat up, as it may take a few minutes to reach the desired temperature.

Q: Only parts of my blanket are getting warm.

A: This is often caused by bunched or pinched heating elements. Lay the blanket flat, untucked, and free from heavy objects. Gently straighten the heating wires as needed to restore function. Run your fingers along the wire, paying special attention to the top and bottom of the blanket where the wire bends. If any portion of the wire is twisted on itself, manually twist it back into place.

If these steps do not resolve the issue, please contact customer support.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	BR54-0663
Dimensions	60"L x 70"W
Material	100% Polyester (Microlight Plush to Sherpa)
Heat Settings	3 (High, Medium, Low)
Auto Shut-Off	2 Hours
EMF Emissions	Virtually Zero
Certifications	UL Certified, OEKO-TEX Certified
Power Input	110V-120V @ 60Hz (Max 160W)

Product Weight	4.4 Pounds
Care Instructions	Machine Washable




Image: A simple diagram illustrating the dimensions of the electric blanket, indicating a length of 70 inches and a width of 60 inches.

WARRANTY INFORMATION

This Beautyrest electric blanket is covered by a **5-year limited warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

For detailed warranty terms and conditions, please refer to the official product documentation or contact customer support.

CUSTOMER SUPPORT

If you have any questions, require assistance, or need to make a warranty claim, please contact the manufacturer:

- **Brand:** Beautyrest
- **Manufacturer:** E&E Co. Ltd DBA JLA Home
- **Contact Information:** Please refer to the contact details provided with your product packaging or visit the official Beautyrest website for support.
- **User Guide (PDF):** For additional information, you can download the official user guide [here](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question