



Manuals.plus /

- › Dell /
- › Dell SE2717H KYKMD 27-inch FHD 1080p LED-Lit Monitor User Manual

## Dell KYKMD

# Dell SE2717H KYKMD 27-inch FHD 1080p LED-Lit Monitor User Manual

Model: KYKMD

## 1. INTRODUCTION

---

This manual provides instructions for setting up, operating, and maintaining your Dell SE2717H KYKMD 27-inch Full HD 1080p LED-Lit Monitor. Please read this manual thoroughly before using your monitor to ensure proper operation and to prevent damage.



*Image 1.1: Front view of the Dell SE2717H KYKMD monitor.*

## 2. SAFETY INFORMATION

---

Observe the following safety precautions to ensure optimal performance and prevent damage to your monitor:

- Do not place the monitor on an unstable cart, stand, or table.
- Do not block ventilation openings.
- Do not use near water or in high-humidity environments.
- Use only the power adapter provided by Dell.
- Refer all servicing to qualified service personnel.

## 3. PACKAGE CONTENTS

---

Verify that all components are present in your package:

- Dell SE2717H KYKMD Monitor
- Monitor Stand (Base and Riser)
- Power Cable
- HDMI Cable
- Documentation (Quick Setup Guide, Safety Information)

## 4. SETUP

---

### 4.1 Assembling the Monitor Stand

1. Place the monitor panel face down on a soft cloth or cushion.
2. Attach the stand riser to the base, ensuring it clicks into place.
3. Align the stand assembly with the mounting slots on the back of the monitor panel and press firmly until it locks.



*Image 4.1: Rear view of the monitor with stand attached.*

### 4.2 Connecting the Monitor

Connect the monitor to your computer using the appropriate cables:

- **Power Connection:** Connect the power cable to the monitor's power port and then to a wall outlet.
- **Video Connection (HDMI):** Connect one end of the HDMI cable to the HDMI port on your monitor and the other end to the HDMI port on your computer.
- **Video Connection (VGA):** Alternatively, connect one end of the VGA cable to the VGA port on your monitor and the other end to the VGA port on your computer.

The monitor supports both HDMI and VGA inputs.




Image 4.2: Key features and connectivity options.

## 5. OPERATING THE MONITOR

---

### 5.1 Power On/Off

Press the power button located on the bottom right bezel of the monitor to turn it on or off. The power LED will indicate the monitor's status.

### 5.2 On-Screen Display (OSD) Menu

The OSD menu allows you to adjust various monitor settings. Use the buttons on the bottom right bezel to navigate and select options.

- **Brightness/Contrast:** Adjust the display's luminance and contrast levels.
- **Input Source:** Manually select between HDMI and VGA inputs.
- **Color Settings:** Customize color temperature, gamma, and other color-related options.
- **ComfortView:** Activate this feature to reduce blue light emissions, which can help reduce eye strain during prolonged use.
- **Display Settings:** Adjust aspect ratio, sharpness, and response time.

### 5.3 Key Display Features

- **Flicker-Free Technology:** The monitor uses direct current to control screen brightness, eliminating screen flickering for a more comfortable viewing experience.
- **IPS Panel:** In-Plane Switching (IPS) panel technology provides consistent colors and wide viewing angles, ensuring clear visuals from various positions.
- **75Hz Refresh Rate:** Offers smoother motion compared to standard 60Hz monitors, beneficial for general use and casual gaming.
- **6ms Response Time:** Provides quick pixel transitions, reducing ghosting in fast-moving scenes.

## 6. MAINTENANCE

---

### 6.1 Cleaning the Monitor

- Always unplug the monitor from the electrical outlet before cleaning.
- Use a soft, clean cloth lightly dampened with water to clean the screen and cabinet.

- Do not use abrasive cleaners, waxes, or solvents.

## 7. TROUBLESHOOTING

If you encounter issues with your monitor, refer to the following common solutions:

Problem	Possible Solution
No image on screen	<p>Ensure the power cable is securely connected.</p> <p>Verify the video cable (HDMI/VGA) is properly connected to both the monitor and the computer.</p> <p>Press the monitor's power button to ensure it is on.</p> <p>Select the correct input source using the OSD menu.</p>
Image is blurry or distorted	<p>Check the video cable for damage or loose connections.</p> <p>Adjust the resolution settings on your computer to the monitor's native resolution (1920x1080).</p> <p>Perform an auto-adjust function via the OSD menu (if available for VGA).</p>
Screen flickering or unstable image	<p>Ensure the video cable is securely connected.</p> <p>Verify that the monitor's refresh rate is set correctly (e.g., 75Hz).</p> <p>Test with a different video cable or port if possible.</p>
Colors appear incorrect	<p>Adjust color settings through the OSD menu.</p> <p>Disable ComfortView temporarily to see if it affects color accuracy.</p> <p>Ensure your graphics card drivers are up to date.</p>

## 8. SPECIFICATIONS

Feature	Detail
Model Number	KYKMD
Screen Size	27 Inches
Panel Type	IPS
Native Resolution	1920 x 1080 (Full HD)
Aspect Ratio	16:9
Refresh Rate	75 Hz
Response Time	6ms
Connectivity	1x HDMI, 1x VGA
Dimensions (LxWxH)	24.44 x 7.3 x 18.08 inches
Weight	12.79 pounds
Special Features	Flicker-Free, ComfortView (Low Blue Light)

# 9. WARRANTY AND SUPPORT

---

Dell products come with a standard limited warranty. For detailed warranty information, technical support, or service requests, please visit the official Dell support website or contact Dell customer service.

You can find support resources, drivers, and contact information at: [www.dell.com/support](http://www.dell.com/support)

