

[Manuals.plus](#) /

› [Waterpik](#) /

› Waterpik CF-201T Flexible Neck 6-Mode Rainfall Shower Head Instruction Manual

Waterpik CF-201T

Waterpik CF-201T Flexible Neck 6-Mode Rainfall Shower Head

INSTRUCTION MANUAL

Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Waterpik CF-201T Flexible Neck 6-Mode Rainfall Shower Head. Please read this manual thoroughly before installation and use to ensure proper function and longevity of the product.

Important Safety Information

- Always ensure the water supply is turned off before attempting any installation or maintenance.
- Do not overtighten connections, as this may damage the product or plumbing.
- Verify that all connections are secure to prevent leaks.
- Test water temperature before stepping into the shower to avoid scalding.

Package Contents

Verify that all components are present before beginning installation:

- Waterpik CF-201T Shower Head with Flexible Neck
- Installation Guide (this manual)



Image: The Waterpik CF-201T Flexible Neck Rainfall Shower Head, showing its overall design and flexible neck.

Installation Instructions

1. **Prepare the Shower Arm:** Ensure the existing shower arm is clean and free of debris. Remove any old shower head.
2. **Apply Plumber's Tape:** Wrap plumber's tape (not included) clockwise around the threads of the shower arm.
3. **Attach Shower Head:** Carefully screw the Waterpik CF-201T shower head onto the shower arm. Hand-tighten until snug. Do not use tools, as this may damage the finish or connections.
4. **Check for Leaks:** Turn on the water supply and check for any leaks around the connection points. If leaks occur, turn off water, re-tighten slightly, and re-check.
5. **Adjust Flexible Neck:** Position the 12-inch flexible neck to your desired height and angle. The neck is designed to hold its position once adjusted.



Image: The Waterpik CF-201T shower head installed on a shower arm, demonstrating the flexible neck's adjustability.

Operating Your Shower Head

The Waterpik CF-201T features 6 spray modes and a flexible neck for customized showering.

- **Adjusting Spray Modes:** Rotate the dial on the shower head face to cycle through the available spray settings. These include a drenching rainfall spray and a concentrated PowerSpray.
- **Positioning the Flexible Neck:** The 12-inch flexible neck allows you to easily adjust the height and horizontal position of the shower head. Simply bend the neck to direct the water flow precisely where you need it.

2 Spray Settings



Image: Visual representation of the two primary spray settings: Drenching Rainfall and PowerSpray, available on the Waterpik CF-201T shower head.

Your browser does not support the video tag.

Video: Official product video demonstrating the various spray patterns and water flow of the Waterpik shower head.

Care and Maintenance

To maintain optimal performance and appearance of your shower head, follow these cleaning guidelines:

- **Cleaning Nozzles:** The Waterpik CF-201T features easy-clean, anti-clog nozzles. To remove mineral deposits, simply rub the rubber nozzles with your finger or a soft brush.
- **Cleaning the Finish:** Use a soft cloth and mild soap to clean the exterior of the shower head. Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the finish.
- **Regular Cleaning:** Regular cleaning helps prevent mineral buildup and ensures consistent spray performance.

Anti-Clog Nozzles

Simply Rub to Remove Mineral Deposits



Image: A hand demonstrating how to rub the anti-clog nozzles on the Waterpik CF-201T shower head to remove mineral deposits.

Troubleshooting

Problem	Possible Cause	Solution
Low Water Pressure	Mineral buildup in nozzles or flow restrictor.	Rub the anti-clog nozzles to clear deposits. Ensure the flow restrictor (if present and removable per local codes) is not obstructed.
Leaking at Connection	Loose connection or insufficient plumber's tape.	Turn off water, re-apply plumber's tape, and hand-tighten the connection securely.
Flexible Neck Does Not Hold Position	Improper adjustment or excessive force.	Ensure the neck is bent into a stable position. Avoid repeatedly bending the same spot with extreme force.

Product Specifications

Feature	Detail
Brand	Waterpik
Model Number	CF-201T
Material	Plastic
Finish Type	Gloss
Number of Settings	6
Hose Length	12 Inches (Flexible Neck)
Item Dimensions (L x W)	5.5"L x 7"W (Shower Head Face)
Item Weight	1.5 Pounds
Special Features	12-inch flexible neck, dual-spray functionality (Rainfall, PowerSpray)




Image: Diagram illustrating the dimensions of the Waterpik CF-201T shower head, including the 12-inch flexible neck.

Warranty and Support

The Waterpik CF-201T Flexible Neck Rainfall Shower Head comes with **lifetime manufacturer's warranty**, ensuring quality and performance.

For technical assistance, warranty claims, or further information, please refer to the official Waterpik website or contact their customer support directly. Contact details are typically available on the product packaging or the manufacturer's official website.