

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Minka Lavery](#) /
- › [Minka Lavery 4177-249 Harbour Point Semi-Flush Light Fixture Instruction Manual](#)

Minka Lavery 4177-249

Minka Lavery Harbour Point Semi-Flush Light Fixture

MODEL: 4177-249

Instruction Manual

1. Important Safety Instructions

Please read and understand all instructions before beginning installation. Failure to do so may result in electric shock, fire, or other injuries that could be fatal or cause property damage. All wiring connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). If you are unfamiliar with electrical wiring, consult a qualified electrician.

- Always disconnect power at the main circuit breaker before installation or servicing.
- Ensure all connections are secure and correct.
- Do not exceed the maximum wattage specified for the bulbs.
- This fixture is designed for indoor use only.
- Handle glass components with care to prevent breakage.

2. Product Overview

The Minka Lavery Harbour Point 4177-249 is a 3-light semi-flush ceiling fixture designed to provide ambient lighting. It features a Liberty Gold finish and an etched white glass shade, offering a transitional style suitable for various indoor settings.



Front view of the Minka Lavery Harbour Point Semi-Flush Light Fixture in Liberty Gold with etched white glass.

Key Features:

- **Dimensions:** 9.75 inches High x 19 inches Wide.
- **Weight:** 6.64 lbs.
- **Lamping:** 3 bulbs, Max 100 Watts per bulb.
- **Socket Base:** E26 Medium Screw Base.
- **Recommended Bulb:** A19 type.
- **Voltage:** 120 Volts.
- **Dimmable:** Yes (requires compatible dimmer switch, not included).
- **Finish:** Liberty Gold.
- **Shade Material:** Etched White Glass.
- **Materials:** Alloy Steel, Glass.
- **Certifications:** UL Listed.

3. Package Contents

Verify that all components are present and undamaged before proceeding with installation.

- 1 x Semi-Flush Light Fixture (Model 4177-249)
- 1 x Etched White Glass Shade
- 1 x Mounting Hardware Kit (includes mounting strap, outlet box screws, wire nuts, ground screw)
- Instruction Manual

Note: Bulbs are not included and must be purchased separately.

4. Setup and Installation

Professional installation is recommended for electrical fixtures. Ensure power is OFF at the circuit breaker before starting.

Tools Required (Not Included):

- Phillips Head Screwdriver
- Flathead Screwdriver

- Wire Strippers
- Electrical Tape
- Safety Glasses
- Ladder

Installation Steps:

1. **Turn Off Power:** Locate the circuit breaker that supplies power to the light fixture location and turn it OFF.
2. **Prepare Mounting:** Attach the mounting strap to the outlet box using the provided outlet box screws. Ensure the mounting strap is securely fastened.
3. **Wiring Connections:** Connect the fixture's wires to the corresponding house wires using wire nuts.
 - Connect the bare copper (ground) wire from the fixture to the house ground wire (usually bare copper or green). Secure with a ground screw to the mounting strap.
 - Connect the white (neutral) wire from the fixture to the white (neutral) house wire.
 - Connect the black (hot) wire from the fixture to the black (hot) house wire.

Ensure all wire nuts are tightly secured and wrapped with electrical tape for added safety. The fixture includes a 7-inch long wire for connections.

4. **Mount Fixture:** Carefully push the wired fixture up to the ceiling and secure it to the mounting strap using the provided screws. Ensure no wires are pinched.
5. **Install Glass Shade:** Attach the etched white glass shade to the fixture according to the specific design. Typically, this involves securing it with decorative nuts or a twist-lock mechanism.
6. **Install Bulbs:** Screw three A19 type bulbs (E26 Medium Screw Base, max 100W each) into the sockets.
7. **Restore Power:** Turn the power back ON at the circuit breaker. Test the light fixture.

19" Dia. Semi Flush



4177-66A
Black Coal Finish
White Glass



4177-84
Brushed Nickel Finish
White Glass



4177-249
Liberty Gold Finish
White Glass

3 - 100W Medium Base

Dimensional diagram of the Minka Lavery Harbour Point Semi-Flush Light Fixture (19" Diameter, 9.75" Height).

5. Operating Instructions

Once installed and powered, the light fixture operates via your standard wall switch. If a compatible dimmer switch is installed, the light output can be adjusted.

- **Turning On/Off:** Use the wall switch connected to the fixture.
- **Dimming:** If a dimmer switch is installed, rotate or slide the dimmer control to adjust the light intensity. Ensure you use dimmable bulbs if utilizing this feature.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your light fixture.

- **Cleaning:** Always turn off power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish. For the glass shade, a mild glass cleaner applied to a cloth (not directly to the fixture) can be used.
- **Bulb Replacement:** Turn off power at the circuit breaker. Allow bulbs to cool completely before touching. Unscrew old bulbs and replace with new A19 type bulbs (E26 Medium Screw Base, max 100W each).

7. Troubleshooting

If you experience issues with your light fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	No power to the fixture Loose wiring connection Faulty bulb	Check circuit breaker and wall switch Verify all wire connections are secure (power off first) Replace bulb(s)
Light flickers	Loose bulb Incorrect bulb type for dimmer Faulty dimmer switch	Tighten bulb(s) Ensure dimmable bulbs are used with a dimmer Consult an electrician to check/replace dimmer
Humming noise	Incompatible dimmer switch or bulbs	Ensure dimmer and bulbs are compatible (e.g., LED bulbs with LED-compatible dimmer)

If problems persist, contact a qualified electrician or Minka Lavery customer support.

8. Specifications

Attribute	Detail
Brand	Minka Lavery
Model Number	4177-249
Product Dimensions	19" L x 19" W x 9.75" H
Item Weight	6.64 Pounds
Color	Liberty Gold
Material	Alloy Steel, Glass
Style	Transitional
Light Fixture Form	Close to Ceiling (Semi Flush Mount)
Number of Light Sources	3
Max Wattage Per Bulb	100 watts
Total Wattage	300 watts (3 x 100W)
Bulb Base	E26 Medium Screw Base
Recommended Bulb	A19
Voltage	120 Volts
Dimmable	Yes (requires compatible dimmer switch)
Shade Material	Glass
Shade Color	White
Specification Met	UL Listed
UPC	753956292714

9. Warranty Information

This Minka Lavery light fixture is covered by a one-year limited manufacturer's warranty. This warranty covers defects in materials and workmanship under normal use and service. For specific details regarding warranty claims, please refer to the original purchase documentation or contact Minka Lavery customer support.

10. Customer Support

For technical assistance, missing parts, or warranty inquiries, please contact Minka Lavery customer support. Contact information can typically be found on the manufacturer's website or your purchase receipt.