

Minka Lavery 8902-94

Minka Lavery 8902-94 European Influence Three Light Wall Mount Instruction Manual

Model: 8902-94

1. INTRODUCTION

Thank you for choosing the Minka Lavery 8902-94 European Influence Three Light Wall Mount. This fixture is designed to provide elegant illumination with a traditional aesthetic, featuring a heritage finish and clear glass shades. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions thoroughly before beginning installation and retain them for future reference.

2. SAFETY INFORMATION

WARNING: RISK OF ELECTRIC SHOCK. DISCONNECT POWER AT THE FUSE BOX OR CIRCUIT BREAKER BEFORE INSTALLATION OR SERVICING.

- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC).
- Consult a qualified electrician if you are unfamiliar with installing electrical fixtures.
- Do not connect this fixture to an ungrounded electrical system.
- Ensure all wires are properly connected and secured.
- Do not exceed the maximum wattage specified for the bulbs.
- Handle glass components with care to prevent breakage.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation. If any parts are missing or damaged, do not attempt to assemble or install the fixture. Contact customer service for assistance.

- Fixture Body (1)
- Glass Shade (1)
- Mounting Hardware Kit (1) - typically includes mounting plate, screws, wire nuts
- Instruction Manual (1)

4. SETUP AND INSTALLATION

Professional installation is recommended for this electrical fixture.

Required Tools (Not Included):

- Phillips Head Screwdriver
- Flathead Screwdriver
- Wire Strippers
- Electrical Tape
- Safety Glasses

Installation Steps:

1. **Turn Off Power:** Locate the circuit breaker or fuse box and turn off the power to the junction box where the fixture will be installed.
2. **Prepare Mounting Plate:** Attach the mounting plate (included in hardware kit) to the junction box using the provided screws. Ensure it is securely fastened.
3. **Make Electrical Connections:** Carefully connect the fixture's wires to the corresponding wires from the junction box. Use wire nuts (included) to secure connections.
 - Connect the **black** fixture wire to the **black** (hot) supply wire.
 - Connect the **white** fixture wire to the **white** (neutral) supply wire.
 - Connect the **ground** fixture wire (bare copper or green) to the **ground** supply wire (bare copper or green) or to the mounting plate's ground screw.

Ensure all connections are tight and no bare wire is exposed. Wrap connections with electrical tape if necessary.

4. **Mount Fixture Body:** Carefully align the fixture body with the mounting plate and secure it using the provided screws.
5. **Install Bulbs:** Insert three (3) B10.5 type incandescent bulbs with an E12 candelabra base into the sockets. Do not exceed 40 watts per bulb.
6. **Attach Glass Shade:** Secure the glass shade to the fixture body according to the specific design of the fixture. Ensure it is seated properly and tightened gently to prevent rattling or falling.
7. **Restore Power:** Once installation is complete and all components are secure, restore power at the circuit breaker or fuse box.



Image 1: Minka Lavery 8902-94 European Influence Three Light Wall Mount. This image displays the complete fixture, highlighting its traditional design, heritage bronze finish, and clear glass shade housing three candelabra-style light bulbs. The ornate wall plate and curved arm are also visible.

5. OPERATING INSTRUCTIONS

The Minka Lavery 8902-94 Wall Mount is operated via a standard wall switch connected to its electrical circuit. This fixture is compatible with dimmer switches, allowing you to adjust the light intensity. Ensure that any dimmer switch used is rated for incandescent lighting and meets local electrical codes.

6. MAINTENANCE

Cleaning:

- Always turn off power to the fixture before cleaning.
- Wipe the fixture with a soft, dry cloth.
- For glass components, use a mild glass cleaner applied to a cloth, then wipe the glass. Avoid spraying cleaner directly onto the fixture.
- Do not use abrasive cleaners or solvents, as they may damage the finish or glass.

Bulb Replacement:

- Turn off power to the fixture at the circuit breaker.
- Allow bulbs to cool completely before touching.
- Carefully remove the glass shade if necessary.
- Unscrew the old bulb and screw in a new B10.5 type incandescent bulb with an E12 candelabra base. Ensure the new bulb does not exceed 40 watts.
- Reattach the glass shade.
- Restore power.

7. TROUBLESHOOTING

If your Minka Lavery 8902-94 fixture is not functioning correctly, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check circuit breaker or fuse. Ensure wall switch is in the 'ON' position.
Light does not turn on.	Loose wire connection.	Turn off power. Check all wire connections for tightness. Consult a qualified electrician.
Light does not turn on.	Defective bulb.	Replace bulb with a new one of the correct type and wattage.
Light flickers.	Loose bulb or wiring.	Turn off power. Tighten bulb. Check wire connections.
Light flickers.	Incompatible dimmer switch.	Ensure dimmer switch is rated for incandescent loads and is compatible with the fixture.

8. SPECIFICATIONS

- **Brand:** Minka Lavery
- **Model:** 8902-94
- **Dimensions:** 11 x 9.75 x 27.5 inches (Width x Depth x Height)
- **Item Weight:** 11.29 pounds
- **Material:** Aluminum, Glass
- **Finish:** Heritage

- **Number of Lights:** 3
- **Bulb Type:** Incandescent (B10.5), E12 Candelabra Base
- **Max Wattage:** 40 watts per bulb (120 watts total)
- **Voltage:** 120 Volts
- **Indoor/Outdoor Usage:** Outdoor (Note: Product title and categories indicate outdoor use, despite a specification listing 'Indoor'.)
- **Control Method:** Wall Switch (Dimmer compatible)
- **Assembly Required:** No (referring to the main fixture body, some assembly of glass/bulbs is required)
- **UPC:** 747396620169

9. WARRANTY AND SUPPORT

This Minka Lavery fixture comes with a limited warranty. For specific details regarding warranty coverage, claims, or technical support, please contact Minka Lavery customer service directly. Keep your purchase receipt as proof of purchase.

For further assistance, please visit the official Minka Lavery website or refer to the contact information provided with your purchase.