

Inandon KV-306

Inandon KV-306 Karaoke Player User Manual

Model: KV-306 | Brand: Inandon

1. INTRODUCTION

Thank you for choosing the Inandon KV-306 Karaoke Player. This 22-inch capacitive touch screen system is designed to provide a comprehensive home entertainment experience with intelligent song selection and free cloud downloads. For optimal performance, please read this manual carefully before use.

What's in the Box

- Inandon KV-306 Karaoke Player Unit
- 22-inch Capacitive Touch Screen
- Microphone
- Power Adapters
- VGA Cable
- Network Cable
- RCA Audio Cables
- Optical Cable (optional, for soundbar connection)

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent damage to the device or injury to yourself:

- Ensure the karaoke machine is used with an amplifier and speakers (not included).
- Do not expose the unit to water or moisture.
- Use only the provided power adapters.
- Keep ventilation openings clear to prevent overheating.
- Avoid placing heavy objects on the unit.

- Disconnect power during lightning storms or when unused for long periods.

3. PRODUCT OVERVIEW

The Inandon KV-306 Karaoke Player consists of a main unit and a separate 22-inch touch screen for song selection and control. Below is an overview of the main unit's front and rear panels.




Image: Front and back panels of the Inandon KV-306 Karaoke Player. The front panel features a USB port and a power button. The rear panel includes LAN, USB, HDMI, VGA, Audio Out (RCA), Coaxial, Optical, DC 12V, MIC OUT, AUX IN, and antenna ports.

Key Features:

- 22-inch Capacitive Touch Screen for intuitive control.
- Wi-Fi Connectivity for online features and cloud downloads.
- Intelligent Song Deletion to optimize hard drive space.
- KTV Intelligent Scoring System for an interactive singing experience.
- Mobile Device Song Selection via dedicated app.
- System Online Update Service for continuous improvement.

4. SETUP

Follow these steps to set up your Inandon KV-306 Karaoke Player:

4.1. Touch Screen Assembly

Assemble the touch screen stand by securing the base and screen mount using the provided screws. Ensure all connections are firm.



Image: Components for assembling the touch screen stand. This includes the base, the vertical support, and the screen mounting plate, along with screws for assembly.

4.2. Connecting the Touch Screen to the Karaoke Player

1. Connect the touch screen VGA cable to the VGA output port on the karaoke player unit.
2. Connect the touch screen network cable to the 'TOUCH SCREEN' network interface on the karaoke player unit.
3. Connect the touchscreen power adapter to the touchscreen's power input.

KTV intelligent scoring system

atmosphere bullet-screen comments experience

Better grasp the singing effect, let you follow the rhythm to practice the song K song is over, enjoy your singing high score



Image: Detailed view of connecting the touch screen's VGA, network, and power cables to the main karaoke player unit.

4.3. Audio Output Connection

The karaoke player requires an external amplifier and speakers for audio output. There are two primary methods for connecting audio:

Method 1: Using RCA Cables (to Amplifier)

1. Connect the RCA red and white cables from the 'AUDIO OUT' ports on the karaoke machine to the 'AUX IN' of your amplifier.
2. Connect the microphone power adapter to the 12V port of the microphone host.
3. Connect the RCA red and white cables from the microphone host's AUX output to the audio input of the amplifier.

Mobile WeChat Wireless Ordering

Support mobile phone APP and WeChat remote song ordering, song ordering is more portable, you can remotely connect and click the song you want while lying on the sofa comfortably, support smart phones, tablets and other terminals to enjoy smart portable entertainment life



Image: Diagram showing how to connect the karaoke player to a soundbar using an optical cable.

4.4. Power Connection

1. Connect the power adapter of the karaoke machine to the DC 12V input on the karaoke machine.
2. Plug the power adapter into a wall outlet.

The system can be upgraded online without delay

Provide system online update service,
online WIFI line can be connected to the network,
and then the system online upgrade is not out of date



Image: Steps for connecting the power adapter to the karaoke player unit and plugging it into a power source.

4.5. Wiring Demonstration Video

For a visual guide on wiring, please refer to the video below:

Video: This video demonstrates the wiring process for the Inandon Karaoke Player, including connections for the touch screen, audio, and power.

5. OPERATING INSTRUCTIONS

Once the system is set up, you can begin enjoying your karaoke experience.

5.1. Powering On/Off

Press the 'POWER' button on the front panel of the main unit to turn the system on or off.

5.2. Using the Touch Screen Interface

The 22-inch capacitive touch screen provides an intuitive interface for navigating songs and features. It supports multi-finger touch for easy interaction.

MULTI-FINGER TOUCH



Image: The multi-finger touch interface of the karaoke player's screen, showing various application icons and controls.

5.3. Song Selection and Cloud Download

- **Intelligent Song Selection:** Browse and select songs directly from the touch screen.
- **Mobile Wireless Ordering:** Use a mobile phone app (e.g., WeChat) to remotely select songs.
- **Cloud Download:** Connect to the internet to access a vast cloud song library (approximately 440,000 songs) and download songs for free. The 4T hard drive stores about 90,000 songs.

Mobile WeChat Wireless Ordering

Support mobile phone APP and WeChat remote song ordering, song ordering is more portable, you can remotely connect and click the song you want while lying on the sofa comfortably, support smart phones, tablets and other terminals to enjoy smart portable entertainment life



Image: A mobile phone displaying a karaoke song selection interface, illustrating the mobile wireless ordering feature.

5.4. Intelligent Song Management

The karaoke machine features intelligent song deletion. When the hard drive memory falls below 10GB, the system automatically deletes songs with low or no click-through rates to free up space. You can re-download these songs from the cloud if needed.

Delete songs intelligently to maintain hard drive capacity

Intelligently delete long-term unclicked songs according to the upper limit of hard disk storage



Image: The karaoke player screen displaying the intelligent song deletion feature, which helps maintain hard drive capacity by removing infrequently played songs.

5.5. KTV Intelligent Scoring System

Enhance your singing experience with the built-in KTV intelligent scoring system, providing real-time feedback on your performance.

KTV intelligent scoring system

atmosphere bullet-screen comments experience

Better grasp the singing effect, let you follow the rhythm to practice the song K song is over, enjoy your singing high score



Image: The karaoke player displaying the KTV intelligent scoring system on a large screen, showing a singer and a score overlay.

5.6. Live Demonstrations

Watch these videos for live demonstrations of the karaoke machine in action:

Video: A live demonstration of the karaoke machine in use, showing two individuals singing along with lyrics displayed on a large screen.

Video: Live footage of karaoke machines in a room with dynamic lighting, showcasing the visual experience during use.

Video: This video illustrates the overall effect of using the karaoke system in a home setting, displaying the screen and audio setup.

6. MAINTENANCE

To ensure the longevity and optimal performance of your Inandon KV-306 Karaoke Player, follow these

maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the touch screen and main unit. Avoid abrasive cleaners or solvents.
- **Software Updates:** The system supports online updates. Regularly check for and install available updates to ensure you have the latest features and improvements.
- **Hard Drive Management:** The intelligent song deletion feature helps manage space. If you frequently download new songs, consider manually reviewing and deleting older, less-played songs.



Image: The karaoke player screen indicating that the system can be upgraded online without delay, highlighting the online update service.

7. TROUBLESHOOTING

If you encounter issues with your Inandon KV-306 Karaoke Player, refer to the following common problems and solutions:

Problem	Solution
---------	----------

Problem	Solution
No sound output	Ensure the karaoke machine is connected to an amplifier and speakers. Check all audio cable connections (RCA or Optical) and verify the amplifier/soundbar input source is correctly selected.
Touch screen not responding	Check the touch screen's power connection and the network cable connection to the main unit. Restart the system.
Cannot download songs from cloud	Verify that the karaoke player is connected to the internet via Wi-Fi or LAN. Check network settings.
Limited English songs	The cloud library has a larger selection of Chinese songs (approx. 240,000) compared to English songs (approx. 20,000). This is expected behavior.
Hard drive full	The system automatically deletes less-played songs when space is low. You can also manually manage songs or re-download from the cloud.

8. SPECIFICATIONS

Feature	Detail
Brand	Inandon
Model Number	KV-306
Special Feature	Touch Screen, Wi-Fi
Color	White
Included Components	Microphone
Recommended Uses	Business, Home, KTV
Power Source	Battery Powered (main unit is DC 12V, touch screen has separate adapter)
Total USB Ports	2
Connectivity Technology	Wi-Fi
Media Type	USB, SD, Wi-Fi
Compatible Devices	Amplifier
UPC	712760261446

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact the seller

directly. For technical support, you may reach out via WeChat at 17727581630.

© 2023 Inandon. All rights reserved.