

[Manuals.plus](#) /

› [360 Lighting](#) /

› 360 Lighting Royce Modern Table Lamps Instruction Manual

360 Lighting 9H211

360 Lighting Royce Modern Table Lamps

INSTRUCTION MANUAL

Product Overview

The 360 Lighting Royce Modern Table Lamps are a set of two elegant and functional lighting fixtures designed to enhance your living space. Featuring a contemporary teardrop shape with a silver finish resin construction, these lamps are complemented by off-white tapered rectangular shades. Each lamp is equipped with an on-off socket switch and is UL listed for safety. They are ideal for bedrooms, living rooms, offices, or as bedside nightstand lighting.



Figure 1: The 360 Lighting Royce Modern Table Lamps in a living room setting.

Safety Information

Please read and understand all instructions before assembling and operating this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the power is turned off at the main circuit breaker before installation or maintenance.
- Do not connect electricity until the lamp is fully assembled.
- Use only the specified bulb type and wattage (maximum 100 watt standard-medium base bulb).
- Do not use the lamp in wet or damp locations.
- Keep flammable materials away from the light bulb.
- This product is for indoor use only.
- If the cord or plug is damaged, do not operate the lamp. Contact customer support for assistance.

Package Contents

Verify that all components are present before beginning assembly:

- 2 x Lamp Bases (Silver finish resin teardrop body with metal base)
- 2 x Rectangular Lamp Shades (Off-white polyester)
- 2 x Harps (for shade attachment)
- 2 x Finials (for securing shade)
- 2 x Power Cords (6-foot long clear cords with plugs)
- (Bulbs not included)



Figure 2: Set of two Royce Modern Table Lamps.

Assembly Instructions

Follow these steps to assemble your 360 Lighting Royce Modern Table Lamps:

1. Carefully unpack all components from the packaging. Place them on a clean, flat, and stable surface.
2. Gently pull the power cord from the base of the lamp until the socket assembly is firmly seated at the top of the lamp

body. Ensure the cord is not twisted or pinched.

3. Attach the harp to the saddle on the lamp socket. The harp has two prongs that fit into the small holes on the saddle.
4. Place the rectangular lamp shade onto the harp. Ensure it sits evenly.
5. Screw the finial onto the threaded rod at the top of the harp to secure the lamp shade in place. Do not overtighten.
6. Insert one maximum 100-watt standard-medium base bulb (not included) into the lamp socket.
7. Plug the lamp's power cord into a suitable electrical outlet.



Figure 3: Detail of the lamp's top assembly.



Figure 4: Detail of the lamp's sturdy base.

Operating Instructions

The Royce Modern Table Lamps feature a convenient on-off socket switch for easy operation. To turn the lamp on or off, simply rotate the switch located on the lamp socket.

For optimal lighting, ensure a standard-medium base bulb with a maximum wattage of 100 watts is installed. LED bulbs are also compatible.

Your browser does not support the video tag.

Video: Overview of the Royce Teardrop Metal Table Lamp Set, demonstrating its features and operation.

Maintenance

Regular maintenance will help preserve the appearance and functionality of your lamps:

- **Cleaning:** Disconnect the lamp from the power source before cleaning. Use a soft, dry cloth to wipe down the lamp

base and shade. Do not use abrasive cleaners or polishes, as they may damage the finish.

- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled before attempting to replace it. Screw in the new bulb firmly but gently.
- **Shade Care:** The off-white polyester shades can be gently dusted with a soft brush or vacuum cleaner attachment. Spot clean with a damp cloth if necessary, avoiding harsh chemicals.

Troubleshooting

Problem	Possible Cause	Solution
Lamp does not light up.	Power cord not plugged in; bulb loose or burnt out; circuit breaker tripped.	Ensure cord is securely plugged in. Tighten or replace bulb. Check and reset circuit breaker.
Light flickers.	Loose bulb; incorrect bulb wattage; faulty wiring.	Tighten bulb. Ensure bulb wattage is within specified range (max 100W). If flickering persists, consult a qualified electrician.
Shade is crooked.	Harp or finial not properly aligned.	Adjust the harp to ensure it is straight. Loosen and re-tighten the finial to properly align the shade.

Specifications

Feature	Detail
Overall Height	24 1/2 inches (62.23 cm)
Base Dimensions	7 inches wide x 4 3/4 inches deep (17.78 cm x 12.06 cm)
Shade Dimensions	13 inches wide, 10 inches deep (top) x 14 inches wide, 11 inches deep (bottom) x 9 1/2 inches high
Weight (Each Lamp)	7.92 lbs (3.59 kg)
Bulb Type	Standard-medium base (E26)
Max Wattage	100 watts
Switch Type	On-off socket switch (Rotary)
Finish Type	Resin (Silver finish)
Shade Material	Polyester (Off-white)
Cord Length	6 feet (1.83 meters)
Certifications	UL listed
Model Number	9H211



Figure 5: Product Dimensions.

Warranty and Support

For warranty information and customer support, please refer to the manufacturer's website, the original purchase documentation, or contact the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

Manufacturer: Lamps Plus

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question