

[Manuals.plus](#) /

› [iClever](#) /

› iClever BK06 Folding Keyboard User Manual

iClever IC-BK06

iClever BK06 Folding Keyboard User Manual

Model: IC-BK06

PRODUCT OVERVIEW

The iClever BK06 Folding Keyboard is a portable Bluetooth keyboard designed for enhanced productivity across multiple devices. Its ergonomic, tri-fold design and full standard-size keys provide a comfortable typing experience, making it ideal for travel and mobile work setups.

Key features include multi-device connectivity (up to three devices), broad operating system compatibility (Mac/iOS/Windows/Android), and a long-lasting rechargeable battery housed within a durable PU leather cover.



Figure 1: iClever BK06 Folding Keyboard in use with a smartphone.

PACKAGE CONTENTS

- iClever BK06 Folding Keyboard
- USB-C Charging Cable
- User Manual (this document)
- Portable Stand Holder (may be included depending on package)

SETUP

1. Charging the Keyboard

Before initial use, fully charge the keyboard. Connect the provided USB-C charging cable to the keyboard's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged. A full charge typically takes approximately 2 hours.

SMALL SIZE EASY TO CARRY



Figure 2: The compact, folded dimensions of the iClever BK06 keyboard, highlighting its portability.

2. Powering On/Off

The keyboard automatically powers on when unfolded and powers off when folded. Ensure the keyboard is fully unfolded for operation.

3. Bluetooth Pairing

The iClever BK06 keyboard supports connection to up to three devices simultaneously. Follow these steps to pair with your device:

1. Unfold the keyboard to power it on.
2. Press and hold the **Fn** key, then press one of the Bluetooth channel keys **Q** for Channel 1, **W** for Channel 2, or **E** for Channel 3 for 3-5 seconds until the corresponding indicator light (blue LED above the channel key) starts blinking rapidly. This indicates the keyboard is in pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "iClever BK06" from the list of found devices.

5. If prompted, enter the pairing code displayed on your device using the iClever keyboard and press **Enter**.
6. Once paired, the indicator light will stop blinking and remain solid blue for a few seconds before turning off, indicating a successful connection.

To switch between paired devices, simply press **Fn + Q**, **Fn + W**, or **Fn + E**. The keyboard will automatically connect to the last paired device on that channel.



Figure 3: The keyboard's ability to connect to and switch between three different devices.

OPERATING THE KEYBOARD

Compatibility

The iClever BK06 keyboard is broadly compatible with various operating systems:

- **iOS:** iPhone, iPad (iOS 9.0 or later)
- **macOS:** MacBooks, iMacs (Mac OS X 10.8 or later with HID profile)

- **Android:** Smartphones, Tablets (Android 6.0 or later)
- **Windows:** PCs, Laptops (Windows 8 or later)
- **Chrome OS**

Note:

- Not compatible with Mac mini, Mac studio, XBOX, Samsung Smart TV, Nokia Phones, and certain Bluetooth adapters.
- This keyboard is Bluetooth only; it does not support USB receiver or wired typing.



Figure 4: Wide compatibility across major operating systems.

Function Keys and Shortcuts

The keyboard features a standard layout with additional function keys accessible via the **Fn** key. Some common shortcuts include:

Key Combination	Function
-----------------	----------

Key Combination	Function
Fn + Q/W/E	Switch between paired Bluetooth devices (Channel 1, 2, or 3)
Fn + F1-F12	Access multimedia and system functions (e.g., volume, playback, brightness)
Fn + 0	Check battery level (LED flashes indicate charge: 4 flashes = 100%, 1 flash = 25%)
Caps Lock	Toggle Caps Lock (LED indicator available)

The keyboard's ergonomic design, with a 166-degree angle, is intended to provide a comfortable typing posture and reduce wrist strain.



Figure 5: The ergonomic design of the keyboard, featuring a 166-degree angle for improved typing comfort.

Cleaning

To clean the keyboard, gently wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials. Ensure the keyboard is powered off and disconnected from any power source before cleaning.

Storage

When not in use, fold the keyboard to protect the keys and conserve battery life. Store it in a cool, dry place away from direct sunlight and extreme temperatures. The PU leather cover provides protection against scratches and fingerprints.



Figure 6: The keyboard's compact folded form factor, making it easy to carry and store.

TROUBLESHOOTING

If you encounter issues with your iClever BK06 keyboard, refer to the following common solutions:

Keyboard Fails to Connect

1. **Charge the keyboard:** Ensure the keyboard has sufficient battery by charging it for at least 2 hours.

- 2. **Clear Bluetooth records:** On your device, remove or delete all previous Bluetooth connection records for the keyboard.
- 3. **Refresh Bluetooth:** Turn off Bluetooth on your device, then turn it back on to refresh the connection.
- 4. **Re-pair:** Follow the Bluetooth pairing steps in the "Setup" section to connect the keyboard again.

Typing Delay, Frequent Disconnections, or Laggy Performance

- **Proximity:** Ensure your device and the keyboard are within close proximity to each other.
- **Interference:** Move away from potential sources of wireless signal interference, such as:
 - Microwaves, cordless phones, baby monitors, wireless speakers, garage door openers, Wi-Fi routers.
 - Computer power supplies.
 - Strong Wi-Fi signals.
 - Metal objects or metal wiring in walls.
- **Charge:** Charge the keyboard for 2 hours.
- **Operating System Update:** Make sure your device's operating system (OS) is up to date.

For further assistance, please refer to the official[Troubleshooting Guide \(PDF\)](#) or [User Manual \(PDF\)](#) available online.

SPECIFICATIONS

Feature	Detail
Brand	iClever
Model Number	IC-BK06
Connectivity Technology	Bluetooth Low Energy (wireless only, 3-device switch)
Keyboard Description	64-key tri-fold ergonomic Bluetooth keyboard with split "V" keys (non-backlit)
Compatible Devices	Windows 10+ PCs, macOS 10.13+ MacBook/iMac, Chromebooks, iPadOS/iOS 13+ iPad/iPhone, Android 8+ phones & tablets
Item Weight	6.2 ounces
Product Dimensions (Unfolded)	13.22"L x 4"W x 0.41"H
Product Dimensions (Folded)	6.18"L x 4.09"W x 0.19"H
Color	Black
Power Source	Rechargeable battery (1 Lithium Ion battery included)
Battery Life	Approx. 40-hour continuous working / 30 days standby (110 mAh battery lasts about 3 months)
Charging Port	USB-C
Key Noise Level	Quiet (< 50 dB)
Cover Material	PU Leather (not spill-proof)

WARRANTY AND SUPPORT

The iClever BK06 Folding Keyboard comes with a 12-month warranty. For warranty claims, technical support, or additional inquiries, please contact iClever customer service through their official channels or visit the [iClever Brand Store on Amazon](#).

Additional resources:

- [Troubleshooting Guide \(PDF\)](#)
- [User Manual \(PDF\)](#)

© 2024 iClever. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question