

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Aluratek](#) /

› [Aluratek 10-inch Slim Digital Photo Frame \(ASDMPF09\) User Manual](#)

## Aluratek ASDMPF09

# Aluratek 10-inch Slim Digital Photo Frame (ASDMPF09) User Manual

Model: ASDMPF09

[Introduction](#) [Package Contents](#) [Product](#)

[Features](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

## 1. INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your Aluratek 10-inch Slim Digital Photo Frame (Model ASDMPF09). This device is designed to display your digital photos, videos, and music with clarity and ease.



*Image: The Aluratek 10-inch Slim Digital Photo Frame, angled to show the display with a vibrant image of children.*

## **2. PACKAGE CONTENTS**

---

Please verify that all items listed below are included in your package:

- Aluratek 10-inch Slim Digital Photo Frame (ASDMPF09)
- Power Adapter

- USB Cable
- Instruction Manual (this document)
- Remote Control



*Image: All components included in the product packaging: the digital photo frame, its remote control, power adapter, USB cable, and the printed instruction manual.*


### 3. PRODUCT FEATURES

The Aluratek Digital Photo Frame offers the following key features:


- **Display:** 10-inch TFT true color LCD with 1024 x 600 resolution and a 16:9 aspect ratio.
- **Memory:** 8GB built-in memory for storing photos, videos, and music.
- **Media Support:** Supports SD / SDHC / SDXC memory cards (up to 32GB) and USB flash drives.
- **Slideshows:** Configurable photo slideshows with various display and transition modes, including background music.
- **Connectivity:** USB port for connecting external storage devices.
- **Ease of Use:** User-friendly interface for simple navigation and operation.
- **Automatic Playback:** Designed for automatic playback of media upon startup.
- **Clock & Calendar:** Integrated clock and calendar functions.

10”  
LCD Screen

for crisp and  
vivid pictures



LCD Display



Multimedia Support



Built-in Memory



SD Card / USB Support




Photo Slideshow



Easy To Use



Clock & Calendar



Digital Signage Solution

*Image: A visual summary of the frame's features, highlighting its 10-inch LCD screen, multimedia capabilities, built-in memory, and support for external storage.*

## 4. SETUP

### 4.1 Unpacking and Placement

1. Carefully remove the digital photo frame and all accessories from the packaging.
2. Place the frame on a stable, flat surface. Ensure adequate ventilation around the device.

### 4.2 Power Connection

1. Connect the power adapter to the DC IN port on the back of the frame.
2. Plug the power adapter into a standard electrical outlet. The frame should power on automatically or enter standby mode.

### 4.3 Inserting Media

To display your media, insert an SD card or USB flash drive into the corresponding slots on the frame.

- **SD Card:** Insert an SD/SDHC/SDXC memory card (up to 32GB) into the SD card slot with the metal

contacts facing down.

- **USB Flash Drive:** Insert a USB flash drive into the USB port.



Simply insert a SD/SDHC card or  
USB flash drive to instantly view photos.

*Image: The rear view of the digital photo frame, illustrating the insertion of an SD card into its designated slot, adjacent to the USB port.*

## 5. OPERATING INSTRUCTIONS

### 5.1 Navigation

The frame can be operated using the buttons on the back of the device or the included remote control.

- Use the directional buttons (**Up, Down, Left, Right**) to navigate through menus.
- Press the **OK** button to confirm selections.
- Press the **MENU** button to access settings or return to the previous menu.
- The **EXIT/RETURN** button allows you to go back or exit a function.



*Image: A detailed view of the navigation and control buttons situated on the rear panel of the digital photo frame.*

## 5.2 Viewing Photos and Slideshows

1. From the main menu, select "Photo" to browse images.
2. The frame will automatically start a slideshow of photos from the inserted media or built-in memory.
3. To customize slideshow settings (e.g., transition effects, display time, background music), access the "Settings" menu.

## 5.3 Playing Videos and Music

1. From the main menu, select "Video" or "Music" to play respective media files.
2. Use the remote control or device buttons for playback controls (Play, Pause, Skip).

## 5.4 Clock and Calendar

The frame includes a clock and calendar function. Access these features from the main menu to view the current date and time.

## 6. MAINTENANCE

---

### 6.1 Cleaning the Frame

- Ensure the frame is powered off and unplugged before cleaning.
- Use a soft, dry, lint-free cloth to gently wipe the screen and frame.
- Do not use liquid cleaners, aerosols, or abrasive materials, as these can damage the screen or finish.

### 6.2 Storage

When not in use for extended periods, store the frame in a cool, dry place, away from direct sunlight and extreme temperatures.

## 7. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Frame does not power on.	Power adapter not connected or faulty.	Ensure the power adapter is securely connected to the frame and a working electrical outlet. Try a different outlet.

Problem	Possible Cause	Solution
No images displayed.	No media inserted or files not supported.	Insert a compatible SD card or USB drive with supported photo files. Check file formats.
"Decode Error" message.	Corrupted or unsupported media file.	Ensure media files are not corrupted and are in a supported format. Try re-saving or using a different file.
Remote control not working.	Batteries are low or incorrectly inserted. Obstruction between remote and frame.	Replace remote control batteries (2 CR2 batteries required, as per specifications). Ensure line of sight to the frame's IR receiver.

## 8. SPECIFICATIONS

Feature	Detail
Model Number	ASDMPF09
Brand	Aluratek
Screen Size	10 Inches
Display Type	TFT True Color LCD
Resolution	1024 x 600
Aspect Ratio	16:9
Built-in Memory	8GB
Supported Memory Cards	SD / SDHC / SDXC (up to 32GB)
Connectivity	USB
Product Dimensions	10 x 12.6 x 8.25 inches
Item Weight	10.4 ounces
Power Source	AC Power Adapter
Remote Control Batteries	2 CR2 batteries (not included)

## 9. WARRANTY AND SUPPORT

### 9.1 Warranty Information

Aluratek products are covered by a limited warranty. Please refer to the warranty card included with your product or visit the official Aluratek website for detailed warranty terms and conditions.

### 9.2 Technical Support

For technical assistance, product registration, or to download the latest drivers and manuals, please visit the Aluratek support website or contact their customer service department. Contact details are typically

## Related Documents - ASDMPF09

 <b>Aluratek</b> aluratek.com	<a href="#"><u>Aluratek AWDMPF110F 10" WiFi Digital Photo Frame Instructional Manual</u></a> Comprehensive guide to setting up and operating the Aluratek AWDMPF110F 10-inch WiFi Digital Photo Frame, including connecting to Wi-Fi, linking social media accounts, transferring photos, and managing settings.
 <b>Aluratek</b> aluratek.com	<a href="#"><u>Aluratek WiFi Digital Photo Frame: Instructional Manual and Setup Guide</u></a> Comprehensive guide for Aluratek WiFi Digital Photo Frames, covering setup, app integration, social media linking (Facebook, Twitter), file transfer via computer, main menu functions, album settings, system configurations, alarm setup, technical support, and warranty information.
 <b>Aluratek</b> aluratek.com	<a href="#"><u>Aluratek 10" WiFi Digital Photo Frame AWDMPF110F: Instructional Manual</u></a> Comprehensive instructional manual for the Aluratek 10-inch WiFi Digital Photo Frame (Model AWDMPF110F). Learn setup, Wi-Fi connection, social media integration (Facebook, Twitter), Photo Partner app usage, and system settings.
 <b>Aluratek</b> aluratek.com	<a href="#"><u>Aluratek WiFi Digital Photo Frame Instructional Manual</u></a> User manual for Aluratek WiFi Digital Photo Frames with touchscreen LCD display, covering setup, app connection, photo transfer via Wi-Fi, email, social media, and computer, plus system settings and troubleshooting.
 <b>Aluratek</b> aluratek.com	<a href="#"><u>Aluratek AWDMPF8BB 8" WiFi Digital Photo Frame Instructional Manual</u></a> This instructional manual provides detailed guidance for the Aluratek AWDMPF8BB 8-inch WiFi Digital Photo Frame with Touchscreen LCD Display. It covers setup, Wi-Fi connection, linking to social media (Facebook, Twitter) and the Aluratek WiFi Frame app, transferring photos via USB or network, and navigating system and album settings. Includes technical support and warranty information.
 <b>Aluratek</b> aluratek.com	<a href="#"><u>Aluratek AWDMPF208F 8-Inch WiFi Digital Photo Frame: Instructional Manual &amp; Setup Guide</u></a> Comprehensive guide for the Aluratek AWDMPF208F 8-inch WiFi Digital Photo Frame. Learn how to set up, connect to Wi-Fi, link social media accounts (Facebook, Twitter), use the Photo Partner app, and navigate system settings for optimal photo display.



### [pdf] User Manual Quick Start Guide Instructions

10 Slim Digital Photo Frame Aluratek mnl M10407 Copyright © 2016 Inc All Rights Reserved aluratek model ASDMPF09 Instructional Manual 7 1 POWER SETUP VOL MENU ZOOM ROTATE MUTE RETURN BGM OK Remote Control Close Up 2 3 11 5 12 4 6 13 Start slideshow with background music If there are files on the same memory media Table of Contents Features 04 English asdmpf09 english manual pub wysiwyg 80 documents get document id 645 703

10 Slim Digital Photo Frame Instructional Manual aluratek.com model **ASDMPF09** mnl M10407 Copyright 2016 Aluratek, Inc. All Rights Reserved. Table of Contents Frame Features .....

04 Frame Con...

lang:en **score:47** filesize: 354.46 K page\_count: 20 document date: 2016-04-25

### [pdf] User Manual

Cadre photo numrique mince de 10 Aluratek Caractristiques du care Gros plan des commandes cadre ASDMPF09 French Manual asdmpf09 french manual aluratek pub media wysiwyg 80 documents get document id 644 704 886

Cadre photo numrique mince de 10 Manuel d instruction aluratek.com modele **ASDMPF09** mnl M10407 Copyright 2016 Aluratek, Inc. Tous les droits sont rservs. Table des matires Caractristiques du care..... 04 ...

lang:fr **score:45** filesize: 362.72 K page\_count: 24 document date: 2016-04-25



### [pdf] Datasheet

asdmpf09 datasheet aluratek 80 documents get document id 649 887

DIGITAL PHOTO FRAMES **ASDMPF09** Product Datasheet 10 Slim Digital Photo Frame with 4GB Built-in Memory Photos Video Music Card Slot USB Port Clock / Calendar **ASDMPF09** Product Datasheet Let s Get Digital aluratek.com Overview: Aluratek s Digital Photo Frames are a wonderful way to bring ...

lang:en **score:27** filesize: 477.94 K page\_count: 3 document date: 2016-06-21

DIGITAL PHOTO FRAME		Comparison Matrix		Aluratek	
Photo Only Frame	ASDMPF08	ASDMPF09	ASDMPF10	ASDMPF11	ASDMPF12
Screen Size	8.0" TFT				
Resolution / Aspect Ratio	800 x 480 x 16:9				
Memory Card Slot (SD/SDHC)	SD / SDHC				
Weight	0.95 lbs				
Dimensions	9.4" x 4.4" x 0.7"				
Build-in Clock and Calendar	USB 2.0				
Features via micro SD	Photo / Video / Music				
Photo / Video / Music	•	•	•	•	•
Internal Memory	4GB	4GB	4GB	4GB	4GB
External Memory	SD / SDHC				
Photo / Video / Music Lock	•	•	•	•	•
Photo / Video / Music Rotation	•	•	•	•	•
Digital Signage Function	•	•	•	•	•

### [pdf] Dimension Guide

digital photo frame comparison matrix v2 aluratek 80 documents get document id 802 807 811 813 818 888

DIGITAL PHOTO FRAME Comparison Matrix Photo Only Frames Photo / Video / Music Frames Model Number ... age Solution ASDPF08F 8 - 1024 X 768 / 4:3 Photos SD / SDHC 7.875 x 2 x 6.5 10.4 oz USB 2.0 **ASDMPF09** 10 4 GB 1024 x 600 / 16:9 Photos / Video / Music SD / SDHC 10 x 2 x 6.625 14 oz USB 2...

lang:en **score:17** filesize: 382.71 K page\_count: 4 document date: 2017-01-14