

Anker PowerCore 26800

Anker PowerCore 26800 Portable Charger User Manual

Model: PowerCore 26800

Brand: Anker

INTRODUCTION

Thank you for choosing the Anker PowerCore 26800 portable charger. This manual provides essential information for the safe and efficient use of your device, including setup, operation, maintenance, and troubleshooting. Please read this manual thoroughly before using the product and retain it for future reference.

SAFETY INFORMATION

- Do not expose the power bank to extreme temperatures (above 60°C/140°F) or direct sunlight.
- Do not disassemble, open, or attempt to repair the power bank.
- Keep the power bank dry and away from water or liquids.
- Avoid dropping, hitting, or subjecting the power bank to strong impacts.
- Dispose of the power bank according to local regulations. Do not dispose of it with household waste.
- Keep out of reach of children.

PACKAGE CONTENTS

The Anker PowerCore 26800 package includes the following items:

- Anker PowerCore 26800 Portable Charger
- 2 x Micro USB Cables
- Travel Pouch
- Welcome Guide (this manual)

Note: USB-C cables and Lightning cables for iPhone/iPad are sold separately and are not included.

PRODUCT OVERVIEW

The Anker PowerCore 26800 is a high-capacity portable charger designed to provide multiple charges for your mobile devices. It features three USB-A output ports and dual Micro-USB input ports for rapid recharging.



Image: Anker PowerCore 26800 Front View. This image displays the sleek black design of the Anker PowerCore 26800, highlighting its three USB-A output ports and two Micro-USB input ports located on one end. Four small LED indicator lights are visible above the ports, indicating the battery level.

ANKER

— The World's —
NO.1
Mobile Charging Brand

Power for Days

6.5

Charges
Galaxy S8



9.6

Charges
iPhone 8



2

Charges
iPad Air 2



Charging times based on laboratory testing.
Actual results may vary.

Image: Power for Days. This graphic demonstrates the extensive charging capacity of the PowerCore 26800, showing it can provide approximately 6.5 charges for a Galaxy S8, 9.6 charges for an iPhone 8, and 2 charges for an iPad Air 2. This illustrates its suitability for extended use without needing to recharge the power bank itself.

Triple-Device Charging



Image: Triple-Device Charging. This image shows the Anker PowerCore 26800 actively charging three different devices simultaneously: a smartphone, a tablet, and another smartphone. Blue arrows indicate the power flow from the power bank's three USB-A output ports to the connected devices, emphasizing its 30W total output capability.

Travel Ready

495 g | 17.46 oz



Image: Travel Ready. This image highlights the compact and portable nature of the PowerCore 26800, showing its dimensions (7.1 inches long, 3.2 inches wide, 0.9 inches thick) and weight (495g / 17.46 oz). The power bank is depicted next to a passport and a carabiner, suggesting its suitability for travel and outdoor activities.

SETUP

Before initial use, it is recommended to fully charge your Anker PowerCore 26800. This ensures optimal performance and battery longevity.

1. Connect one or two Micro USB cables (included) to the input ports of the power bank.
2. Connect the other end(s) of the Micro USB cable(s) to a USB wall charger (not included). For fastest charging, use a wall charger capable of delivering 4A total output (2A per port).
3. The LED indicators will illuminate to show the charging progress. All four LEDs will be solid when fully charged.

OPERATING INSTRUCTIONS

Charging the Power Bank

To recharge your PowerCore 26800, utilize the dual Micro USB input ports for double-speed recharging. A full recharge takes approximately 6.5 hours when using both input ports with a compatible 4A wall charger.

RECHARGE 2X FASTER

A full recharge takes only 6.5 hours.*



*Requires a 4A input | Wall charger sold separately

Image: Recharge 2X Faster. This image illustrates the dual input charging capability of the Anker PowerCore 26800. Two Micro USB cables are shown connected to the power bank's input ports, plugged into a wall adapter, signifying that the device can be recharged twice as fast as standard portable chargers. A note indicates that a full recharge takes only 6.5 hours with a 4A input.

The four LED indicators on the power bank will show the current charge level:

- One LED: 0-25% charged
- Two LEDs: 25-50% charged
- Three LEDs: 50-75% charged
- Four LEDs: 75-100% charged

Charging Your Devices

The PowerCore 26800 features three USB-A output ports, allowing you to charge up to three devices simultaneously. Anker's PowerIQ and Voltage Boost technologies ensure high-speed charging for compatible devices.



Image: Charging Devices in Use. This image shows a person using the Anker PowerCore 26800 to charge two smartphones simultaneously on a wooden table. The power bank is connected to both phones via USB cables, demonstrating its practical application for multi-device charging in a typical setting.

1. Connect your device's charging cable (USB-A end) to one of the PowerCore 26800's USB output ports.
2. Connect the other end of the cable to your device.
3. The power bank will automatically begin charging your device. The LED indicators will show the remaining battery level of the power bank.

Note: This power bank is not compatible with Qualcomm Quick Charge. For USB-C devices, use a USB-A to USB-C cable (not included).

MAINTENANCE

- Clean the power bank with a dry, soft cloth. Do not use corrosive cleaners or aerosols.
- Store the power bank in a cool, dry place when not in use.
- To maintain battery health, fully charge and discharge the power bank at least once every three months if it is not used regularly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging	Faulty cable or wall charger; input ports not fully connected.	Ensure Micro USB cables are securely connected. Try a different wall charger or cable.
Device not charging from power bank	Power bank battery depleted; faulty charging cable; device incompatibility.	Recharge the power bank. Try a different USB-A charging cable. Ensure your device is compatible with standard USB charging (not Qualcomm Quick Charge).
Slow charging	Using a low-power wall charger for power bank; using a non-optimal cable for device.	For power bank, use a 4A (2A per port) wall charger. For devices, ensure cable is in good condition and suitable for fast charging.

SPECIFICATIONS

Feature	Detail
Brand	Anker
Model	PowerCore 26800
Battery Capacity	26800 Milliamp Hours (mAh)
Input (Micro USB)	5V 4A (5V 2A Max Per Port)
Output (USB-A)	5V 6A (5V 3A Max Per Port)
Connector Type	USB-A *3 (Output), Micro-USB*2 (Input)
Special Feature	Fast Charging (via PowerIQ and Voltage Boost)
Color	Black

WARRANTY AND SUPPORT

Anker provides an 18-month worry-free warranty for the PowerCore 26800. For any product-related inquiries, technical support, or warranty claims, please contact Anker customer service. Refer to the official Anker website for the most up-to-date contact information and support resources.

You can typically find support contact details on the manufacturer's official website or through the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question