



Manuals.plus /

- › Tommy Hilfiger /
- › Tommy Hilfiger Smart Watch TH 24/7 Model 1791296 User Manual

Tommy Hilfiger 1791296

Tommy Hilfiger Smart Watch TH 24/7

MODEL 1791296 USER MANUAL

1. Introduction

The Tommy Hilfiger Smart Watch TH 24/7, Model 1791296, is designed to integrate classic watch aesthetics with modern smartwatch functionalities. This hybrid timepiece features a durable stainless steel case, a brown leather strap, and a black Sunray dial with both analog hands and a digital display. It provides essential smart features such as notification alerts and activity tracking, compatible with both iOS and Android devices.



Figure 1: Front view of the Tommy Hilfiger Smart Watch TH 24/7.

2. Setup

2.1 Unboxing

Upon opening the package, ensure all components are present:

- Tommy Hilfiger Smart Watch TH 24/7
- Charging cable
- User manual (this document)



Figure 2: The Tommy Hilfiger Smart Watch packaging box.

2.2 Initial Charging

Before first use, fully charge your smartwatch. Connect the provided charging cable to the watch and a compatible USB power source. The watch uses a product-specific battery, which is included.

2.3 App Installation

To utilize the smart features, download the official Tommy Hilfiger Smart Watch app on your smartphone:

- For iOS devices: Requires iOS 8 or later. Search for the app in the Apple App Store.
- For Android devices: Requires Android 4.4 or later. Search for the app in the Google Play Store.

2.4 Pairing with Smartphone

1. Ensure Bluetooth is enabled on your smartphone.
2. Open the Tommy Hilfiger Smart Watch app.
3. Follow the on-screen instructions within the app to pair your watch. This typically involves selecting your watch from a list of nearby devices.

3. Operating Your Smart Watch

3.1 Analog Time Display

The watch features traditional analog hands for displaying the current time. These hands operate independently of the digital smart functions, ensuring timekeeping even if the smart battery is depleted.

3.2 Digital Display Functions

The integrated digital display provides access to various smart features:

- **Incoming Calls:** View caller ID for incoming calls.
- **Messages:** Receive notifications for text messages.
- **Emails:** Get alerts for new emails.
- **Other Notifications:** Display notifications from other compatible apps on your smartphone.



Figure 3: Digital display showing an incoming call notification.

3.3 Activity Tracking

The built-in activity tracker monitors your daily steps. This data is synchronized with the companion app on your smartphone, allowing you to view your progress and set goals.

3.4 Water Resistance

The watch is water resistant up to 5 ATM (50 meters). This means it is suitable for everyday use, including

splashes, rain, and brief immersion in water. It is **not** recommended for swimming, diving, or prolonged water activities.

4. Maintenance and Care

4.1 Cleaning

- Wipe the watch case and mineral glass with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive materials, as these can damage the finish.

4.2 Battery Management

The smartwatch features a rechargeable battery for its smart functions. Regular charging is required to maintain these features. The analog timekeeping mechanism may use a separate, long-lasting watch battery.

4.3 Strap Care

The brown leather strap requires proper care to maintain its appearance and longevity:

- Avoid prolonged exposure to direct sunlight or extreme temperatures.
- Keep the strap dry. If it gets wet, gently wipe it with a soft cloth and allow it to air dry naturally.
- Do not use harsh cleaning agents on the leather.

5. Troubleshooting

If you encounter issues with your Tommy Hilfiger Smart Watch, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Watch not connecting to phone	Bluetooth is off; App not running; Watch battery low	Ensure Bluetooth is on; Open the app; Charge the watch
No notifications received	App permissions not granted; Notifications disabled in app/phone settings	Check app and phone notification settings; Grant necessary permissions
Short battery life for smart features	Frequent notifications; Heavy usage; Old battery	Reduce notification frequency; Charge regularly; Contact support if battery degradation is significant
Digital display difficult to read outdoors	Display technology limitation	This is a characteristic of the display type. Seek shaded areas for better visibility.

6. Specifications

Feature	Detail
Model Number	1791296 (also 7613272219945)
Case Material	Stainless Steel
Strap Material	Brown Leather
Dial Color	Black Sunray
Glass Type	Durable Mineral Glass
Water Resistance	5 ATM (50 meters)
Compatibility	iOS 8+ / Android 4.4+
Battery	1 Product-specific battery (included)
Weight	89 g (watch only, approximate)

7. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Tommy Hilfiger website. Keep your proof of purchase for warranty claims.