

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [One For All](#) /

> [One For All TV Bracket WM2211 User Manual](#)

One For All WM2211

One For All TV Bracket WM2211 User Manual

Fixed Wall Mount for 13-40 Inch TVs

Model: WM2211 | Brand: One For All

INTRODUCTION

Thank you for choosing the One For All WM2211 Fixed TV Bracket. This manual provides essential information for the safe and correct installation and use of your new TV wall mount. Please read these instructions carefully before installation and retain them for future reference. This fixed wall mount is designed to securely hold LED, LCD, and Plasma TVs ranging from 13 to 40 inches, with a maximum weight capacity of 50 kg. It supports VESA mounting patterns from 75x75mm to 200x200mm, ensuring compatibility with a wide range of televisions.

SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight capacity of 50 kg (110 lbs). Overloading can result in serious injury or damage to equipment.
- **Wall Type:** Ensure the mounting surface (wall) can safely support the combined weight of the mount and the TV. Consult a qualified professional if unsure.
- **Tools:** Use appropriate tools for installation. Always wear safety glasses.
- **Children:** Keep children and pets away during installation. Small parts can be a choking hazard.
- **Damage:** Do not install if any parts are missing or damaged. Contact customer support for replacement parts.
- **Ventilation:** Ensure adequate ventilation around the TV after mounting.

PACKAGE CONTENTS

Before beginning installation, verify that all components are present and undamaged. The package

should contain:

- One For All WM2211 TV Wall Mount Bracket
- Mounting Kit (screws, concrete anchors, spacers)
- Installation Manual



Image: The retail packaging for the One For All WM2211 TV Wall Mount, showing the bracket and key features.

SETUP AND INSTALLATION

The One For All WM2211 bracket is designed for quick and straightforward installation, typically in less than 10 minutes. Follow these steps carefully:

1. Pre-Installation Checks

- **Check VESA Compatibility:** Locate the four mounting holes on the back of your TV. Measure the horizontal and vertical distance between these holes (in millimeters). This is

your TV's VESA pattern. The WM2211 supports VESA sizes: 75x75mm, 100x100mm, 200x100mm, and 200x200mm. Ensure your TV's VESA pattern matches one of these.

- **Check TV Size and Weight:** Confirm your TV is between 13 and 40 inches and weighs no more than 50 kg (110 lbs).
- **Identify Wall Type:** Determine if your wall is solid concrete, brick, wood stud, or drywall. Different wall types require specific anchors and drilling techniques.



Image: A detailed view of the WM2211 bracket, highlighting its maximum weight capacity of 50 kg and VESA compatibility up to 200x200mm.

2. Mounting the Bracket to the Wall

1. **Mark Drilling Holes:** Hold the wall mount against the wall at the desired height and position. Use a pencil to mark the drilling locations through the mount's holes. Use a spirit level to ensure the marks are perfectly horizontal.
2. **Drill Holes:** Drill pilot holes at the marked locations using a drill bit appropriate for your wall type and the provided anchors.
3. **Insert Anchors:** Insert the appropriate wall anchors into the drilled holes. For wood studs, anchors may not be necessary, but ensure screws are driven directly into the center of the stud.
4. **Secure Mount:** Align the wall mount with the anchors and secure it firmly to the wall using the provided screws. Ensure it is tightly fastened and stable.



Image: The One For All WM2211 TV Wall Mount bracket, ready for installation on the wall.

3. Attaching the TV to the Bracket

1. **Attach TV Brackets:** Secure the TV attachment plates (if separate from the main mount) to the back of your TV using the appropriate VESA screws and spacers from the mounting kit. Ensure they are tightened securely.
2. **Hang TV:** Carefully lift the TV and align the attachment plates on the TV with the corresponding hooks or slots on the wall-mounted bracket. Gently lower the TV until it locks into place. You may need assistance for larger TVs.
3. **Secure TV:** Use any provided locking mechanisms (e.g., screws, pull cords) to secure the TV to the wall mount, preventing accidental dislodgement.



Image: A television mounted flush to the wall using the One For All WM2211 bracket, demonstrating its low-profile design.

The WM2211 offers a fixed low profile, with a minimum wall distance of only 14mm, making your TV appear almost flush with the wall.




Image: A visual representation illustrating the minimal 14mm wall distance achieved with the WM2211 bracket, providing a sleek, flush appearance.

One For All Toolbox App

For additional assistance during installation, download the free One For All Toolbox App. This app features helpful tools such as a spirit level and a flashlight, designed to make your installation process even quicker and easier. The app is available for both iOS and Android devices.

OPERATING

The One For All WM2211 is a fixed wall mount, meaning once installed, the TV's position relative to the wall is static. There are no moving parts for adjustment. Ensure the TV is positioned correctly during installation as repositioning will require unmounting and remounting.

MAINTENANCE

- **Cleaning:** To clean the mount, wipe it with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Periodic Checks:** Periodically check all screws and fasteners to ensure they remain tight and secure. Over time, vibrations or changes in temperature can cause them to loosen.
- **Damage:** If you notice any signs of damage or wear, discontinue use and contact customer support.

TROUBLESHOOTING

If you encounter issues during or after installation, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
TV does not fit the mount.	Incorrect VESA pattern or TV size/weight.	Verify your TV's VESA pattern (75x75, 100x100, 200x100, 200x200) and ensure it is within the 13-40 inch size and 50 kg weight limit.
Mount feels unstable on the wall.	Screws not tightened, incorrect anchors, or weak wall.	Ensure all screws are securely tightened. Use appropriate anchors for your wall type. If the wall is weak, reinforce it or choose a different mounting location.
TV is not level after mounting.	Wall mount was not level during installation.	Remove the TV, then adjust the wall mount to be perfectly level using a spirit level. Re-mount the TV.
Missing parts from the mounting kit.	Packaging error.	Do not proceed with installation. Contact One For All customer support for replacement parts.

SPECIFICATIONS

Brand:	One For All
Model Number:	WM2211
Mounting Type:	Wall Mount
Movement Type:	Fixed
Compatible TV Sizes:	13 - 40 Inches
Maximum Weight Capacity:	50 kg (110 lbs)
VESA Compatibility:	75x75mm, 100x100mm, 200x100mm, 200x200mm
Minimum Wall Distance:	14 mm (0.55 inches)
Material:	Metal
Color:	Black
Product Dimensions:	8.66 x 0.55 x 8.66 inches
Item Weight:	1.5 pounds

WARRANTY AND SUPPORT

One For All products are designed and manufactured to high quality standards. For information regarding warranty terms and conditions, or for technical support, please visit the official One For All website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

Related Documents - WM2211

	<p>One For All WM4221 SOLID TV Wall Mount - Quick Installation Guide</p> <p>This document provides a quick installation guide for the One For All WM4221 SOLID TV wall mount. It includes product specifications, important warnings, warranty information, and step-by-step visual instructions described in text.</p>
	<p>One For All WM4452 SOLID TV Wall Mount Quick Installation Guide</p> <p>A concise and SEO-optimized HTML guide for installing the One For All WM4452 SOLID TV wall mount. Includes product specifications, parts list, step-by-step instructions, warranty information, and safety warnings.</p>
	<p>WM6252 ULTRA SLIM TV Wall Mount Installation Guide ONE FOR ALL</p> <p>Comprehensive installation guide for the ONE FOR ALL WM6252 ULTRA SLIM TV wall mount, including specifications, guarantee terms, warnings, and step-by-step instructions.</p>
	<p>One For All WM6611 Ultra Slim TV Wall Mount - Quick Installation Guide</p> <p>A quick installation guide for the One For All WM6611 Ultra Slim TV wall mount, detailing product specifications, warranty terms, safety warnings, and step-by-step installation instructions with hardware lists.</p>
	<p>One For All WM5450 Dynamic Full-Motion TV Wall Mount Installation Guide</p> <p>This guide provides instructions for installing the One For All WM5450 Dynamic Full-Motion TV Wall Mount. It includes safety warnings, parts lists, and step-by-step installation procedures for mounting your TV securely.</p>
	<p>One For All WM4411 Solid TV Wall Mount Quick Installation Guide</p> <p>A comprehensive guide for the One For All WM4411 Solid TV Wall Mount, detailing installation steps, warranty information, and safety warnings in multiple languages.</p>