

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [CASTLECREEK](#) /
- › [CASTLECREEK 4-Drawer Lockable Storage Chest User Manual \(Model 667206\)](#)

CASTLECREEK 667206

CASTLECREEK 4-Drawer Lockable Storage Chest User Manual

Model: 667206

1. INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your CASTLECREEK 4-Drawer Lockable Storage Chest. This unit is designed to provide secure and organized storage for various items such as collectibles, keepsakes, and other valuables.



Image: The CASTLECREEK 4-Drawer Lockable Storage Chest, showcasing its oak finish and felt-lined top surface.

2. PRODUCT FEATURES

The CASTLECREEK 4-Drawer Lockable Storage Chest offers several features designed for security and organization:

- **Secure Storage Base:** Ideal for storing knives, antiques, coins, collectible items, militaria, and other keepsakes.
- **Lockable Design:** Features a slide-under door hide at the front, which is lockable to secure your valuables.
- **Durable Construction:** Made from wood composite with a hardwood veneer for lasting quality.
- **Four Felt-Lined Drawers:** Provides spacious storage with black felt lining to prevent scratches and damage to contents.
- **Brass-Tone Accents:** Includes attractive brass-tone details such as metal pulls, latches, locks, and carry handles.




Image: An overview of the CASTLECREEK 4-Drawer Storage Base, highlighting its function for secure collection organization.




Image: Detailed views of the lock mechanism, the protective felt top, and the four felt-lined drawers.

3. SETUP AND ASSEMBLY

Assembly of this storage chest is required. Please refer to the separate assembly instructions included in the

packaging for detailed steps and diagrams. Ensure all components are present before beginning assembly.

Placement Considerations:

- Place the chest on a flat, stable, and level surface to prevent tipping and ensure proper drawer function.
- Avoid placing the chest in direct sunlight or near heat sources to prevent wood warping or fading.
- Ensure adequate space around the chest for full drawer extension and access to the locking mechanism.

4. OPERATION

Opening and Closing Drawers:

1. Grasp the brass-tone pull handle on the desired drawer.
2. Gently pull the drawer straight out to open.
3. Push the drawer straight in until it is fully closed. Avoid forcing drawers.

Using the Locking Mechanism:

1. To access the lock, slide the front panel upwards and inwards, revealing the keyhole.
2. Insert the provided key into the lock.
3. Turn the key clockwise to lock the chest, securing the drawers and the slide-under door.
4. Turn the key counter-clockwise to unlock the chest.
5. Remove the key and slide the front panel back down to conceal the lock.
6. Store keys in a safe, memorable location away from the chest.

5. CARE AND MAINTENANCE

- **Cleaning:** Wipe the exterior surfaces with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the wood veneer.
- **Felt Lining:** The felt lining in the drawers helps protect your items. If it becomes dusty, gently vacuum with a brush attachment or use a lint roller. Do not wet the felt.
- **Wood Care:** Periodically inspect the wood for any signs of wear. For minor scratches, wood repair markers or polishes designed for hardwood veneer can be used.
- **Hardware:** The brass-tone hardware can be cleaned with a soft, dry cloth. Avoid liquid cleaners that may tarnish the finish.

6. TROUBLESHOOTING

Drawers are Sticking:

- Ensure the chest is on a level surface. Uneven surfaces can cause drawers to bind.
- Check for any obstructions inside the drawer or along the drawer slides.
- If the wood-on-wood slides feel rough, a small amount of furniture wax or paraffin applied to the contact surfaces can improve smoothness.

Lock Mechanism Not Engaging:

- Ensure the slide-under door is fully closed and aligned before attempting to lock.
- Verify that the key is fully inserted and turned completely.

Lost Keys:

- If keys are lost, contact CASTLECREEK customer support for assistance. Provide your model number and any identifying information from the lock if possible.

7. SPECIFICATIONS

Attribute	Detail
Brand	CASTLECREEK
Model Number	667206
Product Dimensions (D x W x H)	11.1" x 21.1" x 9.5"
Color	Oak
Item Weight	47 Pounds
Number of Drawers	4
Material	Wood Composite with Hardwood Veneer
Assembly Required	Yes
Recommended Uses	Collectibles, Keepsakes, Valuables

8. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or visit the official CASTLECREEK website. You may also contact CASTLECREEK customer service directly for assistance with any issues or questions regarding your storage chest.

Please have your model number (667206) and purchase details available when contacting support.

