

[Manuals.plus](#) /

› [Beliani](#) /

› User Manual: Beliani Ribotten Freestanding 160 x 200 cm BASIC

Beliani 39558

User Manual: Beliani Ribotten Freestanding 160 x 200 cm BASIC

Model: 39558

INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your Beliani Ribotten Freestanding 160 x 200 cm BASIC slatted bed base. Please read these instructions carefully before use to ensure proper setup and longevity of the product.

The Beliani Ribotten is a freestanding slatted bed base designed for optimal mattress support and comfort. It features a robust steel frame and 48 flexible slats, suitable for various mattress types.

PRODUCT OVERVIEW



Figure 1: Overall view of the Beliani Ribotten Freestanding 160 x 200 cm BASIC slatted bed base.

The Beliani Ribotten Freestanding slatted bed base is constructed with a durable steel frame and features 48 individual slats made from poplar wood, designed to provide flexible and even support for your mattress. It includes 10 support legs for enhanced stability.

Key Features:

- Suitable for all types of mattresses.

- Even weight distribution for maximum comfort.
- High-quality materials for durability.
- Ensures comfortable back support.
- Hygienic construction.
- Foldable construction with 10 support legs for stability.
- 48 flexible slats made of durable poplar wood.
- Maximum weight capacity: 350 kg.

SPECIFICATIONS

Attribute	Detail
Product Type	Freestanding Slatted Bed Base
Model Number	39558
Brand	Beliani
Color	Black
Main Material	Steel (Alloy Steel)
Additional Material	Synthetic material, Poplar wood (slats)
Number of Legs	10
Number of Slats	48
Width	160 cm
Length	200 cm
Height	18-21 cm
Sleeping Area	160x200 cm
Product Weight	23 kg
Weight Capacity	350 kg
Assembly Required	Yes (Estimated 20-40 minutes)



Figure 3: Detail of a frame connection, showing bolts for secure assembly.

3. **Attach Slats:** Insert the 48 poplar wood slats into their designated holders on the frame. Ensure each slat is firmly seated.



Figure 4: Detail of a slat holder, demonstrating how slats are secured within the frame.



Figure 5: Top view of the slatted bed base, showing the arrangement of the 48 slats.

4. **Install Support Legs:** Attach the 10 support legs to the designated points on the frame. Ensure they are securely fastened and provide stable support.



Figure 6: Corner detail showing a securely attached support leg.





Figure 7: Detail of a single support leg, illustrating its design.

5. **Final Check:** Before placing a mattress, ensure all connections are tight and the bed base is stable and level.

OPERATING INSTRUCTIONS

The Beliani Ribotten Freestanding slatted bed base is designed for direct use with a mattress. No additional bed frame is strictly required, as it is a freestanding unit.

- **Mattress Placement:** Carefully place your mattress directly onto the assembled slatted bed base. The 160x200 cm dimensions are suitable for standard double mattresses of the same size.
- **Weight Distribution:** The 48 flexible slats are designed to provide even weight distribution, adapting to your body's contours for enhanced comfort and support.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 350 kg (including mattress and occupants) to prevent damage to the bed base and ensure safety.
- **Ventilation:** The slatted design promotes air circulation, contributing to a hygienic sleeping environment and extending the life of your mattress.

CARE AND MAINTENANCE

Regular care will help maintain the condition and extend the lifespan of your slatted bed base.

- **Cleaning the Frame:** For the steel frame, wipe with a damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Cleaning the Slats:** The poplar wood slats can be gently wiped with a dry or slightly damp cloth. Ensure they are thoroughly dried afterwards to prevent moisture damage.
- **Regular Inspection:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten if necessary.
- **Avoid Overloading:** Adhere to the maximum weight capacity of 350 kg to prevent structural damage.

TROUBLESHOOTING

This section addresses common issues you might encounter with your slatted bed base.

- **Squeaking Noises:**
 - Check all frame connections and leg attachments. Tighten any loose bolts.
 - Ensure slats are properly seated in their holders.
 - If the bed base is placed on an uneven floor, slight movement can cause noise. Consider using felt pads under the legs or leveling the floor.
- **Instability/Wobbling:**
 - Verify that all 10 support legs are firmly attached and making full contact with the floor.
 - Ensure the frame is assembled correctly and all fasteners are tight.
- **Damaged Slat:**
 - If a slat is damaged, contact customer support for replacement options. Avoid using the bed base with broken slats as it can compromise support and safety.

WARRANTY INFORMATION

Specific warranty details for the Beliani Ribotten Freestanding 160 x 200 cm BASIC are typically provided at the point of purchase or within the product packaging. Please retain your proof of purchase for any warranty claims.

For information regarding warranty periods and conditions, please refer to the documentation included with your product or contact Beliani customer service.

CUSTOMER SUPPORT

Should you require further assistance, have questions about assembly, or need to report a missing or damaged part, please contact Beliani customer support.

Contact details can usually be found on the Beliani website or on your purchase invoice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01K5S3U58>

More documents and user manuals: <https://manuals.plus/>