

RGV 110831

RGV Aeternum ELT Digital 800W Food Dehydrator - 6 Trays Instruction Manual

Model: 110831 | Brand: RGV

INTRODUCTION

The RGV Aeternum ELT Digital 800W Food Dehydrator is designed for healthy, hygienic, and natural drying of fruits, vegetables, herbs, and other foods. This process helps preserve the nutritional properties of your food. Featuring a digital display for easy temperature control and an automatic shut-off function, this appliance simplifies food preservation.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

PACKAGE CONTENTS

Please ensure all items are present upon unpacking:

- RGV Aeternum ELT Digital 800W Food Dehydrator unit
- 6 drying trays


- Power cord
- Instruction Manual

PRODUCT OVERVIEW

The RGV Aeternum ELT Digital 800W Food Dehydrator features a robust design with a digital control panel for precise operation. It includes six spacious trays for simultaneous drying of various foods.



Front view of the RGV Aeternum ELT Digital 800W Food Dehydrator. This image shows the sleek black plastic exterior with a clear door, revealing the internal structure and fan.



Interior view of the RGV Aeternum ELT Digital 800W Food Dehydrator with its six transparent trays. The trays are designed for optimal airflow and easy loading of food items.



Close-up of the digital control panel on the RGV Aeternum ELT Digital 800W Food Dehydrator. It features an ON/OFF button, temperature and time adjustment buttons, and a clear digital display.

SETUP

1. Unpack the dehydrator and all its components.
2. Wash the drying trays and the interior of the unit with warm, soapy water. Rinse thoroughly and dry completely.
3. Place the dehydrator on a stable, flat, and heat-resistant surface, ensuring adequate ventilation around the unit.
4. Insert the clean drying trays into the unit.

5. Plug the power cord into a grounded electrical outlet (230V - 50Hz).

OPERATING INSTRUCTIONS

1. Preparing Food for Dehydration

Proper preparation is key to successful dehydration. Wash all food items thoroughly. Slice fruits and vegetables into uniform thickness for even drying. For meats, ensure they are lean and sliced thinly.

Video demonstrating food preparation and loading into a food dehydrator. This clip shows various fruits being sliced and arranged on drying trays, highlighting the ease of use and adjustable temperature settings.

2. Loading Trays

Arrange the prepared food items on the drying trays in a single layer, ensuring there is space between each piece for optimal air circulation. Do not overload the trays.

Video showcasing the loading process of a food dehydrator with various fruits and vegetables. The video emphasizes the efficient use of multiple trays for simultaneous drying.

3. Setting Temperature and Time

Use the digital display to set your desired temperature and drying time. The temperature is adjustable from 35°C to 78°C. Refer to a dehydration guide for recommended settings for different food types. The unit features an automatic shut-off function once the set time is complete.

4. Dehydration Process

The aluminum fan ensures uniform heat distribution across all 6 compartments, promoting consistent drying. Avoid opening the door frequently during the process to maintain stable temperature and humidity levels.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your dehydrator.

1. Unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. Remove all drying trays.
3. Wash the trays and the interior of the unit with warm, soapy water. A soft brush can be used for stubborn residues.
4. Rinse all parts thoroughly with clean water.
5. Dry all components completely before reassembling or storing the unit.
6. The main unit should be wiped clean with a damp cloth. Do not immerse the main unit in water.

Video demonstrating the cleaning process of the dehydrator trays. The trays are shown being washed under running water, emphasizing easy maintenance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Dehydrator does not turn on	Not plugged in or power switch off	Ensure the unit is properly plugged into a working outlet and the ON/OFF button is pressed.
Food not drying evenly	Overloaded trays or uneven slicing	Ensure food is spread in a single layer with space between pieces. Slice food to uniform thickness.

Problem	Possible Cause	Solution
---------	----------------	----------

Drying takes too long	Temperature too low or high humidity	Increase temperature if appropriate for the food type. Ensure the room is not excessively humid.
-----------------------	--------------------------------------	--

SPECIFICATIONS

- Brand: RGV
- Model: 110831
- Material: Plastic (Food-safe)
- Color: Black
- Power: 800 W
- Voltage: 230 V
- Frequency: 50 Hz
- Number of Trays: 6
- Dimensions: 362 × 472 × 290 mm
- Item Weight: 6.4 kg (14.33 lbs)
- Temperature Range: 35°C to 78°C
- Dishwasher Safe: No (for main unit)
- Country of Origin: Italy

WARRANTY AND SUPPORT

This RGV product comes with a 2-year manufacturer's warranty. For technical support, troubleshooting assistance, or warranty claims, please refer to the contact information provided in your purchase documentation or visit the official RGV website. Ensure you have your model number (110831) and proof of purchase available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question