

[Manuals.plus](#) /

› [iLive](#) /

› iLive ITB066B 32-inch Bluetooth Soundbar User Manual

## iLive ITB066B

# iLive ITB066B 32-inch Bluetooth Soundbar User Manual

Model: ITB066B

## INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your iLive ITB066B 32-inch Bluetooth Soundbar. This soundbar is designed to enhance your audio experience for home theater systems, televisions, and other compatible devices.

## PACKAGE CONTENTS

- iLive ITB066B 32-inch Bluetooth Soundbar
- Remote Control
- Power Adapter
- RCA Stereo Audio Cable
- User Manual (this document)

## PRODUCT OVERVIEW



Image: The iLive ITB066B 32-inch Bluetooth Soundbar, shown with its accompanying remote control. The soundbar is black and rectangular, with speaker grilles on the front. The remote control is also black with various function buttons.

## Front Panel / Top Panel Controls

- Power Button
- Source Button (to switch input modes)
- Volume Up/Down Buttons
- LED Indicators (Power, Source, Bluetooth Pairing)

## Rear Panel Connections

- DC Power Input
- RCA Audio Input (L/R)
- Optical Audio Input
- 3.5mm AUX Input (Line In)

## SETUP

---

### Power Connection

1. Connect the power adapter to the DC input on the soundbar.
2. Plug the power adapter into a standard wall outlet.
3. The power indicator LED will illuminate.

### Audio Connections

#### RCA Stereo Audio Connection

1. Connect one end of the RCA stereo audio cable to the RCA L/R outputs on your TV or audio source.
2. Connect the other end of the RCA stereo audio cable to the RCA L/R inputs on the soundbar.
3. Select "LINE IN" as the source on the soundbar.

#### Optical Audio Connection

1. Connect an optical audio cable (not included) from the optical output of your TV or audio source to the OPTICAL IN port on the soundbar.
2. Select "OPTICAL" as the source on the soundbar.
3. Ensure your TV's audio output is set to PCM or Stereo mode, as the soundbar may not support Dolby Digital or DTS formats.

#### Bluetooth Connection

1. Power on the soundbar.
2. Press the "Source" button on the soundbar or remote control until the Bluetooth indicator LED flashes, indicating pairing mode.
3. On your Bluetooth-enabled device (smartphone, tablet, etc.), search for "iLive ITB066B" in the Bluetooth settings.
4. Select "iLive ITB066B" to pair. Once paired, the Bluetooth indicator LED will stop flashing and remain solid.
5. You can now play audio from your device through the soundbar.

## OPERATING INSTRUCTIONS

---

## Power On/Off

Press the "Power" button on the soundbar or remote control to turn the unit on or off.

## Volume Control

Use the "Volume Up" and "Volume Down" buttons on the soundbar or remote control to adjust the volume level.

## Source Selection

Press the "Source" button on the soundbar or remote control repeatedly to cycle through available input sources: Bluetooth, Line In (RCA), Optical.

## Bluetooth Playback

When connected via Bluetooth, use the Play/Pause, Skip Forward, and Skip Backward buttons on the soundbar or remote control to control media playback on your paired device.

## MAINTENANCE

---

- Disconnect the power adapter before cleaning.
- Use a soft, dry cloth to clean the exterior of the soundbar.
- Do not use abrasive cleaners, waxes, or solvents.
- Keep the soundbar away from direct sunlight, heat sources, and excessive dust or moisture.

## TROUBLESHOOTING

---

| Problem                    | Possible Cause                                                                      | Solution                                                                                                                                                      |
|----------------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| No power                   | Power adapter not connected or outlet not working.                                  | Ensure power adapter is securely connected and plugged into a working outlet.                                                                                 |
| No sound                   | Incorrect source selected, volume too low, or audio cables not connected properly.  | Verify correct input source is selected. Increase volume. Check all audio cable connections. Ensure TV audio output is set correctly (e.g., PCM for optical). |
| Bluetooth pairing fails    | Soundbar not in pairing mode, device too far, or interference.                      | Ensure soundbar is in Bluetooth pairing mode (flashing LED). Move device closer to soundbar. Turn off other Bluetooth devices to reduce interference.         |
| Remote control not working | Batteries are dead or inserted incorrectly, or remote is not pointed at the sensor. | Replace remote control batteries. Ensure batteries are inserted with correct polarity. Point remote directly at the soundbar's remote sensor.                 |

## SPECIFICATIONS

---

- Model:** ITB066B
- Brand:** iLive
- Dimensions:** 84.7D x 10.2W x 6.2H Centimetres (33.3 x 4.0 x 2.4 inches approx.)
- Weight:** 2 Pounds (0.91 kg approx.)
- Connectivity:** Bluetooth, RCA (Line In), Optical

**Bluetooth Range:** Up to 60 feet (18 meters)

**Speaker Type:** Soundbar

**Audio Output Mode:** Stereo

**Speaker Maximum Output Power:** 50 Watts

**Included Components:** Soundbar, Remote Control

**Material:** Plastic, Cloth

**Color:** Black

## WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the warranty card included with your product or visit the official iLive website. Keep your purchase receipt for warranty claims.