

[Manuals.plus](#) /

› [GLOBO](#) /

› Globo Round LED Ceiling Light 12W for Bedroom 1 Bulb Chrome Opal 41738-12 User Manual

GLOBO 41738-12

Globo Round LED Ceiling Light User Manual

Model: 41738-12

1. INTRODUCTION

Thank you for purchasing the Globo Round LED Ceiling Light, model 41738-12. This modern ceiling fixture is designed to provide efficient and warm illumination for your living spaces, particularly bedrooms. Featuring an integrated LED module and a sleek design, this product offers superior quality finishes and long-lasting performance. Please read this manual thoroughly before installation and use to ensure safe and proper operation.



Figure 1: Main view of the Globo Round LED Ceiling Light (Model 41738-12).

2. SAFETY INSTRUCTIONS

WARNING: Risk of electric shock. Installation should only be performed by a qualified electrician or a person with adequate electrical knowledge.

- Always disconnect the main power supply at the circuit breaker or fuse box before beginning any installation, maintenance, or cleaning.
- Ensure that the voltage rating of the fixture matches your local power supply (230 Volts).
- Do not modify the fixture in any way. Any modifications may void the warranty and create a safety hazard.
- This fixture is rated IP20, meaning it is protected against solid objects larger than 12.5mm but has no protection against water. Do not install in damp or wet locations.
- Keep packaging materials out of reach of children.
- Handle the fixture with care to avoid damage.

3. PACKAGE CONTENTS

Carefully unpack the box and ensure all components are present and undamaged. If any parts are missing or damaged, do not attempt to assemble or install the product. Contact your retailer for assistance.

- Globo Round LED Ceiling Light Fixture (Model 41738-12)
- Integrated LED Module (pre-installed)
- Mounting Hardware (screws, wall anchors, etc.)
- Instruction Manual

4. SPECIFICATIONS

Feature	Specification
Brand	GLOBO
Model Number	41738-12
Product Dimensions (L x W x H)	29 x 29 x 9 cm
Item Weight	580 g
Material	Acrylic
Color (Fixture)	Chrome/White
Light Color	Warm White
Power Consumption	12 Watts
Luminous Flux	430 lm
Voltage	230 Volts

Feature	Specification
IP Rating	IP20
Installation Type	Ceiling Mount
Integrated LED	Yes

5. SETUP AND INSTALLATION

Before starting installation, ensure you have the necessary tools: screwdriver, wire strippers, drill (if needed), and safety glasses.

- 1. Turn Off Power:** Locate the circuit breaker or fuse box that controls the power to the installation location. Turn off the power completely to prevent electric shock. Verify the power is off using a voltage tester.
- 2. Prepare Mounting Surface:** If replacing an existing fixture, carefully remove it. Ensure the ceiling junction box is securely mounted and capable of supporting the fixture's weight.
- 3. Attach Mounting Bracket:** Secure the mounting bracket (if separate from the fixture base) to the junction box using the provided screws.
- 4. Make Electrical Connections:**
 - Connect the live (usually black or brown) wire from the ceiling to the live wire of the fixture.
 - Connect the neutral (usually white or blue) wire from the ceiling to the neutral wire of the fixture.
 - Connect the ground (usually green/yellow or bare copper) wire from the ceiling to the ground screw on the mounting bracket or fixture.

Use appropriate wire connectors (not always included) to secure all connections. Ensure no bare wires are exposed.

- 5. Mount the Fixture:** Carefully align the fixture with the mounting bracket and secure it using the provided screws or twist-lock mechanism. Ensure the fixture is flush with the ceiling and securely fastened.
- 6. Restore Power:** Once the fixture is securely installed and all connections are checked, restore power at the circuit breaker or fuse box.



Figure 2: The ceiling light installed, demonstrating its illumination in a room setting.



Figure 3: The ceiling light providing ambient lighting in a contemporary living space.

6. OPERATING INSTRUCTIONS

The Globo Round LED Ceiling Light is designed for simple operation. Once properly installed and connected to the main power supply, it can be controlled using a standard wall switch connected to the fixture's circuit.

- **Turning On/Off:** Flip the wall switch connected to the light fixture to the "ON" position to illuminate the light. Flip the switch to the "OFF" position to turn the light off.
- **Integrated LED:** This fixture uses an integrated LED module, which means the light source is built into the unit and is not designed for user replacement. The LED module has a long lifespan, reducing the need for frequent bulb changes.

7. MAINTENANCE

Regular maintenance will help preserve the appearance and performance of your ceiling light.

- **Cleaning:** Before cleaning, ensure the power to the fixture is turned off at the circuit breaker. Use a soft, dry, or slightly damp cloth to wipe the surface of the fixture. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or acrylic components.
- **LED Lifespan:** The integrated LED module is designed for a long operational life. If the LED module fails, the entire fixture may need to be replaced. Do not attempt to replace individual LED components.
- **Inspection:** Periodically inspect the fixture for any signs of damage, loose wiring, or wear. If any issues are found, disconnect power and consult a qualified electrician.

8. TROUBLESHOOTING

If you encounter any issues with your Globo Round LED Ceiling Light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	◦ No power to the fixture. ◦ Loose wire connections. ◦ Faulty wall switch. ◦ Damaged LED module.	◦ Check the circuit breaker or fuse. ◦ Ensure all wire connections are secure (with power off). ◦ Test the wall switch. ◦ If LED module is damaged, contact retailer for replacement.
Light flickers or dims.	◦ Loose wire connections. ◦ Incompatible dimmer switch (this fixture is not specified as dimmable). ◦ Voltage fluctuations.	◦ Check all wire connections (with power off). ◦ Ensure a standard ON/OFF switch is used, not a dimmer. ◦ Consult an electrician if voltage issues are suspected.
Humming noise from fixture.	◦ Loose mounting. ◦ Electrical interference.	◦ Ensure the fixture is securely mounted to the ceiling. ◦ Consult an electrician if electrical interference is suspected.

If the problem persists after trying these solutions, please contact a qualified electrician or the retailer for further assistance.

9. WARRANTY INFORMATION

Specific warranty details for the Globo Round LED Ceiling Light (Model 41738-12) may vary by region and retailer. Please refer to the warranty documentation provided at the time of purchase or contact your retailer for precise information regarding warranty coverage, terms, and conditions.

Generally, products are covered against defects in materials and workmanship for a specified period from the date of purchase. Keep your proof of purchase (receipt or invoice) as it will be required for any warranty claims.

10. CUSTOMER SUPPORT

For technical assistance, replacement parts, or any other inquiries not covered in this manual, please contact your point of purchase or the manufacturer directly.

Manufacturer: GLOBO Lighting

Please have your product model number (41738-12) and purchase date ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question