

[Manuals.plus](#) /

> [GUESS](#) /

> GUESS Delancy Analog White Dial Men's Watch - W0870G2 User Manual

GUESS W0870G2

GUESS Delancy Analog White Dial Men's Watch - W0870G2 User Manual

INTRODUCTION

This manual provides essential instructions for the proper setup, operation, and maintenance of your GUESS Delancy Analog White Dial Men's Watch, model W0870G2. Please read this guide thoroughly to ensure optimal performance and longevity of your timepiece.



Figure 1: GUESS Delancy Analog White Dial Men's Watch W0870G2. This image displays the watch with its white dial, rose gold finish, and black leather strap.

SETUP

1. Unboxing Your Watch

Carefully remove your watch from its packaging. Inspect the watch for any visible damage. Ensure all components are present.



Figure 2: The GUESS watch box, showing the watch cushion inside the open box and the closed lid with the GUESS logo.

2. Setting the Time and Date

- 1. Pull out the crown:** Gently pull the crown (the small knob on the side of the watch case) out to the first or second click position.
 - **First click:** For setting the date (if applicable). Turn the crown clockwise or counter-clockwise until the correct date is displayed.
 - **Second click:** For setting the time. Turn the crown to move the hour and minute hands.
- 2. Set the time:** Rotate the crown until the hour and minute hands indicate the correct time. To ensure accuracy, it is recommended to set the time a few minutes ahead and then turn it back.
- 3. Push in the crown:** Once the time and date are set, push the crown back into its normal position against the watch case. This will start the watch movement.

3. Wearing Your Watch

Adjust the leather strap to fit comfortably around your wrist. The buckle closure should be secure but not too tight, allowing for proper circulation.

OPERATION

1. Basic Timekeeping

Your GUESS Delancy watch features a precise Japanese Quartz movement, providing accurate analog time display with hour, minute, and second hands.

2. Day/Date Display

The watch includes an analog day and date display. The date typically advances automatically at midnight. If the date changes during the day, it indicates the watch is set to PM instead of AM. To correct this, pull the crown to the second click and advance the time by 12 hours.

3. Water Resistance

This watch is water resistant up to 30 meters (3 ATM). This means it is suitable for everyday use and can withstand splashes or brief immersion in water. It is **not** suitable for swimming, showering, or diving. Avoid operating the crown while the watch is wet.

MAINTENANCE

1. Cleaning Your Watch

Wipe the watch case and crystal with a soft, dry cloth. For the leather strap, use a slightly damp cloth and allow it to air dry completely. Avoid using harsh chemicals or abrasive materials.

2. Battery Replacement

The watch is powered by a Lithium Metal battery. When the watch stops running, it indicates the battery needs replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and water resistance.

3. Strap Care

Leather straps can be affected by moisture, sweat, and direct sunlight. To prolong the life of your strap, avoid prolonged exposure to water and extreme temperatures. Clean regularly and allow it to breathe.

4. Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and strong magnetic fields. The original watch box is ideal for storage.

TROUBLESHOOTING

- **Watch not running:**
 - Check if the crown is fully pushed in.
 - The battery may be depleted. Refer to the "Battery Replacement" section.
- **Date/Day not changing at midnight:**
 - The watch might be set to the wrong AM/PM cycle. Advance the time by 12 hours as described in "Day/Date Display" section.
- **Condensation under the crystal:**
 - This indicates moisture has entered the watch. Seek professional service immediately to prevent damage to the movement.

SPECIFICATIONS

Model Number	W0870G2
Brand	GUESS
Movement	Japanese Quartz
Display Type	Analog

Case Diameter	44 Millimetres
Case Thickness	10 Millimetres
Band Material	Leather
Band Width	20 Millimetres
Water Resistance	30 Meters (3 ATM)
Battery Type	Lithium Metal (included)
Item Weight	100 Grams
Special Features	Analog Dial with Day/Date Display, Second Hand

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your purchase or contact GUESS customer service. Keep your proof of purchase for warranty claims.

