

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VECELO](#) /

› [VECELO Dining Table with 4 Chairs Instruction Manual \(Model B01KCBIT72\)](#)

## VECELO 5 Piece Dining Table Set

# VECELO Dining Table with 4 Chairs Instruction Manual

Model: 5 Piece Dining Table Set (ASIN: B01KCBIT72)

## PRODUCT OVERVIEW

This manual provides detailed instructions for the assembly, use, and maintenance of your VECELO Dining Table with 4 Chairs. Please read carefully before assembly and retain for future reference.

The VECELO Dining Table with 4 Chairs is a versatile and space-saving furniture set designed for dining areas. It features a sturdy construction and a modern aesthetic, suitable for various home decors.

## PACKAGE CONTENTS

Before beginning assembly, ensure all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1 x Dining Table
- 4 x Chairs
- 1 x Instruction Manual (this document)
- 1 x Accessory Bag (containing all necessary hardware and tools)

## SAFETY WARNINGS

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and bolts are securely tightened before use. Periodically check and re-tighten as needed.
- Do not stand on the table or chairs.
- Do not place excessively hot items directly on the table surface without protection.
- Keep small parts and packaging materials away from children.
- Maximum weight capacity for the table: 200 lbs.
- Maximum weight capacity for each chair: 275 lbs.


## SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is straightforward and can typically be completed by one person in approximately 30-60 minutes. All necessary

tools are included in the accessory bag.

## Step 1: Identify Components and Hardware

Unpack all components and lay them out on a clean, soft surface. Refer to the parts list in the included instruction sheet to identify each piece.



*Image: Detailed dimensions and weight capacity for the VECELO Dining Table and Chairs. The table measures 43.3 inches in length, 27.5 inches in width, and 30 inches in height. Each chair measures 15.7 inches in length, 16.9 inches in width, and 33.8 inches in height. The table has a maximum load of 200 lbs, and each chair has a maximum load of 350 lbs.*

## Step 2: Assemble the Table Frame

Connect the table legs and support bars using the provided screws and the Allen key. Ensure all connections are finger-tight before fully tightening.

# SPACE SAVING DESIGN

Store the chairs underneath the table when not in use,  
ideal for space-limited rooms.



← In Use

Stored →



*Image: Illustration of the VECELO dining set's space-saving design. The chairs can be neatly tucked under the table when not in use, ideal for smaller living spaces.*

## Step 3: Attach the Tabletop

Carefully place the tempered glass tabletop onto the assembled frame. Align the pre-drilled holes in the glass with the mounting points on the frame. Secure the tabletop using the designated fasteners.



*Image: A close-up of the premium tempered glass table top, emphasizing its smooth, durable surface and the secure attachment points to the metal frame.*

#### **Step 4: Assemble the Chairs**

For each chair, attach the backrest to the seat frame, then connect the legs and crossbars. Ensure all screws are tightened for stability.

**Note:** The chairs feature a soft padded top and a high back for comfort.

#### **Step 5: Final Tightening**

Once all components are assembled, go back and fully tighten all screws and bolts on both the table and chairs. Do not overtighten.

### **OPERATING INSTRUCTIONS**

The VECELO Dining Table with 4 Chairs is designed for dining and general household use. Ensure the table is placed on a level surface to prevent wobbling. The chairs can be easily pulled out for use and pushed back under the table for

space-saving storage.

## MAINTENANCE AND CARE

- Cleaning:** Wipe the table and chair surfaces with a dry cloth. For stubborn stains on the tempered glass, use a glass cleaner. For chair upholstery, use a damp cloth with mild soap if necessary, and dry immediately.
- Protection:** Avoid using abrasive cleaners or materials that could scratch the surfaces. Use placemats or coasters to protect the tabletop from heat and spills.
- Inspection:** Periodically check all fasteners to ensure they remain tight. Re-tighten if any looseness is detected.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Table/Chair wobbles	Uneven floor or loose fasteners.	Ensure the product is on a level surface. Check and tighten all screws and bolts.
Difficulty assembling parts	Incorrect orientation of parts or misaligned holes.	Refer to the instruction manual diagrams. Ensure parts are oriented correctly before tightening. Do not force parts together.

## SPECIFICATIONS

- Brand:** VECELO
- Model:** 5 Piece Dining Table Set (ASIN: B01KCBIT72)
- Color:** Black
- Material:** Stainless Steel, Tempered Glass
- Table Dimensions:** 43.3" (L) x 27.5" (W) x 30" (H)
- Chair Dimensions:** 15.7" (L) x 16.9" (W) x 33.8" (H)
- Item Weight:** 60 pounds
- Seating Capacity:** 4
- Included Components:** 1 x Dining Table, 4 x Chairs, 1 x Instruction, 1 x Accessory Bag

## WARRANTY AND SUPPORT

This VECELO product comes with a **5-year warranty**. For warranty claims, missing parts, or any other inquiries, please contact VECELO customer support through the retailer where the product was purchased or visit the official VECELO website.

For additional support and product information, visit the [VECELO Store on Amazon](#).