

Mr. Coffee TM75RS-RB-1

Mr. Coffee TM75RS-RB-1 3-Quart Tea and Iced Coffee Maker User Manual

Model: TM75RS-RB-1 | Brand: Mr. Coffee

INTRODUCTION

Welcome to the Mr. Coffee TM75RS-RB-1 3-Quart Tea and Iced Coffee Maker user manual. This appliance is designed to simplify the process of brewing fresh, homemade iced tea or coffee. It accommodates coffee grounds, tea bags, or loose tea, allowing for a variety of cool, refreshing beverages. This manual provides essential information for safe operation, setup, brewing, maintenance, and troubleshooting to ensure optimal performance and longevity of your appliance.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using this appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- Scalding may occur if the lid is removed during the brewing cycle.

PARTS AND FEATURES

Familiarize yourself with the components of your Mr. Coffee Iced Tea and Coffee Maker:

- **Main Brewing Unit:** Houses the heating element and water reservoir.
- **Removable Brew Basket:** Holds coffee grounds, tea bags, or loose tea.
- **3-Quart Pitcher with Lid:** Collects the brewed beverage and is suitable for serving.
- **Brew Strength Selector Bar:** Allows adjustment of brew intensity.
- **Auto Shut-Off:** Automatically turns off the appliance after the brewing cycle is complete.
- **Reusable Filter:** For convenience and environmental benefit.



Image: The Mr. Coffee TM75RS-RB-1 3-Quart Tea and Iced Coffee Maker in red, showing the main brewing unit and the pitcher.





Image: The Mr. Coffee TM75RS-RB-1 Iced Tea and Coffee Maker with its top lid open, revealing the water reservoir and brew basket area.



Image: The Mr. Coffee TM75RS-RB-1 Iced Tea and Coffee Maker with its pitcher filled with brewed tea, alongside a glass of iced tea with fruit garnish.

SETUP

1. **Unpack:** Carefully remove all packaging materials and labels from the appliance.
2. **Initial Cleaning:** Before first use, wash the pitcher, lid, and brew basket in warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the brewing unit with a damp cloth.
3. **Placement:** Place the iced tea and coffee maker on a flat, stable, heat-resistant surface, away from the edge of the counter. Ensure there is adequate ventilation around the unit.
4. **First Brew Cycle (Water Only):** To clean the internal components, fill the water reservoir with clean water up to the 3-quart mark. Place the empty pitcher with its lid under the dispenser. Run a brew cycle without any tea or coffee. Discard the water.

OPERATING INSTRUCTIONS

Follow these steps to brew your favorite iced tea or coffee:

1. **Prepare the Pitcher:** Fill the 3-quart pitcher with ice cubes up to the indicated ice line. Place the pitcher with its lid (ensuring the lid is correctly positioned for brewing) under the dispenser of the brewing unit.
2. **Add Water:** Open the lid of the brewing unit and fill the water reservoir with fresh, cold water up to the desired level, typically the 3-quart mark for a full pitcher. Close the lid securely.
3. **Add Tea or Coffee:** Place the removable brew basket into its designated slot. For tea, add tea bags or loose tea into the brew basket. For coffee, add coffee grounds. Refer to the recipe or your preference for quantity.
4. **Select Brew Strength:** Adjust the Brew Strength selector bar to your desired intensity (e.g., strong, regular).
5. **Start Brewing:** Plug the appliance into a standard electrical outlet. Press the ON/OFF button or switch to start the brewing cycle. The indicator light will illuminate.
6. **Brewing Process:** Hot water will be dispensed over the tea or coffee, dripping into the ice-filled pitcher below. The appliance will automatically shut off once the brewing cycle is complete.
7. **Serve:** Once brewing is complete and the appliance has shut off, carefully remove the pitcher. Stir the brewed beverage to ensure the ice is fully melted and the flavor is evenly distributed. Serve immediately or refrigerate for later.

Instructional Videos

Your browser does not support the video tag.

Video: A closer look at the Mr. Coffee Iced Tea Maker, demonstrating its features and components. (Duration: 1:53)

Your browser does not support the video tag.

Video: Demonstration of how to use the iced tea maker, including filling and brewing steps. (Duration: 0:45)

Your browser does not support the video tag.

Video: A user review and demonstration of the iced tea maker, highlighting its functionality. (Duration: 0:47)

MAINTENANCE AND CLEANING

Regular cleaning ensures the best taste and extends the life of your appliance.

- **Daily Cleaning:** After each use, unplug the appliance and allow it to cool. Remove the pitcher, lid, and brew basket. These parts are dishwasher safe (top rack recommended) or can be washed by hand with warm, soapy water.
- **Wipe Down:** Wipe the exterior of the brewing unit with a soft, damp cloth. Do not immerse the brewing unit in water or any other liquid.
- **Descaling (Self-Cleaning Cycle):** Over time, mineral deposits can build up. To descale, fill the water reservoir with a

mixture of one part white vinegar and two parts water. Place the empty pitcher under the dispenser. Run a brew cycle. After the cycle, discard the vinegar solution and run two full cycles with clean water to rinse thoroughly. This process should be performed every 1-3 months depending on water hardness.

TROUBLESHOOTING

If you encounter issues with your Mr. Coffee Iced Tea and Coffee Maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet not working.	Ensure the power cord is securely plugged into a working electrical outlet.
Brewing is slow or incomplete.	Mineral buildup; insufficient water.	Perform a descaling cycle. Ensure the water reservoir is filled to the correct level.
Weak tea/coffee.	Not enough tea/coffee; incorrect brew strength setting.	Increase the amount of tea/coffee. Adjust the Brew Strength selector to a stronger setting.
Overflowing brew basket.	Too much tea/coffee; brew basket clogged.	Reduce the amount of tea/coffee. Clean the brew basket thoroughly to remove any clogs.

SPECIFICATIONS

- **Brand:** Mr. Coffee
- **Model Name:** TM75RS-RB-1
- **Capacity:** 3 Quarts
- **Color:** Red
- **Wattage:** 900 watts
- **Operation Mode:** Fully Automatic
- **Special Features:** Auto Shut-Off, Dishwasher Safe Pitcher, Permanent Filter
- **Coffee Input Type:** Grounds and Loose Tea
- **Filter Type:** Reusable
- **Material:** Plastic
- **Included Components:** Machine, Plastic filter, Pitcher with lid

WARRANTY AND SUPPORT

This Mr. Coffee appliance comes with a limited manufacturer's warranty. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your product packaging or visit the official Mr. Coffee website. For technical support, replacement parts, or further assistance, please contact Mr. Coffee customer service through their official website or the contact information provided in your product documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question