

ZENY FBA_Zeny01015

ZENY 39" Full Size Electric Guitar Instruction Manual

Model: FBA_Zeny01015

Brand: ZENY

INTRODUCTION

Thank you for choosing the ZENY 39" Full Size Electric Guitar. This comprehensive beginner starter package is designed to provide an excellent entry point into the world of electric guitar playing. This manual will guide you through the setup, operation, and maintenance of your new instrument and its accessories, ensuring a rewarding musical experience.

PRODUCT FEATURES

- Right-handed electric guitar with accessories, ready for immediate use.
- Durable all-wood construction with steel strings and an attractive, smooth finish.
- Maple wood neck with truss rod for optimal playability and adjustment.
- String Length: 25.59" / 650mm.
- Includes a 10W amplifier, nylon carrying case, extra strings, strap, cable, and guitar picks.

PACKAGE CONTENTS

Your ZENY Electric Guitar package includes the following items:

- 39" Full Size Electric Guitar (Blue)
- 10W Mini Guitar Amplifier
- Nylon Carrying Bag
- Guitar Shoulder Strap
- Extra Set of Steel Strings
- Guitar Cable
- Guitar Picks (2 pieces)
- Truss Rod Adjustment Tools (Allen wrenches)

Quality Accessories



Guitar Shoulder Strap



Guitar Picks



Power Cord



Spare Strings & Changing Tools



Mini Guitar Amplifier



Carrying Bag

Image: All accessories included with the ZENY 39" Full Size Electric Guitar kit, neatly arranged. This includes the guitar strap, two guitar picks, a power cord, spare strings with changing tools, the mini guitar amplifier, and a carrying bag.

SETUP INSTRUCTIONS

1. **Unpacking:** Carefully remove all items from the packaging. Inspect the guitar and accessories for any signs of damage.
2. **Attaching the Strap:** Securely attach the guitar shoulder strap to the strap buttons located on the body of the guitar.
3. **Connecting to the Amplifier:**
 - Ensure the amplifier is turned off and its volume is set to minimum.
 - Connect one end of the included guitar cable to the input jack on the guitar.
 - Connect the other end of the guitar cable to the 'INPUT' jack on the 10W Mini Guitar Amplifier.
 - Plug the amplifier's power cord into a suitable electrical outlet.

4. Tuning the Guitar:

- It is crucial to tune your guitar before playing. Use a digital tuner (not included in this specific package but widely available) or a tuning app on your smartphone.
- The standard tuning for a 6-string guitar from thickest to thinnest string is E-A-D-G-B-e.
- Gently pluck each string and adjust the corresponding tuning peg on the headstock until the tuner indicates the correct pitch.



Image: A young person playing the blue ZENY 39" Full Size Electric Guitar, connected to the mini amplifier, demonstrating a typical setup for practice.

OPERATING INSTRUCTIONS

Guitar Controls

- **Volume Knob:** Controls the overall output volume of the guitar. Turn clockwise to increase volume, counter-clockwise to decrease.

- **Tone Knobs (x2):** Adjust the tonal character of the guitar, from brighter to warmer sounds.
- **5-Way Pickup Selector Switch:** Allows you to select different pickup configurations for varied tones.

Amplifier Controls



Image: Detailed view of the ZENY 10W Mini Guitar Amplifier, showing its input, drive volume, treble, bass, phone, and power controls.

- **Power Switch:** Turns the amplifier on or off.
- **Input Jack:** Connect your guitar cable here.
- **Drive Volume:** Controls the volume when the 'Drive' (distortion) effect is engaged.
- **Treble Knob:** Adjusts the high frequencies of the sound.
- **Bass Knob:** Adjusts the low frequencies of the sound.
- **Phone Jack:** For connecting headphones for silent practice.

CUSTOMIZING YOUR SOUND

Experiment with the guitar's volume and tone knobs, along with the 5-way pickup selector switch, to discover a wide range of sounds. The amplifier's Treble and Bass controls further allow you to shape your desired tone.



Image: Close-up of the ZENY Electric Guitar's body, highlighting the Neck, Middle, and Bridge pickups, the 5-way switch, Volume knob, and two Tone knobs, illustrating options for sound customization.

Pickup Selector Positions:

- **Position 1 (Bridge Pickup):** Bright, sharp tone, ideal for lead guitar and rock.
- **Position 2 (Bridge & Middle Pickups):** Slightly warmer than the bridge, with a distinct

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question