

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [BaBylissPRO](#) /
- › [BaBylissPRO H100E Mini Liss Style'Up Mini Straightener User Manual](#)

BaBylissPRO H100E

BaBylissPRO H100E Mini Liss Style'Up Mini Straightener User Manual

Model: H100E | Full Model Number: 3030050125177

INTRODUCTION

This manual provides essential information for the safe and effective use of your BaBylissPRO H100E Mini Liss Style'Up Mini Straightener. Please read all instructions carefully before use and retain this manual for future reference.

SAFETY INSTRUCTIONS

To ensure safe operation and prevent injury or damage, observe the following safety precautions:

- **Fire Hazard:** Surfaces become extremely hot during use. Avoid direct contact with skin.
- **Risk of Electric Shock:** Keep the device away from water. Do not use it near bathtubs, sinks, showers, or other water sources.
- **Fire Hazard:** Unplug the device when not in use. Do not leave it unattended when plugged into an electrical outlet.
- Keep the device out of reach of children.
- Do not use the appliance if the cord or plug is damaged.
- Do not attempt to repair the appliance yourself. Contact qualified service personnel.

PRODUCT OVERVIEW

The BaBylissPRO H100E Mini Liss Style'Up is a compact and portable mini straightener designed for quick styling and touch-ups. It features ceramic plates for smooth gliding and consistent heat distribution.





A close-up view of the BaBylissPRO H100E Mini Liss Style'Up Mini Straightener, featuring its compact pink design and ceramic plates.

Key Features

- Compact and lightweight design, ideal for travel.
- "Satin'Touch" ceramic heating plates (14 x 60 mm) for smooth styling.
- Maximum temperature setting of 200°C.
- Corded power source for consistent performance.

SETUP

Before first use, ensure the straightener is clean and free from any packaging materials. Place the straightener on a heat-resistant surface.

OPERATING INSTRUCTIONS

Follow these steps for effective hair straightening:

1. Plug the mini straightener into a suitable electrical outlet.
2. Select the desired temperature. The straightener operates between 180 °C and 200 °C.
3. Wait until the straightener has reached the selected temperature. This usually takes a few moments.
4. Take a small section of dry hair. Pass the straightener over this section, ensuring the hair is evenly distributed between the plates and sections do not overlap.
5. Repeat the process over your entire hair, working in small sections until desired results are achieved.
6. After use, unplug the mini straightener from the electrical outlet and allow it to cool completely before storing.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and performance of your straightener:

- Always unplug the appliance and allow it to cool down completely before cleaning.
- Wipe the exterior and heating plates with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure no water enters the appliance.
- Store the straightener in a dry, safe place, away from moisture and extreme temperatures.

TROUBLESHOOTING

If you encounter any issues, refer to the following common problems and solutions:

- **Appliance not heating:** Ensure the straightener is properly plugged into a working electrical outlet. Check for any visible damage to the cord or plug.
- **Hair not straightening effectively:** Ensure hair is clean and dry before use. Work with smaller sections of hair. Allow the straightener to reach its full temperature before use.
- **Unusual odor or smoke:** Immediately unplug the device and discontinue use. Contact customer support.

TECHNICAL SPECIFICATIONS

Model Number	3030050125177 (H100E)
Plate Material	Ceramic ("Satin'Touch")
Plate Dimensions	14 x 60 mm
Maximum Temperature	200°C
Power Source	Corded
Product Dimensions	10 x 5 x 25 cm
Weight	0.26 g
Color	Pink
Manufacturer	Conair Italy s.r.l.

WARRANTY AND SUPPORT

This BaBylissPRO H100E Mini Liss Style'Up Mini Straightener comes with a **2-year guarantee** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support, service, or warranty inquiries, please contact the manufacturer or your local distributor. Do not attempt to repair the appliance yourself.