

[Manuals.plus](#) /

› [Guardzilla](#) /

› Guardzilla Indoor HD WiFi Security Camera User Manual

Guardzilla LYSB01KP60TJU-ELECTRNCS

Guardzilla Indoor HD WiFi Security Camera User Manual

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Guardzilla Indoor HD WiFi Security Camera. Designed for home security, this camera offers high-definition video streaming, two-way audio, motion detection alerts, and an integrated 100dB siren. Please read this manual thoroughly before using your device to ensure optimal performance and safety.



Figure 1: Front view of the Guardzilla Indoor HD WiFi Security Camera.

PRODUCT FEATURES

- **HD Quality Video:** Live streaming high-definition video of your home, accessible via your smartphone, day or night.
- **Motion Alerts:** Receive text, email, or push alerts on your phone when motion is detected, accompanied by a video record of the event.
- **Two-Way Audio:** Listen in and broadcast your voice into the monitored room directly through your smartphone.
- **Integrated 100dB Siren:** Optionally activate an ear-piercing siren to deter intruders.
- **Easy Setup:** Quick 5-minute setup process involving plugging in the device, downloading the free Guardzilla App, and connecting to your home Wi-Fi network.

PACKAGE CONTENTS

Please verify that all items are present in your package:

- Guardzilla Indoor HD WiFi Security Camera (Black)
- Power Adapter

- Quick Start Guide (if applicable)

SETUP GUIDE

Follow these steps for initial setup of your Guardzilla camera:

1. **Power On:** Plug the provided power adapter into the camera's power port and then into a standard electrical outlet. The camera will power on automatically.
2. **Download App:** Download the free *Guardzilla App* from your smartphone's app store (available for iOS and Android).
3. **Create Account:** Open the Guardzilla App and follow the on-screen prompts to create a new user account or log in if you already have one.
4. **Add Device:** Within the app, select the option to "Add New Device" or similar. Follow the app's instructions to connect your camera to your home Wi-Fi network. This typically involves scanning a QR code on the camera or entering your Wi-Fi credentials.
5. **Placement:** Position your camera in the desired location. Ensure it has a clear line of sight to the area you wish to monitor and is within range of your Wi-Fi signal. The camera is designed for indoor use.



Figure 2: Example placement of the Guardzilla camera on a flat surface.

OPERATING INSTRUCTIONS

Live View

To view live video from your camera, open the Guardzilla App and select your camera from the device list. The live feed will begin streaming. Ensure you have a stable internet connection for optimal viewing.

Motion Detection and Alerts

The camera is equipped with motion detection. When motion is detected, the camera can send alerts to your smartphone and record a short video clip. You can configure alert settings (e.g., push notifications, email alerts) and motion sensitivity within the Guardzilla App.

- **Arming/Disarming:** Use the app to arm or disarm the motion detection system.
- **Sensitivity:** Adjust motion sensitivity to minimize false alarms from pets or environmental factors.

Two-Way Audio

The two-way audio feature allows you to listen to sounds from the camera's location and speak through the camera's speaker. While in live view mode in the app, look for a microphone icon to speak and a speaker icon to listen.

Siren Activation

In case of an emergency or to deter unwanted activity, you can manually activate the 100dB siren through the Guardzilla App. Locate the siren icon within the live view interface and tap it to activate/deactivate.

MAINTENANCE

Cleaning

To clean the camera, gently wipe the exterior with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the device. Ensure the lens is clean for optimal video quality.

Software Updates

Periodically check the Guardzilla App for available software or firmware updates for your camera. Updates often include performance improvements, new features, and security enhancements. Follow the in-app instructions to perform any updates.

TROUBLESHOOTING

If you encounter issues with your Guardzilla camera, refer to the following common problems and solutions:

- **Camera Offline/Not Connected:**

- Ensure the camera is powered on and the power adapter is securely connected.
- Check your home Wi-Fi network. Ensure your router is working correctly and the Wi-Fi signal is strong where the camera is located.
- If you have changed your Wi-Fi network name (SSID) or password, you may need to delete the camera from the Guardzilla App and re-add it as a new device to reconnect to the new Wi-Fi settings.
- For iPhone users, try turning off "Wi-Fi Assist" or "Cellular Assist" in your phone's settings, as this can sometimes interfere with the camera's connection during setup or operation.

- **Poor Video Quality:**

- Clean the camera lens with a soft, dry cloth.
- Ensure adequate lighting in the monitored area.
- Check your internet speed. A slow connection can affect streaming quality.

- **Motion Alerts Not Working or Too Frequent:**

- Verify that motion detection is armed in the Guardzilla App.
- Adjust the motion sensitivity settings within the app. Lower sensitivity for fewer alerts, higher for more.
- Ensure the camera's field of view is not obstructed and is positioned to capture relevant motion.

- **Two-Way Audio Issues:**

- Check your smartphone's volume settings.
- Ensure there is no obstruction to the camera's microphone or speaker.
- A stable internet connection is crucial for clear audio.

If these steps do not resolve your issue, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Guardzilla
Model Number	LYSB01KP60TJU-ELECTRNCS
Connectivity Protocol	Wi-Fi
Video Capture Resolution	720p
Color	BLACK
Item Dimensions (L x W x H)	4.49 x 5.52 x 2.86 inches
Item Weight	1.35 Pounds
Low Light Technology	Day/Night
Alert Type	Motion Only
Indoor/Outdoor Usage	Indoor
Control Method	App
UPC	856751002332

WARRANTY AND CUSTOMER SUPPORT

Warranty Information

The Guardzilla Indoor HD WiFi Security Camera comes with a **1-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact Guardzilla customer support:

- **Phone Support:** (855) 268-7733 (US-based support)
- Please have your product model number (LYSB01KP60TJU-ELECTRNCS) and purchase date ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I reset my Guardzilla Indoor HD Wi-Fi Security Camera if I haven't used it in a long time?

Important Note: Guardzilla officially ceased operations in 2020 and shut down its servers. Because these cameras rely on those servers to function, most users report that the devices and the Guardzilla app are no...

[Read full answer](#)