LG AKB74915305

LG AKB74915305 TV Remote Control User Manual

1. Introduction and Overview

This document provides comprehensive instructions for the LG AKB74915305 TV Remote Control. This genuine Original Equipment Manufacturer (OEM) part is designed to operate compatible LG televisions from a short distance. Please follow the guidelines in this manual for proper setup and operation.

The LG AKB74915305 remote control features an ergonomic design with 45 buttons, offering full control over your television's functions. It utilizes infrared connectivity and has a maximum operating range of 30 feet.


CAPTION
TV
1
2
3
4
5
6
7
8
9
LIST
0
FLASHBK
FAV
VOL
INFO
CH
PAGE
RECENT
LIVE
MENU
LIVE
ZOOM
OK
BACK
EXIT
SAP/*
SLEEP
LG
AKB74915305

Image 1: Front view of the LG AKB74915305 TV Remote Control, showing all buttons including power, number pad, volume, channel, navigation, and smart TV function buttons.

2. Setup: Battery Installation

The remote control requires two AAA batteries (not included) for operation. Ensure you have fresh batteries before proceeding.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Slide the cover back into place until it clicks securely.



Image 2: Back view of the LG AKB74915305 TV Remote Control, highlighting the battery compartment cover.

3. Operating Instructions

To operate your LG television, point the remote control directly at the TV's infrared sensor.

- **Power On/Off:** Press the **POWER** button (red button at the top left) to turn the television on or off.
- **Volume Control:** Use the **VOL +/-** buttons to adjust the volume level.
- **Channel Navigation:** Use the **CH PAGE +/-** buttons to change channels. Alternatively, use the number pad (0-9) to directly enter channel numbers.
- **Navigation Pad:** Use the directional arrows (**UP, DOWN, LEFT, RIGHT**) and the central **OK** button to navigate menus and select options.
- **Recent Applications:** Press the **RECENT** button to access recently used applications or inputs.
- **Home Screen:** Press the **HOME** button (house icon) to go to the smart TV home screen and access various applications.
- **Back/Exit:** Use the **BACK** button to return to the previous screen or the **EXIT** button to close menus or applications.

4. Compatibility

This LG AKB74915305 remote control is compatible with a wide range of LG television models. Please verify your TV model number for full compatibility. Compatible models include, but are not limited to:

- LG 43UH6030
- LG 43UH6100
- LG 43UH6500
- LG 49UH6030
- LG 49UH6090
- LG 49UH6100
- LG 49UH6500
- LG 50UH5500
- LG 50UH5530
- LG 55UH6030
- LG 55UH6090
- LG 55UH6150
- LG 55UH6550
- LG 60UH6035
- LG 60UH6150
- LG 60UH6550
- LG 65UH5500
- LG 65UH6030

5. Specifications

Feature	Specification
Brand	LG
Model Name/Number	AKB74915305
Connectivity Technology	Infrared
Button Quantity	45

Maximum Range	30 Feet
Battery Type	2 AAA batteries (required)
Item Weight	1.44 ounces
UPC	717969518728

6. Troubleshooting

If your remote control is not responding or functioning correctly, consider the following:

- **Check Batteries:** Ensure the batteries are inserted with correct polarity and are not depleted. Replace with fresh AAA batteries if necessary.
- **Remove Obstructions:** Make sure there are no objects blocking the line of sight between the remote control and the TV's infrared sensor.
- **Verify Compatibility:** Confirm that the remote control model AKB74915305 is compatible with your specific LG television model.
- **Reset TV:** Sometimes, restarting your television (unplugging it for a minute and plugging it back in) can resolve minor communication issues.

7. Warranty and Support

For detailed warranty information regarding your LG AKB74915305 TV Remote Control, please refer to the documentation provided with your original television purchase or contact LG customer service directly. For technical assistance, visit the official LG support website or consult your television's owner's manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question