Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi ECAM 45760

De'Longhi Eletta ECAM 45760 Super-Automatic Espresso Machine User Manual

Model: ECAM 45760 | Brand: De'Longhi

Introduction

This manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of your De'Longhi Eletta ECAM 45760 Super-Automatic Espresso Coffee Machine. Please read this manual thoroughly before using the appliance for the first time and keep it for future reference.

The De'Longhi Eletta ECAM 45760 is designed to deliver a wide range of coffee and milk-based beverages, including espresso, cappuccino, latte, and macchiato, with convenience and quality. Its advanced features, such as the adjustable ceramic grinder and automatic milk frother, ensure a premium coffee experience.

Product Overview and Components

Familiarize yourself with the main components of your espresso machine.



Figure 1: Front view of the De'Longhi Eletta ECAM 45760 Super-Automatic Espresso Machine, showcasing the control panel, coffee spouts, and integrated milk carafe.



Figure 2: Side view of the De'Longhi Eletta ECAM 45760, illustrating its dimensions (14.2 inches wide, 10.3 inches deep, 18.1 inches high) and highlighting the LatteCrema System and 13 grind settings.

Key Components:

- **Control Panel:** Sensor metal touch control panel for intuitive operation.
- **Water Tank:** Front-loading 47-ounce (approx. 1.4-liter) removable reservoir with filter.
- **Bean Hopper:** Holds approximately half a pound of coffee beans.
- **Coffee Grounds Container:** Capacity for 14 single or 7 double espresso servings.
- **Milk Carafe (LatteCrema System):** Automatic milk frother for various milk-based drinks.
- **Bypass Doser:** Allows use of pre-ground coffee.
- **Brewing Unit:** Removable with variable capacity.
- **Drip Tray:** Removable with level indicator.
- **Cup Warmer:** Integrated feature to pre-heat cups.

Setup and First Use

1. Unpacking and Placement:

- Remove all packaging materials.
- Place the machine on a stable, flat surface, away from heat sources and water. Ensure adequate ventilation.
- Note: This model operates on 220-240V~50/60Hz. A power adapter (8.2x6.5x3.8 inches) is included for use in the United States. Ensure the adapter is properly connected before plugging into a power outlet.

2. Filling the Water Tank:

- Remove the water tank from the front of the machine.
- Fill it with fresh, cold tap water up to the MAX level.
- Insert the water filter as instructed in the separate filter guide (if applicable).
- Return the water tank to its position, ensuring it is securely seated.

3. Filling the Bean Hopper:

- Open the lid of the bean hopper.
- Pour fresh coffee beans into the hopper. Do not overfill.

4. Initial Rinse Cycle:

- After plugging in the machine, follow the on-screen prompts for the initial rinse cycle. This primes the circuits and ensures optimal performance.
- Place a container under the coffee spouts and milk frother to collect water during this process.

Operating the Machine

1. Control Panel Overview:

The machine features a sensor metal touch control panel with intuitive icons for various functions and drink selections.

2. Preparing Coffee:

- **Selecting a Drink:** Use the touch panel to select your desired coffee type (e.g., Espresso, Long Coffee).
- **Adjusting Strength and Quantity:** The machine allows customization of coffee strength and quantity. Refer to the display for options.
- **Grind Settings:** The integrated silent ceramic grinder has 13 adjustable settings. Adjust the grind fineness according to your preference and coffee type. Finer grind for stronger espresso, coarser for milder coffee.
- **Using Pre-Ground Coffee:** For pre-ground coffee, use the bypass doser. Add one scoop of pre-ground coffee into the dedicated compartment before selecting your drink.



Figure 3: The machine brewing two cups of espresso simultaneously, demonstrating its dual spout capability and efficient coffee preparation.

3. Preparing Milk-Based Beverages:

The patented AUTOMATIC CAPPUCCINO system and LatteCrema System allow for easy preparation of frothed milk and milk-based drinks.

- **Attaching the Milk Carafe:** Ensure the milk carafe is filled with fresh, cold milk and properly attached to the machine.
- **Selecting a Drink:** Choose from options like Cappuccino, Caffelatte, Latte Macchiato, or Flat White from the menu. The machine will automatically froth and dispense milk, then brew coffee.
- **Frothed or Hot Milk:** The system can also dispense frothed or hot milk independently for other uses.



Figure 4: The machine's milk frothing wand dispensing frothed milk into a pitcher, illustrating its versatility beyond integrated milk carafe use.

4. User Profiles:

The machine supports up to six full-blown user profiles. Each profile can save preferred settings for various drinks, including Coffee, Latte, Flat White, Cappuccino, Latte Macchiato, and Milk Long.



Figure 5: Visual representation of various coffee types that can be prepared by the De'Longhi Eletta ECAM 45760, including single/double espresso, long coffee, espresso macchiato, cappuccino, latte macchiato, latte, flat white, tea, and milk.

Maintenance and Cleaning

Regular cleaning and maintenance are crucial for the longevity and optimal performance of your espresso machine.

1. Automatic Cleaning Programs:

- The machine features automatic descaling, cleaning, and rinsing programs. Follow the prompts on the display.
- A cleaning warning for the cappuccino system will appear when cleaning is required.

2. Removable Components:

- **Brewing Unit:** The brewing unit is removable for manual cleaning. Rinse it under running water regularly.
- **Water Tank:** Clean the water tank periodically with mild detergent and rinse thoroughly.
- **Drip Tray and Coffee Grounds Container:** Empty and clean these components daily or as indicated by the machine. All removable components are dishwasher safe.
- **Milk Carafe:** Disassemble and clean all parts of the milk carafe after each use to prevent milk residue buildup.

3. Water Filter:

The machine includes a water filter to reduce the frequency of descaling. Replace the filter as recommended by the manufacturer or when indicated by the machine.

Troubleshooting

This section addresses common issues you might encounter. For more complex problems, refer to the full troubleshooting guide in the comprehensive manual or contact customer support.

- **"Empty Water" or "Empty Bean Container" Indicator:** Refill the respective containers. The machine will resume operation once refilled.
- **"Coffee Grounds Container Full" Indicator:** Empty the coffee grounds container and ensure it is properly reinserted.
- **"Cleaning Warning for Cappuccino System":** Perform the automatic cleaning cycle for the milk frother as prompted.
- **Coffee Not Dispensing:** Check if the water tank is full, the brewing unit is correctly inserted, and the coffee spouts are not blocked.
- **Milk Not Frothing Properly:** Ensure the milk carafe is clean, the milk is fresh and cold, and the frothing nozzle is not clogged.
- **Programming Water Hardness:** The machine allows programming the water hardness level, which affects descaling frequency. Adjust this setting based on your local water supply to optimize performance and maintenance alerts.
- **Sound Feedback:** The machine provides sound feedback for various operations and alerts.

Specifications

Detailed technical specifications for the De'Longhi Eletta ECAM 45760.

General Specifications

Dimensions (l x w x h inches):	14.2 x 10.3 x 18.1
Weight (Lbs):	24.2
Input power (W):	1450
Color:	White
«LONG» coffee:	Yes
“LatteCrema” System :	Yes
Auto shut-off:	Yes
Beans container capacity:	14.1oz.
Coffee grounds container:	14 single/7 double espresso
MY milk	Yes
Coffee powder use:	Yes
Display:	2-line with icons
Descaling, cleaning and rinsing program:	Yes
Maximum cup height:	5.75 inches
Energy saving function:	Yes
New silent grinder with 13 settings:	Yes
Power supply switch:	Yes
Programmable water hardness:	Yes
Pump pressure (bar):	15
Removable drip tray with level indicator:	Yes
Removable infuser unit:	Yes
Removable water tank:	Yes
Selection for 1 or 2 cups:	Yes
Cup holder:	Yes
Stand-by function:	Yes
Water filter:	Yes
Related Voltage/Frequency (V~Hz):	220-240~50/60

! A power adapter is included (8.2x6.5x3.8 inches) in order to work in the United States !

Figure 6: General specifications table for the De'Longhi Eletta ECAM 45760, including dimensions, weight, power, and features.

Feature	Specification

Feature	Specification
Brand	De'Longhi
Model Number	ECAM 45760 (de5cc185-d8b1-4146-9e52-065a63816aa6)
Color	White
Product Dimensions (D x W x H)	10.3" x 14.2" x 11.8"
Item Weight	31.1 pounds
Coffee Maker Type	Espresso Machine (Super-Automatic)
Special Features	Integrated Coffee Grinder, Water Filter, Cup Warmer, Milk Frother, Jug, Thermal
Filter Type	Reusable
Specific Uses For Product	Espresso, Cappuccino, Caffelatte, Latte Macchiato, Flat White, Milk Frothing
Operation Mode	Fully Automatic
Human Interface Input	Buttons (Sensor Metal Touch Control Panel)
Coffee Input Type	Coffee Beans and Ground Coffee
Grinder Settings	13 adjustable settings
Pump Pressure	Up to 15 bars
Water Reservoir Capacity	47 ounces (approx. 1.4 liters)
Double Boiler System	Yes
User Profiles	Up to 6

Warranty and Support

Your De'Longhi super-automatic coffee machine is backed by a **12-month Warranty** and an Unconditional Satisfaction Guarantee. De'Longhi is committed to providing world-class customer support.
If you encounter any issues or are not 100% satisfied with your product, please contact De'Longhi customer support immediately for assistance. Support is typically available 7 days per week.
For further assistance, visit the official De'Longhi website or refer to the contact information provided with your purchase documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01KXV4WV8

More documents and user manuals: **https://manuals.plus/**