

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Bose](#) /
- › [Bose Virtually Invisible 300 Wireless Surround Speakers User Manual](#)

Bose 768973-1110

Bose Virtually Invisible 300 Wireless Surround Speakers User Manual

Model: 768973-1110

[Introduction](#) [What's in the](#)

[Box](#) [Setup](#) [Operating](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

INTRODUCTION



Image: Two black Bose Virtually Invisible 300 Wireless Surround Speakers, shown from the front at an angle, highlighting their compact design.

The Bose Virtually Invisible 300 Wireless Surround Speakers are designed to enhance your home entertainment experience by providing immersive surround sound. These compact speakers seamlessly integrate with your existing Bose SoundTouch 300 soundbar and Acoustic 300 wireless bass module, placing you at the center of the audio action. Their small size allows for discreet placement, ensuring your focus remains on your entertainment.

WHAT'S IN THE BOX

- Virtually Invisible 300 speakers (2)
- Wireless surround speaker receivers
- Power supply
- Necessary cables

SETUP

Setting up your Bose Virtually Invisible 300 Wireless Surround Speakers is designed to be straightforward, allowing you to enjoy enhanced audio quickly. These speakers are intended to be paired with a compatible Bose soundbar, such as the SoundTouch 300, and optionally the Acoustic 300 wireless bass module.

Placement

For optimal surround sound, position the speakers behind your primary listening area. The wireless connectivity allows for flexible placement without the need for long audio cables running across your room. Ensure each speaker's wireless receiver is within range of your soundbar and has access to a power outlet.



Image: A single black Bose Virtually Invisible 300 Wireless Surround Speaker mounted on a light-colored wall, demonstrating a typical placement option.

Connection

1. Connect each Virtually Invisible 300 speaker to its corresponding wireless surround speaker receiver using the provided cables.
2. Plug the power supply for each receiver into a wall outlet.
3. Ensure your Bose SoundTouch 300 soundbar (and Acoustic 300 bass module, if applicable) is powered on and connected to your home network.
4. Follow the instructions in the Bose SoundTouch app to pair the surround speakers with your soundbar. The app will guide you through the wireless connection process and audio calibration.



Image: Two Bose Virtually Invisible 300 Wireless Surround Speakers, black, shown with their wireless receivers and cables, illustrating the components and connections.

Audio Calibration (ADAPTiQ)

After connecting, perform the ADAPTiQ audio calibration using the headset provided with your Bose soundbar. This process optimizes the sound performance for your specific room's acoustics and speaker placement, ensuring balanced and immersive surround sound. This step is crucial for the best audio experience.

OPERATING YOUR SPEAKERS

Once set up, your Virtually Invisible 300 speakers operate seamlessly with your Bose soundbar. They automatically power on and off with the soundbar and adjust their volume in sync with the main system.

Volume Adjustment

The overall system volume, including the surround speakers, is controlled via your soundbar's remote control or the Bose SoundTouch app. Some users may find it beneficial to fine-tune the individual volume levels of the surround speakers through the app for a personalized listening experience, especially if the initial calibration results in perceived low sound from the rear speakers.

Source Selection

The surround speakers will play audio from whatever source is selected on your Bose soundbar (e.g., TV, Bluetooth, Wi-Fi streaming). They are designed to provide a full, immersive soundstage for all your audio content.

MAINTENANCE

To ensure the longevity and optimal performance of your Bose Virtually Invisible 300 Wireless Surround Speakers, follow these simple maintenance guidelines:

- **Cleaning:** Gently wipe the surfaces of the speakers and receivers with a soft, dry cloth. Avoid using liquid cleaners, solvents, or abrasive materials, as these can damage the finish.
- **Placement:** Keep the speakers away from direct heat sources, excessive moisture, or extreme temperatures. Ensure adequate ventilation around the wireless receivers.
- **Cables:** Periodically check all cable connections to ensure they are secure. Avoid bending or pinching cables, which can lead to damage.
- **Software Updates:** Keep your Bose SoundTouch app and soundbar firmware updated to ensure compatibility and access to the latest features and performance improvements.

TROUBLESHOOTING

Problem	Possible Solution
No sound from surround speakers	<ul style="list-style-type: none">• Ensure power cables are securely plugged into outlets and receivers.• Verify speakers are correctly paired with the soundbar via the Bose SoundTouch app.• Perform ADAPTiQ audio calibration again.• Check the soundbar's settings in the app to ensure surround speakers are enabled and their volume is not set too low.
Low volume from surround speakers	<ul style="list-style-type: none">• Run ADAPTiQ audio calibration. This process sets the volume for the rear speakers.• Adjust the individual volume level of the surround speakers in the Bose SoundTouch app (e.g., to +4 as suggested by some users).
Intermittent sound or disconnections	<ul style="list-style-type: none">• Ensure wireless receivers are within optimal range of the soundbar and not obstructed.• Check for potential wireless interference from other devices.• Verify soundbar and speaker firmware are up to date.• Restart the soundbar and surround speakers by unplugging them for 30 seconds and plugging them back in.

SPECIFICATIONS

- **Model Name:** Virtually Invisible 300
- **Item Model Number:** 768973-1110
- **Speaker Type:** Surround Sound
- **Color:** Black
- **Product Dimensions (each speaker):** 3.3"D x 3.2"W x 3.7"H
- **Item Weight (each speaker):** 1.2 lbs (speakers only), 2.2 lbs (total for pair)
- **Connectivity Technology:** Wireless
- **Power Source:** Corded Electric

- **Speaker Maximum Output Power:** 100 Watts
- **Included Components:** Virtually Invisible 300 speakers (2), wireless surround speaker receivers, power supply, necessary cables.

WARRANTY & SUPPORT

The Bose Virtually Invisible 300 Wireless Surround Speakers come with a Limited Warranty. For detailed warranty information, product support, or to contact customer service, please visit the official Bose website or refer to the documentation included with your product.

You can also find additional support and resources by visiting the [Bose Store on Amazon](#).