



[Manuals.plus](#) /

› [Bose](#) /

› Bose Acoustimass 300 Wireless Bass Module User Manual

Bose 760093-1110

Bose Acoustimass 300 Wireless Bass Module User Manual

Model: 760093-1110

INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your Bose Acoustimass 300 Wireless Bass Module. Designed to enhance your home entertainment experience, this bass module delivers deep, dramatic sound when paired with compatible Bose sound systems.

SETUP

What's in the Box

- Acoustimass 300 wireless bass module

Placement

For optimal performance, place the Acoustimass 300 Wireless Bass Module in a location that allows for clear, unobstructed sound propagation. Consider placing it near a wall or in a corner to enhance bass response, but avoid placing it directly against a wall if the sound becomes too boomy.



Figure 1: Example placement of the Acoustimass 300 in a living room.

Connecting the Bass Module

The Acoustimass 300 is designed for wireless connection to a compatible Bose soundbar, such as the SoundTouch 300 soundbar. Ensure your soundbar is powered on and in setup mode.

1. **Power Connection:** Connect the power cord to the POWER port on the back of the bass module and then to a wall outlet.



Figure 2: Rear panel connections of the bass module.

2. **Wireless Pairing:** The bass module should automatically pair with your compatible Bose soundbar. A solid white light on the bass module indicates a successful connection.
3. **Manual Pairing (if needed):** If the bass module does not pair automatically, refer to your soundbar's user manual for specific instructions on manually pairing wireless accessories.

The bass module connects wirelessly for easier placement and integrates seamlessly with your existing Bose SoundTouch system.

OPERATING

Once connected, the Acoustimass 300 Wireless Bass Module operates in conjunction with your paired Bose soundbar. It automatically enhances the low-frequency audio output, providing a richer and more immersive listening experience for music, movies, and television.

Adjusting Bass Levels

Bass levels are typically controlled through the settings of your paired Bose soundbar or via the Bose SoundTouch app. Consult your soundbar's manual or the SoundTouch app interface for options to adjust bass intensity to your preference.



Figure 3: Front view of the Acoustimass 300.

MAINTENANCE

The Bose Acoustimass 300 Wireless Bass Module requires minimal maintenance to ensure long-lasting performance.

- **Cleaning:** Use a soft, dry cloth to clean the surface of the bass module. Do not use liquid cleaners, sprays, or solvents, as they may damage the finish.
- **Ventilation:** Ensure the bass module has adequate ventilation. Do not block any ventilation openings.
- **Placement:** Avoid placing the unit in direct sunlight or near heat sources.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from bass module	Not powered on or not paired.	Ensure power cord is securely connected. Check the status light on the bass module. If not solid white, re-initiate pairing process from your soundbar.
Distorted or weak bass	Improper placement or incorrect bass level settings.	Adjust bass levels via the SoundTouch app or soundbar settings. Experiment with different placements to find optimal bass response. Ensure no objects are obstructing the bass module.
Intermittent connection	Wireless interference or distance from soundbar.	Move the bass module closer to the soundbar. Avoid placing it near other wireless devices that may cause interference. Restart both the soundbar and bass module.

SPECIFICATIONS

Feature	Detail
Model Name	kkkk
Speaker Type	Subwoofer
Special Feature	Bass Boost
Recommended Uses	Music, Movies, Electrical
Compatible Devices	Smartphone, Tablet, MP3 Player, Desktop, Television, Projector, Laptop
Controller Type	App Control
Surround Sound Channel Configuration	5.1
Color	Black
Included Components	Acoustimass 300 wireless bass module
Product Dimensions	11.61"D x 11.61"W x 12.79"H
Item Weight	13.6 Kilograms (29.9 pounds)
Is Waterproof	FALSE
Number of Items	1
Control Method	App
Wireless Communication Technology	Bluetooth
Speaker Size	10 Inches
Power Source	Corded Electric
Woofer Diameter	12 Inches

Feature	Detail
Water Resistance Level	Not Water Resistant
Customer Package Type	Standard Packaging
Audio Driver Type	Dynamic Driver
Bluetooth Range	10 Meters
Audio Driver Size	12 Inches
Subwoofer Connectivity Technology	Wireless
Connectivity Protocol	Wi-Fi
Includes MP3 player?	No
Processor Count	2
Series Number	7600931110
UPC	779177311485 017817738705
Global Trade Identification Number	00017817738705, 00779177311485
Manufacturer	Bose Corporation
First Available	September 14, 2016
Brand	Bose
Speaker Maximum Output Power	300 Watts
Connectivity Technology	Bluetooth, Wi-Fi
Audio Output Mode	Surround
Mounting Type	Bar Mount,Floor Mount

Note: "kkkk" for Model Name is as provided in the source data.




Figure 4: Product dimensions.

WARRANTY AND SUPPORT

The Bose Acoustimass 300 Wireless Bass Module comes with a **Limited Warranty**. For detailed warranty information, product support, and service inquiries, please refer to the official Bose website or contact Bose customer service. An electronic version of the User Manual is available for download: [Download User Manual \(PDF\)](#)