

[Manuals.plus](#) /

› [Ravensburger](#) /

› Ravensburger Disney Castle 3D Jigsaw Puzzle (Model 12510) Instruction Manual

Ravensburger 12510

Ravensburger Disney Castle 3D Jigsaw Puzzle (Model 12510) Instruction Manual

216 Piece 3D Jigsaw Puzzle with Easy Click Technology

1. INTRODUCTION

Thank you for choosing the Ravensburger Disney Castle 3D Jigsaw Puzzle. This 216-piece puzzle is designed to create a stunning three-dimensional model of the iconic Disney Castle. Utilizing our unique Easy Click Technology, each piece is crafted for a precise fit, ensuring a stable and satisfying assembly experience. This manual provides comprehensive instructions to guide you through the setup, assembly, and care of your 3D puzzle.



Image: The fully assembled Ravensburger Disney Castle 3D Puzzle, showcasing its intricate details and vibrant colors.

2. WHAT'S IN THE BOX

Your Ravensburger Disney Castle 3D Jigsaw Puzzle package should contain the following items:

- 216 numbered puzzle pieces
- 96 accessory parts
- Instruction manual

3. SETUP

Before beginning assembly, ensure you have a clean, flat, and spacious workspace. This will allow you to sort pieces effectively and prevent loss. It is recommended to work on a surface that can accommodate the puzzle's dimensions (approximately 17.5 x 10.5 x 0.04 inches when flat, and a significant 3D structure).



Image: An icon representing the 216 puzzle pieces included in the set.

4. ASSEMBLY INSTRUCTIONS (OPERATING)

The Ravensburger Disney Castle 3D Puzzle uses Easy Click Technology, meaning pieces fit together precisely without the need for glue. The pieces are also numbered on the back for easier assembly, allowing you to follow a sequence or build by image recognition.

4.1 Sorting Pieces

1. Separate the 216 puzzle pieces from the accessory parts.
2. Sort the puzzle pieces by their numbers on the back. This can help in building sections sequentially.
3. Alternatively, sort pieces by color or distinct features to build sections based on the image.




Image: Puzzle pieces showing numbers on their reverse side, indicating a guided assembly process.

4.2 Assembling the Walls

1. Begin by connecting the base pieces, following the numbered sequence or the image on the box.
2. Continue building upwards, ensuring each piece clicks securely into place. The sturdy plastic pieces interlock perfectly to form a robust structure.
3. Pay attention to the orientation of the pieces to ensure the castle's imagery aligns correctly.



Image: A close-up of the sturdy plastic puzzle pieces, highlighting their quality and interlocking design.

4.3 Adding Accessory Parts and Towers

1. Once the main walls are constructed, attach the accessory parts as indicated in the detailed instructions provided within the box.
2. Assemble the towers separately, then integrate them into the main castle structure.
3. Ensure all connections are firm to maintain the 3D model's stability.



Image: A detailed view of a castle tower, featuring characters from Beauty and the Beast, demonstrating the intricate design.

4.4 Completion and Display

Upon successful assembly, your Ravensburger Disney Castle 3D Puzzle is ready for display. It is designed

to be a durable and attractive decorative piece.



Image: Two children engaged in assembling the Disney Castle 3D Puzzle, highlighting the enjoyable and interactive nature of the product.

4.5 Assembly Video

Watch the official Ravensburger video for a visual guide on assembling 3D puzzles and connecting with the brand's products.

Your browser does not support the video tag.

Video: An official Ravensburger video demonstrating the assembly process for their 3D puzzles and the brand experience.

5. MAINTENANCE

To ensure the longevity of your Ravensburger Disney Castle 3D Puzzle, follow these simple maintenance guidelines:

- **Cleaning:** Gently dust the assembled puzzle with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as these may damage the printed surface or the plastic pieces.
- **Storage:** If disassembling for storage, carefully separate the pieces to avoid bending or breaking. Store all pieces and accessory parts in their original box in a cool, dry place away from direct sunlight to prevent fading or warping.

6. TROUBLESHOOTING

Encountering issues during assembly? Here are some common problems and their solutions:

- **Pieces not fitting:**
 - Double-check the piece number on the back against the instructions or the surrounding pieces.
 - Ensure the piece is oriented correctly. Sometimes a slight rotation is needed.
 - Apply gentle, even pressure. Avoid forcing pieces, as this can cause damage.
- **Missing pieces:**
 - Thoroughly check your workspace, under furniture, and inside the box.
 - If a piece is genuinely missing, contact Ravensburger customer support with your product details.
- **Assembled sections are unstable:**
 - Ensure all pieces are fully clicked into place. Re-examine connections for any gaps.
 - Verify that accessory parts are correctly installed, as they contribute to structural integrity.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	17.5 x 10.5 x 0.04 inches (flat)
Item Weight	4 pounds
Model Number	12510
Manufacturer Recommended Age	12 years and up
Number of Pieces	216
Technology	Easy Click Technology

8. SAFETY INFORMATION

Warning: Not suitable for children under the age of 3 due to small parts which may present a choking hazard.

Always supervise young children during play to ensure safe use of the product.

9. WARRANTY AND SUPPORT

Ravensburger is committed to providing high-quality products. For any questions, concerns, or to report missing parts, please contact Ravensburger customer support. Refer to the packaging for specific contact information or visit the official Ravensburger website.

Please retain your proof of purchase for any warranty claims.