

Soundmaster UR190

Soundmaster UR190 Digital Clock Radio Instruction Manual

Model: UR190DBR

1. INTRODUCTION

Thank you for purchasing the Soundmaster UR190 Digital Clock Radio. This manual provides detailed instructions for the setup, operation, and maintenance of your device. Please read this manual thoroughly before use to ensure proper functionality and to maximize your listening experience.

2. SAFETY INFORMATION

- Ensure the power adapter voltage matches your local power supply.
- Do not expose the unit to rain, moisture, or extreme temperatures.
- Avoid placing the unit near heat sources or in direct sunlight.
- Do not open the casing; refer all servicing to qualified personnel.
- Keep the unit away from strong magnetic fields.
- Dispose of batteries responsibly according to local regulations.

3. PACKAGE CONTENTS

Please check that all items are present:

- Soundmaster UR190 Digital Clock Radio
- AC Power Adapter
- Instruction Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the controls and features of your Soundmaster UR190.



Figure 1: Front View of the Soundmaster UR190 Digital Clock Radio. This image displays the front of the radio, featuring a large speaker grille on the left, a digital display in the center, and two rotary knobs for 'VOLUME' and 'SELECT' functions. The 'Soundmaster' logo is visible above the display. The unit has a brown wood-grain finish with a light-colored bezel.

Front Panel Controls:

- **Volume Knob:** Rotate to adjust audio volume. Press to mute/unmute.
- **Select Knob:** Rotate to navigate menus or tune radio stations. Press to confirm selections.
- **Digital Display:** Shows time, date, radio station information, and menu options.
- **Speaker Grille:** Audio output.

Top Panel Controls:

- **Buttons (e.g., Preset, Mode, Alarm):** Specific functions for radio presets, changing modes (DAB+/FM), and alarm settings.
(Note: Exact button labels are not visible in the provided image, refer to your unit for precise labels)

Rear Panel / Side Panel:

- **Power Input:** Connect the AC power adapter here.
- **USB Charging Port:** For charging external devices.
- **Battery Compartment:** For backup batteries (1 AAA battery required).
- **Antenna:** For radio reception.

5. SETUP

5.1 Power Connection

1. Connect the supplied AC power adapter to the DC IN port on the back of the unit.

2. Plug the adapter into a standard wall outlet.
3. The unit will power on or enter standby mode.

5.2 Battery Backup

To retain time and alarm settings during a power outage, install a backup battery.

1. Locate the battery compartment on the unit.
2. Insert 1 AAA battery, observing the correct polarity (+/-).
3. Close the battery compartment cover securely.

5.3 Initial Setup (First Use)

Upon first power-on, the unit may prompt you to set the language, time, and date. Follow the on-screen instructions using the **Select Knob** to navigate and confirm.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

Press the **Power** button (usually on the top panel) to turn the unit on or off (standby mode).

6.2 Radio Operation (DAB+/FM/PLL)

1. Press the **Mode** button to switch between DAB+, FM, or other available radio modes.
2. **Auto Scan:** In DAB+ or FM mode, press and hold the **Select Knob** to initiate an auto-scan for available stations.
3. **Manual Tuning:** Rotate the **Select Knob** to manually tune to a frequency.
4. **Saving Presets:** Once a station is tuned, press the **Preset** button (if available) and use the **Select Knob** to choose a preset number, then press again to save.
5. **Recalling Presets:** Press the **Preset** button briefly and use the **Select Knob** to select a saved station.

6.3 Setting the Clock and Date

If not set during initial setup, or to adjust:

1. In standby mode, press and hold the **Time Set** or **Menu** button.
2. Use the **Select Knob** to adjust hours, minutes, day, month, and year.
3. Press the **Select Knob** to confirm each setting.

6.4 Setting Alarms (Dual Alarm Function)

The UR190 features a dual alarm function, allowing two separate alarm times.

1. Press the **Alarm 1** or **Alarm 2** button.
2. Use the **Select Knob** to set the desired alarm time (hour and minute). Press to confirm.
3. Select the alarm source: **Buzzer** or **Radio**. If Radio, select the desired station.
4. Choose the alarm frequency: Daily, Weekdays, Weekends, or Once.
5. Confirm all settings. The alarm icon will appear on the display.

6.5 Snooze and Alarm Off

- **Snooze:** When the alarm sounds, press the **Snooze** button (often a large button on top) to temporarily silence it for a few minutes.
- **Alarm Off:** To turn off the alarm completely, press the **Alarm 1** or **Alarm 2** button again, or the **Power** button.

6.6 USB Charging Port

Connect your mobile device's USB charging cable to the USB port on the unit to charge it. Note that charging speed may vary depending on the device.

6.7 Display Dimmer

Press the **Dimmer** button (if available) or navigate through the menu settings to adjust the brightness of the digital display.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the unit. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the unit for an extended period, disconnect it from power and remove the backup battery.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power adapter not connected or faulty outlet.	Check power connections. Try a different outlet.
Poor radio reception	Antenna not extended or weak signal.	Extend the antenna fully. Reposition the unit for better signal.
Alarm does not sound	Alarm not activated or volume too low.	Ensure alarm is set and enabled. Increase volume.
Display is blank	Unit is off, in standby, or display dimmer is set to minimum.	Press Power button. Adjust display dimmer setting.

9. SPECIFICATIONS

Brand	Soundmaster
Model	UR190DBR
Display Type	Digital
Radio Bands Supported	DAB+, FM, PLL
Special Features	Alarm, Charging Port, Radio
Power Source	AC (Corriente alterna), Battery (Batería)
Battery Requirement	1 AAA battery (for backup)
Hardware Interface	3.5mm Audio, USB
Product Dimensions	20.9 x 12.3 x 12.2 cm
Item Weight	0.8 Kilograms
Colour	Brown

10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Soundmaster website. Keep your proof of purchase for warranty claims.

Related Documents - UR190

	soundmaster UR190 DAB/FM Radio Bedienungsanleitung Umfassende Bedienungsanleitung für das soundmaster UR190 Digitalradio mit DAB+/FM-Empfang und USB-Ladefunktion. Enthält Anleitungen zur Einrichtung, Bedienung und Wartung.
	Soundmaster FUR4005 Radio Alarm Clock User Manual Comprehensive user manual for the Soundmaster FUR4005 radio alarm clock, detailing setup, operation, safety guidelines, specifications, and manufacturer information.
	Soundmaster DAB700 User Manual Comprehensive user manual for the Soundmaster DAB700 digital radio, covering installation, operation, features like DAB/FM radio, Bluetooth, USB/Micro SD playback, alarm, sleep timer, and technical specifications.
	soundmaster UR8800 Digitaluhr Bedienungsanleitung Bedienungsanleitung für die soundmaster UR8800 Digitaluhr, mit Details zu Einrichtung, Funktionen, Bedienung, Sicherheit und technischen Spezifikationen. Erfahren Sie, wie Sie Zeit, Alarmer und Display einstellen.
	soundmaster FUR5005: Bedienungsanleitung und Bedienungshinweise Umfassende Bedienungsanleitung für das soundmaster FUR5005 Radiowecker. Enthält Informationen zu Einrichtung, Bedienung, Alarmfunktionen, Sicherheitshinweisen und Umweltschutz.



[Soundmaster FUR6005: Ihr moderner Radiowecker mit Projektion](#)

Entdecken Sie die Funktionen der Soundmaster FUR6005, einer Funk-Uhr mit Projektion, Alarm, Schlummerfunktion und Infrarotsensor. Erfahren Sie mehr über die einfache Bedienung und Installation.

Documents - Soundmaster – UR190



[\[pdf\] User Manual](#)

Provided by ManualsAndMore Download User Manual SOUNDMASTER UR180 Instruction manualsandmore |||

DEUTSCH ENGLISH FRANCAIS NEDERLANDS ITALIANO NORSK SVENSKA
DANSK CESTINA Hersteller Wrllein GmbH Gewerbestrasse 12 D 90556 Cadolzburg
GERMANY Tel.: 49 9103/71670 Fax.: 49 9103/716712 Email: info@woerlein.com Web:
www.woerlein.com **UR190** ENVIRONMENTAL PROTECTION Do not dispose of this
product wi...

lang:en score:45 filesize: 1.14 M page_count: 14 document date: 2019-07-23



[soundmaster UR190 DAB/FM Radio Bedienungsanleitung](#)

Umfassende Bedienungsanleitung für das soundmaster UR190 Digitalradio mit DAB+/FM-Empfang und USB-Ladefunktion. Enthält Anleitungen zur Einrichtung, Bedienung und Wartung.

lang:de score:31 filesize: 8.05 M page_count: 127 document date: 2021-05-26



[pdf]

LOCATION OF CONTROLS alina BDA UR190DBR 20877 soundmaster de media woerlein Manuals
 DEUTSCH ENGLISH FRANCAIS NEDERLANDS ITALIANO NORSK SVENSKA
 DANSK CESTINA Hersteller Wrlain GmbH Gewerbestrasse 12 D 90556 Cadolzburg
 GERMANY Tel.: 49 9103/71670 Fax.: 49 9103/716712 Email. info woerlein.com Web:
 www.woerlein.com **UR190** Dieses Symbol zeigt an, dass im Inneren des Gertes
 gefhrli...

lang:de score:29 filesize: 8.05 M page_count: 127 document date: 2021-05-26



[pdf]

LOCATION OF CONTROLS alina gebruiksaanwijzing soundmaster ur190 de en fr nl it no se dk cz 1
 gizmo retail pub media product g e |||
 DEUTSCH ENGLISH FRANCAIS NEDERLANDS ITALIANO NORSK SVENSKA
 DANSK CESTINA Hersteller Wrlain GmbH Gewerbestrasse 12 D 90556 Cadolzburg
 GERMANY Tel.: 49 9103/71670 Fax.: 49 9103/716712 Email. info woerlein.com Web:
 www.woerlein.com **UR190** Dieses Symbol zeigt an, dass im Inneren des Gertes
 gefhrli...

lang:de score:26 filesize: 9.27 M page_count: 126 document date: 2016-08-17



[pdf]

Náhled * souboru s návodem k obsluze NÁVOD K OBSLUZE Radiopřijímač DAB Soundmaster
 UR190WE šedý Databáze návodů v češtině radioprijimac dab soundmaster ur190we sedy 113341 locked
 navod cz preview 114 |||
 DEUTSCH ENGLISH FRANCAIS NEDERLANDS ITALIANO NORSK SVENSKA
 DANSK CESTINA Hersteller Wrlain GmbH Gewerbestrasse 12 D 90556 Cadolzburg
 GERMANY Tel.: 49 9103/71670 Fax.: 49 9103/716712 Email. info woerlein.com Web:
 www.woerlein.com **UR190** Dieses Symbol zeigt an, dass im Inneren des Gertes
 gefhrli...

lang:de score:17 filesize: 875.5 K page_count: 4 document date: 2023-08-15



[\[pdf\]](#) Declaration of Conformity

soundmaster 2021 niwotron ch index cfm action act getfile doc id 101817 |||

electronic 2021/22 Nachhaltigkeit sustainability Nachhaltig und verantwortungsvoll zu arbeiten, ... Aux In Jack Headphone Jack Emergency Use with 4 x AAA Batteries not incl. AC Adaptor included **UR190WE** 12 www.soundmaster.de **UR190DBR** **UR190** DAB /UKW Uhrenradio mit USB-Ladebuchse DAB /FM Clock...

lang:en **score:15** filesize: 15.12 M page_count: 60 document date: 2021-04-12




[\[pdf\]](#) Borchure Catalog

hier Merken Gizmo Retail Soundmaster catalogus 2021 2022 gizmo retail nl media wysiwyg Brochures |||

electronic 2021/22 Nachhaltigkeit sustainability Nachhaltig und verantwortungsvoll zu arbeiten, ... Aux In Jack Headphone Jack Emergency Use with 4 x AAA Batteries not incl. AC Adaptor included **UR190WE** 12 www.soundmaster.de **UR190DBR** **UR190** DAB /UKW Uhrenradio mit USB-Ladebuchse DAB /FM Clock...

lang:en **score:15** filesize: 11.48 M page_count: 60 document date: 2021-06-28



[\[pdf\]](#) Borchure Catalog

electronic gizmo retail nl Unsere hauseigene Servicewerkstatt hat nahezu 100 % aller Ersatzteile auch für Altgeräte auf Lager ein Gerät einfach als Müll Es wird k Soundmaster catalogus 2020 2021 pub media wysiwyg Brochures |||

electronic 2020/21 Nachhaltigkeit sustainability Nachhaltig und verantwortungsvoll zu arbeiten, ... 1 x 4W RMS AC Adaptor 5V/1A included Tel. 49 0 91 03 - 71 67-0 13 Uhrenradios Clock radios **UR190WE** **UR190DBR** **UR190** DAB /UKW Uhrenradio mit USB-Ladebuchse DAB /FM Clock Radio with USB Chargi...

lang:en **score:13** filesize: 9.89 M page_count: 56 document date: 2020-03-23



[\[pdf\]](#) Decleration of Conformity

electronic Gizmo Retail Unsere hauseigene Servicewerkstatt hat nahezu 100 % aller Ersatzteile auf Lager auch für Altgeräte Es wird kein Gerät einfach als Müll soundmaster 2020 niwotron ch index cfm action act getfile doc id 101650 |||

electronic 2020/21 Nachhaltigkeit sustainability Nachhaltig und verantwortungsvoll zu arbeiten, ... 1 x 4W RMS AC Adapter 5V/1A included Tel. 49 0 91 03 - 71 67-0 13

Uhrenradios Clock radios **UR190WE UR190DBR UR190** DAB /UKW Uhrenradio mit USB-Ladebuchse DAB /FM Clock Radio with USB Chargi...

lang:en **score:13** filesize: 14.47 M page_count: 56 document date: 2020-03-23



[\[pdf\]](#)

Herunterladen Pro AV Multimedia Audio Radio Streaming Radios Soundmaster SCD2120GR Grün NewStore GmbH Support index dispatch attachments getfile attachment id 6465 shop newstore ch |||

50 Jahre electronic 2018/19 Inhalt 2018/19 2 www.woerlein.com Bluetooth DAB

Internet 2018 ... RMS DC 6V 4x UM-3/AA 1.5V Batteries batteries not included

AC/DC adapter included DAB600DBR **UR190DBR UR190** DAB / UKW Uhrenradio mit USB Ladebuchse DAB / FM Clock Radio with USB Charging Socke...

lang:de **score:12** filesize: 9.26 M page_count: 68 document date: 2018-02-15