



Manuals.plus /

› Pathline Products /

› Pathline Products Fireplace Glass Doors for Marco Fireplace (Silver Finish) Instruction Manual

Pathline Products Marco Fireplace Glass Doors

Pathline Products Fireplace Glass Doors for Marco Fireplace (Silver Finish) Instruction Manual

Model: Marco Fireplace Glass Doors

PRODUCT OVERVIEW

These Pathline Products Fireplace Glass Doors are designed to fit specific Marco fireplace units, offering both aesthetic enhancement and functional benefits. The doors feature a brushed stainless finish and are constructed with durable materials to provide a secure enclosure for your fireplace.

- **Compatibility:** Designed for Marco fireplace units, including models B41CF, B41HC, B41HCI, D41, 792794, 792795, 792796, 792797, 792847, 792848, 792849, 792851, 792857, 792861, 792862, 792863, 792864.
- **Finish Options:** Available in Silver (Brushed Stainless) and Black.
- **Safety:** Includes mesh screens for ember containment.



Image: Pathline Products Fireplace Glass Doors in a brushed silver finish, installed in a stone fireplace. The glass doors are closed, showing the interior of the firebox.

IMPORTANT COMPATIBILITY INFORMATION

It is crucial to verify your fireplace model number before ordering. These doors are specifically designed for the Marco units listed below and will not fit other models. The model number, brand, and date of manufacture can often be found on a tag located on the inside sheet metal wall of the firebox. Location of this tag may vary.



WARNING!

This replacement door set is only made to fit:

Brand:

Marco

Model #'s

**B41CF, B41HC, B41HCI,
D41, 792794, 792795,
792796, 792797, 792847,
792848, 792849, 792851,
792857, 792861, 792862,
792863, 792864**

Image: A visual guide indicating the location of a fireplace model number on a rating plate, alongside a list of compatible Marco fireplace models.

SETUP AND INSTALLATION

Installation of the fireplace glass doors typically involves securing the frame to the existing fireplace opening. While the product is designed for straightforward installation, it is recommended to have two people for the process due to the weight and size of the unit. The doors are generally fully assembled, requiring only the attachment of handles and securing the unit in place.

Installation Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components listed in the package contents are present.
2. **Prepare Fireplace Opening:** Ensure the fireplace opening is clean and free of debris.
3. **Position the Frame:** Carefully lift and position the door frame into the fireplace opening.
4. **Secure the Frame:** Use the provided hardware to secure the frame to the fireplace. Adjustable brackets are typically used to ensure a snug fit.
5. **Attach Handles:** Install the door handles onto the glass doors.
6. **Final Adjustments:** Check that the doors open and close smoothly and that the mesh screens operate correctly.

Installation Video Resources:

Video: A seller-provided video demonstrating the installation process for fireplace screens with doors. This video shows the unboxing, measuring, and securing of the fireplace screen.

Your browser does not support the video tag.

For additional installation guidance, you may refer to external resources such as <https://youtu.be/6JVdCl6X-7Y>.

OPERATING INSTRUCTIONS

The fireplace glass doors are designed for ease of use and safety. They feature both glass doors and internal mesh screens.

- **Opening/Closing Glass Doors:** Use the handles to gently open and close the glass doors. The doors are typically bi-folding or cabinet-style, allowing for a wide opening.
- **Using Mesh Screens:** The internal mesh screens are crucial for safety when a fire is burning. Always ensure the mesh screens are closed to contain embers and sparks. These screens often have magnetic catches for secure closure.
- **Fire Operation:** When a fire is active, keep the glass doors open and the mesh screens closed. This allows for proper ventilation while preventing sparks from escaping. Once the fire has completely died down and cooled, the glass doors can be closed to reduce heat loss and prevent drafts.



Image: Fireplace glass doors with the glass panels folded open, revealing the internal mesh screens which are closed, with a fire burning inside the fireplace.

MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your fireplace glass doors.

- **Glass Cleaning:** Clean the glass panels regularly to remove soot and grime. Use a specialized fireplace glass cleaner or a mixture of vinegar and water. Avoid abrasive cleaners that can scratch the glass. Ensure the fireplace is completely cool before cleaning.
- **Frame Cleaning:** Wipe down the metal frame with a soft, damp cloth to remove dust and ash. For stubborn stains, a mild soap solution can be used. Dry thoroughly to prevent rust.

- **Mesh Screen Inspection:** Periodically inspect the mesh screens for any tears, holes, or damage. Damaged screens should be repaired or replaced immediately to maintain safety.
- **Hinge and Latch Check:** Ensure hinges and latches operate smoothly. Apply a small amount of high-temperature lubricant if necessary.

TROUBLESHOOTING

If you encounter issues with your fireplace glass doors, consider the following:

- **Doors Not Fitting Correctly:** Double-check your fireplace model number against the compatible list. Ensure the installation brackets are properly adjusted and tightened.
- **Air Leakage:** If air is still escaping around the doors, ensure the frame is securely sealed against the fireplace opening. Some models may benefit from additional high-temperature sealant if gaps are present.
- **Sticking Doors/Screens:** Clean hinges and tracks thoroughly. Apply a high-temperature lubricant if friction persists. Ensure no debris is obstructing the movement.
- **Damaged Glass/Mesh:** For safety, any damaged glass or mesh screens should be replaced immediately. Contact customer support for replacement parts.

SPECIFICATIONS

Brand	Pathline Products
Model Compatibility	Marco units: B41CF, B41HC, B41HCI, D41, 792794, 792795, 792796, 792797, 792847, 792848, 792849, 792851, 792857, 792861, 792862, 792863, 792864
Material	Glass, Metal (Steel)
Finish Type	Brushed Stainless (Silver) or Black
Style	Modern
First Available Date	August 29, 2016
Manufacturer	Burgess Manufacturing Corporation

WARRANTY AND SUPPORT

While specific warranty details for this exact product are not provided, similar fireplace glass doors often come with **one-year limited warranty** covering manufacturing defects. Please refer to the product packaging or contact Pathline Products directly for precise warranty information and customer support.

For any questions, technical assistance, or to inquire about replacement parts, please contact Pathline Products customer service.