

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [NutriChef](#) /

› [NutriChef PKAIRFR48 Infrared Convection Halogen Oven Air Fryer Instruction Manual](#)

## NutriChef PKAIRFR48

# NutriChef PKAIRFR48 Infrared Convection Halogen Oven Air Fryer Instruction Manual

Model: PKAIRFR48

## INTRODUCTION

---

The NutriChef PKAIRFR48 Halogen Oven Air Fryer is a versatile countertop appliance designed for healthier cooking. Utilizing infrared convection technology, it allows you to prepare a variety of meals with little to no added oil. This manual provides essential information for safe and efficient operation, maintenance, and care of your new appliance.

## IMPORTANT SAFETY INSTRUCTIONS

---

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Always use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended household use.
- A warning label is present on the appliance indicating 'Hot Surface Area - Do Not Touch'. Possible burning could occur if contact is made.

## PRODUCT COMPONENTS


---

Your NutriChef Air Fryer comes with several components designed to enhance your cooking experience:


# WHAT'S IN THE BOX?



Air Fryer



Food Rack & Tongs



Cooking Rack



Power Cord

**Image:** The main air fryer unit, a food rack, a cooking basket, and the power cord. These are the essential items included in the box.

- **Air Fryer Unit:** The main appliance with the heating element and control panel.
- **Cooking Bowl:** A large, transparent glass bowl with a capacity of 13+ quarts.
- **Food Rack & Tongs:** For holding food during cooking and safe handling.
- **Cooking Basket:** A mesh basket for air frying smaller items like fries.
- **Power Cord:** For connecting the appliance to an electrical outlet.

## SETUP

Before first use, ensure all packaging materials are removed. Place the air fryer on a stable, heat-resistant surface. Insert the desired cooking accessory (food rack or cooking basket) into the glass bowl. The glass bowl sits securely in its base.

## OPERATING INSTRUCTIONS

The NutriChef Air Fryer is designed for simple and efficient operation.

### Basic Operation: Time and Temperature Controls

# AIR-FRYING MADE EASY

Insert Food, Set the Time & Temp



High Powered Heating  
Element: 1200 Watt



Temperature Settings:  
149°F - 482°F



Maximum Time Setting:  
60 Minutes



**Image:** The control panel features two rotary dials for setting time (up to 60 minutes) and temperature (149°F - 482°F), along with Power and Heat indicator lights.

1. **Place Food:** Insert your food into the cooking bowl with the appropriate accessory.
2. **Set Temperature:** Use the 'Temp' dial to select your desired cooking temperature (range: 149°F - 482°F).
3. **Set Time:** Use the 'Time' dial to set the cooking duration (up to 60 minutes). The appliance will automatically turn off when the timer expires.
4. **Start Cooking:** Ensure the handle is in the 'down' position to activate the heating element. The Power and Heat indicator lights will illuminate.

## Versatile Cooking Functions

Your air fryer is capable of multiple cooking methods:



Defrost



Roast



Steam



Broil



Bake



Grill



Barbecue



## HALOGEN OVEN AIR FRYER

7 Preset Cooking  
Settings

**Image:** Visual representation of the air fryer's capabilities, including defrosting frozen vegetables, roasting a whole chicken, steaming green beans, broiling shrimp, baking cake, grilling ribs, and barbecuing chicken wings.

- **Defrost:** Thaw frozen foods quickly and efficiently.
- **Broil:** Achieve a crispy, browned finish.
- **Roast:** Perfect for meats and vegetables.
- **Bake:** Prepare cakes, pastries, and more.
- **Steam:** Cook vegetables and other delicate foods.
- **Grill:** Ideal for meats, poultry, and fish.
- **BBQ:** For a smoky, grilled flavor.

### Rapid Air Circulation

The built-in convection oven-style vortex fan ensures rapid air circulation, cooking food evenly and thoroughly from all sides. This results in perfectly crisped exteriors and moist interiors.

# RAPID AIR CIRCULATION

For Even Cooking All Around



Oven-Style  
Vortex Fan



**nutrichef**<sup>™</sup>

**Image:** An illustration demonstrating the internal airflow, highlighting how the oven-style vortex fan distributes heat for even cooking.

## Automatic Power-Off Feature

For safety and convenience, the appliance features an automatic power-off function. Lifting the handle will automatically turn off the heating element, and closing the handle will resume cooking (if time remains on the timer).

# HEALTHIER MEALS, QUICKER!

Cooking Bowl Capacity: 13+ Quart



Handle Open to  
Automatically  
Turn Off



Handle Close to  
Automatically  
Turn On

**Image:** Two diagrams illustrating the handle mechanism: 'Handle Open to Automatically Turn Off' and 'Handle Close to Automatically Turn On'.

## Cooking Bowl Capacity

The generous 13+ quart capacity of the cooking bowl allows for preparing large meals, such as a whole chicken or a substantial batch of fries, making it suitable for families or meal prepping.

## HEALTHY COOKING BENEFITS

The NutriChef Air Fryer utilizes halogen infrared convection technology, which significantly reduces the need for added oils. This method prepares healthier meals compared to traditional frying, resulting in tasty, low-fat foods with crispy skins and juicy interiors.

## CLEANING AND MAINTENANCE

The appliance is designed for easy cleaning.

# STAIN RESISTANT & EASY-TO-CLEAN

Removable Stainless Steel Cooking Bowl



**Image:** The removable glass cooking bowl and metal racks are shown, emphasizing their stain-resistant properties and ease of cleaning, including being dishwasher safe.

- **Removable Bowl:** The stainless steel cooking bowl is stain-resistant and can be easily removed for cleaning.
- **Accessories:** All removable accessories, including racks and baskets, are dishwasher-safe for convenient cleanup.
- **Main Unit:** Wipe the main unit with a damp cloth. Do not immerse the main unit in water.
- **Self-Cleaning Function:** Some models may feature a 'Thaw Wash' setting on the temperature dial. To use, fill the bowl with water up to the rack level, add a small amount of dish soap, set the temperature to 'Thaw Wash', and run for approximately 10 minutes. This helps to loosen grease and food residue.

## SPECIFICATIONS

<b>Brand</b>	NutriChef
<b>Model Name</b>	NutriChef Air Fryer
<b>Item Model Number</b>	PKAIRFR48
<b>Color</b>	White

<b>Power Source</b>	Electric (120V)
<b>Heating Element</b>	1200 Watt
<b>Temperature Settings</b>	149°F - 482°F (65°C - 250°C)
<b>Max Cook Time Setting</b>	60 Minutes
<b>Cooking Bowl Capacity</b>	13+ Quarts (12.3 Liters)
<b>Cooking Bowl Size (L x H)</b>	13.0" x 6.7" inches
<b>Product Dimensions</b>	8.9"D x 14"W x 13.5"H
<b>Item Weight</b>	12.5 pounds
<b>Control Type</b>	Knob, Touch
<b>Special Features</b>	Programmable, Stain Resistant, Temperature Control, Timer

## TROUBLESHOOTING

---

If the appliance does not turn on, ensure it is properly plugged into a working outlet and the handle is in the 'down' (cooking) position. If the heating element or fan malfunctions, contact customer support.

## WARRANTY AND SUPPORT

---

Your NutriChef Air Fryer comes with a one-year manufacturer's warranty, covering defects in materials and workmanship. For warranty claims or technical support, please contact NutriChef customer service. Keep your purchase receipt as proof of purchase.

## PRODUCT VIDEOS

---

### NutriChef Air Fryer Overview

Your browser does not support the video tag.

**Video Description:** This video provides a general overview of the NutriChef Air Fryer, highlighting its features and ease of use for preparing various dishes.

### NutriChef Air Fryer Features and Cooking

Your browser does not support the video tag.

**Video Description:** A detailed look at the NutriChef Air Fryer (PKAIRFR48), showcasing its infrared convection cooking capabilities and how it prepares healthy meals.

### NutriChef Air Fryer PKAIRFR48 Demonstration

Your browser does not support the video tag.

**Video Description:** This video demonstrates the NutriChef Air Fryer model PKAIRFR48 in action, highlighting its cooking process and results.