

[Manuals.plus](#) /

› [RYGHT](#) /

› Ryght Pocket 2 Portable Bluetooth Outdoor Speaker User Manual

RYGHT R482648

Ryght Pocket 2 Portable Bluetooth Outdoor Speaker User Manual

Model: R482648

INTRODUCTION

Welcome to the user manual for your Ryght Pocket 2 Portable Bluetooth Outdoor Speaker. This compact and powerful speaker is designed for mobile use, offering high-quality sound and robust features for your on-the-go lifestyle. Please read this manual carefully to ensure proper use and maintenance of your device.

IMPORTANT SAFETY INFORMATION

- Avoid exposing the speaker to extreme temperatures (hot or cold) or direct sunlight for prolonged periods.
 - Do not attempt to disassemble, repair, or modify the speaker yourself. This will void the warranty and may cause damage.
 - Keep the speaker away from strong magnetic fields.
 - Use only the provided charging cable. Using unauthorized cables may damage the speaker or battery.
 - While the speaker is IPX6 rated for water resistance, do not submerge it in water. Ensure the port cover is securely closed before exposure to water.
 - Keep out of reach of children.
-

PACKAGE CONTENTS

Please check that all items are present in your package:




Image: All components included with the Ryght Pocket 2 speaker.

- Ryght Pocket 2 Bluetooth Speaker
- Micro USB Charging Cable
- 3.5mm Jack Audio Cable
- Carabiner
- Suction Cup Mount
- Bike Handlebar Mount
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the various parts and controls of your Ryght Pocket 2 speaker.



Image: Front view of the Ryght Pocket 2 speaker.



Image: Side view of the Ryght Pocket 2 speaker revealing the charging and audio input ports.

Controls and Ports

- **Power Button:** Press and hold to turn the speaker on or off.
 - **Volume Up (+):** Short press to increase the volume.
 - **Volume Down (-):** Short press to decrease the volume.
 - **Multi-function Button (Y-logo):** Press once to Play/Pause music or Answer/End a call. Press and hold to activate Bluetooth pairing mode.
 - **Micro USB Port:** Used for charging the speaker's internal battery.
 - **3.5mm Audio Jack:** For connecting audio devices via a wired connection.
 - **Microphone:** Integrated for hands-free calling functionality.
-

SETUP

Charging the Speaker

1. Connect the Micro USB cable to the speaker's charging port.
2. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will illuminate to show charging status. A full charge takes approximately 1.5 hours.
4. For the first use, it is recommended to charge the speaker for 3 hours to optimize battery performance.

Bluetooth Pairing

1. Ensure the speaker is charged and turned off.
2. Press and hold the Power button to turn on the speaker. It will automatically enter pairing mode, indicated by a flashing LED.
3. On your smartphone, tablet, or other Bluetooth-enabled device, enable Bluetooth.
4. Search for "Ryght Pocket 2" in the list of available devices.
5. Select "Ryght Pocket 2" to pair. Once successfully paired, the LED indicator will stop flashing and remain solid.
6. The speaker has a Bluetooth operating range of up to 10 meters (33 feet).

Wired Connection

1. Connect one end of the 3.5mm audio jack cable to the speaker's audio input port.
 2. Connect the other end to the audio output of your device (e.g., smartphone, MP3 player).
 3. The speaker will automatically switch to wired mode when the cable is connected.
-

OPERATING INSTRUCTIONS

Music Playback

- **Play/Pause:** Press the Multi-function button once.
- **Next Track:** Press and hold the Volume Up (+) button.
- **Previous Track:** Press and hold the Volume Down (-) button.

- **Volume Control:** Short press the Volume Up (+) or Volume Down (-) buttons to adjust the volume.

Hands-Free Calling

- **Answer Call:** Press the Multi-function button once when an incoming call rings.
- **End Call:** Press the Multi-function button once during an active call.
- **Reject Call:** Press and hold the Multi-function button when a call comes in.

Mounting Options

The Ryght Pocket 2 comes with versatile mounting accessories to suit various activities.



Image: Ryght Pocket 2 speaker mounted on a bicycle handlebar.



Image: Ryght Pocket 2 speaker attached to a backpack using the included carabiner.

- **Carabiner:** Use the included carabiner to easily attach the speaker to your backpack, belt loop, or other convenient locations.
- **Suction Cup:** Screw the suction cup into the universal screw thread on the back of the speaker. Attach it to smooth, flat surfaces like glass, tiles, or shower walls.
- **Bike Mount:** Secure the bike mount to your bicycle handlebar and then screw the speaker onto the mount for on-the-go music during rides.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your Ryght Pocket 2 speaker, follow these care instructions:



Image: The Ryght Pocket 2 speaker showing its IPX6 water resistance.

- **Cleaning:** Wipe the speaker with a soft, slightly damp cloth. Do not use harsh chemicals, abrasive cleaners, or solvents, as they may damage the surface.
 - **Water Resistance (IPX6):** The speaker is protected against powerful water jets. However, it is not designed for submersion. Always ensure the rubber port cover is securely closed before exposing the speaker to water or moisture.
 - **Storage:** When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.
 - **Battery Care:** To preserve battery life, fully charge the speaker before long periods of storage. Avoid completely draining the battery frequently.
-

TROUBLESHOOTING

If you encounter any issues with your Ryght Pocket 2 speaker, please refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is low or depleted.	Charge the speaker for at least 1.5 hours. Ensure the charging cable is properly connected.
Cannot pair with Bluetooth device.	Speaker is not in pairing mode; Bluetooth is off on your device; Device is out of range.	Ensure the speaker's LED is flashing (indicating pairing mode); Turn on Bluetooth on your device; Move your device closer to the speaker (within 10m).
No sound.	Volume is too low on speaker or device; Incorrect input mode; Device not playing audio.	Increase speaker and device volume; Ensure correct connection (Bluetooth or 3.5mm jack); Check if music or audio is playing on your connected device.
Sound distortion.	Volume is too high; Device is too far from speaker or signal interference.	Reduce the volume on both the speaker and your device; Move your device closer to the speaker; Avoid obstacles between the speaker and device.
Call quality is poor.	Microphone obstructed; Weak Bluetooth signal.	Ensure the microphone area is clear; Move closer to the connected device to improve signal strength.

TECHNICAL SPECIFICATIONS



Image: Dimensions of the Ryght Pocket 2 speaker.

- **Model:** R482648
- **Output Power:** 5W RMS
- **Frequency Response:** 80Hz - 20KHz
- **Signal-to-Noise Ratio (SNR):** 80 dBA
- **Battery Type:** Lithium-ion polymer
- **Battery Capacity:** 800mAh - 3.7V

- **Charging Time:** Approximately 1.5 hours
- **Playback Time:** Up to 8 hours
- **Bluetooth Range:** Up to 10 meters (33 feet)
- **Water Resistance:** IPX6 (Protected against powerful water jets)
- **Dimensions:** 100 x 65 x 45 mm (approx. 3.94 x 2.56 x 1.77 inches)
- **Weight:** 137 g (approx. 4.83 oz)
- **Connectivity:** Bluetooth, 3.5mm Audio Jack
- **Microphone:** Integrated for hands-free calls
- **Material:** Plastic and Metal

WARRANTY AND SUPPORT

Your Ryght Pocket 2 speaker is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions regarding warranty duration and coverage.

For technical support, troubleshooting assistance, or warranty claims, please contact your local retailer or visit the official Ryght website.

Website: www.ryght.com (Note: This is a placeholder URL, please refer to your product packaging for the correct support contact information.)

Manufacturer: Mobility Lab

Country of Origin: China

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B01LA5MQZA>

More documents and user manuals: **<https://manuals.plus/>**