

[manuals.plus](#) /

› [Logitech](#) /

› [Logitech B330 Silent Plus Wireless Optical Mouse User Manual](#)

Logitech 910-004913

Logitech B330 Silent Plus Wireless Optical Mouse User Manual

Model: 910-004913

INTRODUCTION

This manual provides comprehensive instructions for setting up, operating, and maintaining your Logitech B330 Silent Plus Wireless Optical Mouse. Designed for comfort and quiet operation, this mouse offers reliable wireless connectivity for an enhanced computing experience.



Image: Logitech B330 Silent Plus Wireless Optical Mouse. This image displays the sleek black design of the mouse, highlighting its ergonomic shape and the prominent Logitech branding. A small green LED indicator is visible near the scroll wheel, indicating power or connection status. The side of the mouse features a

SETUP

1. Battery Installation

The Logitech B330 mouse requires one AA battery for operation. Follow these steps to install the battery:

1. Locate the battery compartment cover on the underside of the mouse.
2. Slide or lift the cover to open the compartment.
3. Insert one AA battery, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Replace the battery compartment cover until it clicks securely into place.

2. Connecting to Your Computer

The mouse connects wirelessly via a USB receiver. Follow these steps to establish a connection:

1. Locate the USB receiver, typically stored inside the battery compartment of the mouse.
2. Plug the USB receiver into an available USB port on your computer.
3. Turn on the mouse using the On/Off switch, usually located on the underside of the mouse.
4. Your computer should automatically detect and install the necessary drivers. The mouse will be ready for use once the installation is complete.

Note: For optimal performance, ensure the mouse is within a reasonable range of the USB receiver and free from major obstructions.

OPERATING THE MOUSE

The Logitech B330 Silent Plus mouse is designed for intuitive and comfortable use. Its silent click feature minimizes noise, making it ideal for quiet environments.

- **Left-Click Button:** Used for selecting items, opening files, and activating functions.
- **Right-Click Button:** Used for accessing context menus and additional options.
- **Scroll Wheel:** Roll the wheel up or down to scroll through documents and web pages. The scroll wheel can also be pressed down for a middle-click function, often used to open links in new tabs.

The ergonomic design provides a comfortable grip, reducing strain during extended use. The optical sensor ensures precise tracking on various surfaces.

MAINTENANCE

To ensure the longevity and optimal performance of your Logitech B330 mouse, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the exterior of the mouse. Avoid using harsh chemicals or abrasive materials.
- **Sensor Cleaning:** Occasionally, gently wipe the optical sensor on the underside of the mouse with a clean, dry cotton swab to remove any dust or debris that might affect tracking performance.
- **Battery Replacement:** When the mouse's performance degrades or the indicator light signals low battery, replace

the AA battery as described in the "Setup" section. The average battery life is approximately 24 months.

- **Storage:** When not in use for extended periods, turn off the mouse to conserve battery life. Store it in a clean, dry place away from extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Mouse not responding.	Low battery; USB receiver disconnected; mouse turned off.	Replace battery; ensure USB receiver is securely plugged in; turn on the mouse.
Cursor erratic or not moving smoothly.	Dirty optical sensor; unsuitable surface; interference.	Clean the optical sensor; use on a clean, non-reflective mouse pad; move closer to the receiver or away from other wireless devices.
Connection issues.	Receiver not recognized; driver issues.	Try a different USB port; restart your computer; visit the Logitech support website for driver updates.

SPECIFICATIONS

Brand:	Logitech
Model:	910-004913
Product	
Dimensions:	1.51 x 2.67 x 4.15 inches
Item Weight:	0.704 ounces
Color:	Black
Connectivity	
Technology:	Wireless
Movement	
Detection:	Optical
Power Source:	Battery Powered (1 AA battery required)
Average Battery	
Life:	24 months
Operating System:	Windows, macOS
Date First	
Available:	September 1, 2016







WARRANTY AND SUPPORT

Logitech products are manufactured to the highest quality standards and are backed by a limited hardware warranty. For detailed warranty information, product support, and frequently asked questions, please visit the official Logitech support website.

Logitech Support: <https://support.logi.com>

Please retain your proof of purchase for warranty claims.

Related Documents - 910-004913

 The image shows the cover of a Logitech M240 Silent Mouse Datasheet. It features the Logitech logo and the text 'Informacije o proizvodu (EN)' and 'LOGITECH bačica miš M240 Silent grafično'. There is a small image of the mouse.	<p>Logitech M240 for Business Wireless Mouse Datasheet - Features, Specs, Compatibility</p> <p>Comprehensive datasheet for the Logitech M240 for Business wireless mouse. Details features like Logi Bolt, Silent Touch, 18-month battery, product specifications, compatibility, and environmental certifications.</p>
 The image shows the cover of a Logitech MX Master 3S Performance Wireless Mouse Datasheet. It features the Logitech logo and the text 'Logitech MX Master 3S Performance Wireless Mouse'. There is a small image of the mouse.	<p>Logitech MX Master 3S Performance Wireless Mouse - Advanced Ergonomics & 8K DPI Sensor</p> <p>Discover the Logitech MX Master 3S, a reimagined wireless mouse with quiet clicks, an 8K DPI sensor for ultimate performance on any surface, and advanced ergonomic design for productivity.</p>
 The image shows the cover of a Logitech G PRO X SUPERLIGHT 2 LIGHTSPEED Gaming Mouse Datasheet. It features the Logitech logo and the text 'Logitech G PRO X SUPERLIGHT 2 LIGHTSPEED Gaming Mouse'. There is a small image of the mouse.	<p>Logitech G PRO X SUPERLIGHT 2 LIGHTSPEED Gaming Mouse - Advanced Performance</p> <p>Discover the Logitech G PRO X SUPERLIGHT 2, an ultra-lightweight wireless gaming mouse designed for esports champions. Featuring LIGHTFORCE hybrid switches, the advanced HERO 2 sensor, and LIGHTSPEED wireless technology for ultimate precision and speed.</p>
 The image shows the cover of a Logitech Mouse M105 Quick Start Guide. It features the Logitech logo and the text 'Logitech Mouse M105 Quick Start Guide'. There is a small image of the mouse.	<p>Logitech Mouse M105 Quick Start Guide</p> <p>This guide provides essential information for setting up and using the Logitech Mouse M105. It covers basic features, connection instructions, and troubleshooting tips to ensure optimal performance.</p>
 The image shows the cover of a Logitech MX Master 3S for Business Wireless Mouse Datasheet. It features the Logitech logo and the text 'MX MASTER 3S FOR BUSINESS'. There is a small image of the mouse.	<p>Logitech MX Master 3S for Business Wireless Mouse - Features and Specifications</p> <p>Discover the Logitech MX Master 3S for Business wireless mouse, engineered for enhanced productivity, comfort, and advanced security with Logi Bolt connectivity. Explore its features, technical specifications, and compatibility.</p>
 The image shows the cover of a Logitech G305 LIGHTSPEED Wireless Gaming Mouse User Guide. It features the Logitech logo and the text 'Logitech G305 LIGHTSPEED Wireless Gaming Mouse User Guide'. There is a small image of the mouse.	<p>Logitech G305 LIGHTSPEED Wireless Gaming Mouse User Guide</p> <p>Comprehensive user guide for the Logitech G305 LIGHTSPEED Wireless Gaming Mouse, detailing its HERO sensor, LIGHTSPEED wireless technology, battery life, specifications, and package contents. Learn about its features and requirements.</p>