

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PageFlip](#) /

› [Butterfly Bluetooth Page Turner Pedal – Silent, Rugged Foot Pedal Page Turner for iPad, Android & PC – Hands-Free Sheet Music Control – Works with forScore, OnSong, MobileSheets and 100+ more](#)

PageFlip PFBUTTERFLY01

PageFlip Butterfly Bluetooth Page Turner Pedal Instruction Manual

Model: PFBUTTERFLY01

Brand: PageFlip

INTRODUCTION

The PageFlip Butterfly is a wireless Bluetooth page turner designed for hands-free control of digital content across various devices, including iPads, Android tablets, and PCs. It provides reliable and silent operation, mimicking standard keyboard commands for broad compatibility with music apps and presentation software. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your PageFlip Butterfly pedal.



Figure 1: PageFlip Butterfly Bluetooth Page Turner Pedal

KEY FEATURES

- **Hands-Free Page Turning:** Easily turn pages using the Bluetooth page turner pedal without lifting a finger. Perfect for musicians and speakers using tablets or computers during live performances or practice.
- **Seamless Compatibility:** Works flawlessly with forScore, MobileSheets, OnSong, Newzik, and more. Supports iOS, Android, Mac, Windows, and Linux via Bluetooth or USB dongle (optional dongle not included).
- **Durable & Silent Performance:** Features a rugged design, silent foot action, and smart sleep mode, ideal for quiet and reliable operation in any setting.
- **3 Pedal Modes:** Switch instantly between PageUp/PageDown, Arrow Up/Down, or Left/Right for customized control and intuitive one-button mode switching.
- **Long-Lasting Battery:** Runs for approximately one year on just 2 AA batteries (not included). An LED warning light alerts you before power runs out.

Why Musicians Trust PageFlip



- ✓ Absolutely silent
- ✓ 3 pedal modes
- ✓ iPad, Android, Mac, PC, Linux
- ✓ Bluetooth only
- ✓ 1 year on AA batteries
- ✓ Durable and compact
- ✓ Peace of Mind – No recharging stress
- ✓ Used by musicians & educators worldwide



OTHERS

- ✗ Loud click sound
- ✗ Single mode only
- ✗ Often iOS-only or app-limited
- ✗ Cord Connection
- ✗ Inconvenient recharging battery use
- ✗ Flimsy plastic
- ✗ No Peace of Mind – Risk of mid-show battery failure
- ✗ Hobby-level use only

Figure 2: Key advantages of the PageFlip Butterfly pedal.

SETUP GUIDE

1. Battery Installation

The PageFlip Butterfly pedal operates on 2 AA batteries. To install:

1. Locate the battery compartment on the underside of the pedal.
2. Use a small screwdriver to remove the screws securing the battery cover.
3. Insert 2 AA batteries, ensuring correct polarity (+/-).
4. Replace the battery cover and secure with screws.

2. Bluetooth Pairing

The pedal connects wirelessly via Bluetooth. Follow these steps to pair your device:

1. Turn on the PageFlip Butterfly pedal using the power switch. The blue LED indicator will start flashing, indicating it's in pairing mode.
2. On your tablet, smartphone, or computer, navigate to the Bluetooth settings.
3. Select

