

Jocca 7105Q

Jocca Q-MAX Isothermal Bag User Manual

Model: 7105Q

Brand: Jocca

INTRODUCTION

This manual provides instructions for the proper use and care of your Jocca Q-MAX Isothermal Bag. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

PRODUCT OVERVIEW

The Jocca Q-MAX Isothermal Bag is designed to keep your food and beverages at their desired temperature. It features a dual-compartment design for efficient storage and a comfortable carrying handle.



Image 1: Front view of the Jocca Q-MAX Isothermal Bag in black, showing the comfortable handle and zippered compartments.

- **Top layer:** Designed for food storage, offering easy access.
- **Bottom layer:** Suitable for fresh food boxes or additional items, providing extra insulation.
- **Handle:** Features a newly designed comfortable and soft plastic handle for easy carrying.

- **Shoulder Strap:** Includes an adjustable shoulder strap for convenient hands-free transport.



Image 2: The top compartment of the isothermal bag opened, revealing the insulated interior.



Image 3: The isothermal bag with its top compartment open and a food container placed next to it, demonstrating storage capacity.

SETUP

1. Unpack the isothermal bag from its packaging.
2. Inspect the bag for any signs of damage.
3. Wipe the interior and exterior with a damp cloth before first use. Ensure it is completely dry.
4. For optimal insulation, pre-chill or pre-warm the bag by placing cold packs or warm items inside for a short period before adding your food.

OPERATING INSTRUCTIONS

Using the Compartments

- The **top compartment** is ideal for items that need to be easily accessible or for smaller food containers.
- The **bottom compartment** is designed to hold larger items, such as fresh food boxes or multiple smaller containers, providing enhanced insulation.

Carrying the Bag

Use the comfortable plastic handle for hand-carrying. The adjustable shoulder strap allows for convenient hands-free transport; adjust the strap length for comfortable carrying.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the interior lining with a damp cloth and mild soap. Rinse with a clean damp cloth. Do not submerge the entire bag in water.
- **Drying:** Allow the bag to air dry completely with the compartments open to prevent mold or mildew growth.
- **Storage:** Store the bag in a cool, dry place when not in use.
- **Avoid:** Do not use abrasive cleaners, bleach, or harsh chemicals, as these can damage the material. Do not machine wash or tumble dry.

TROUBLESHOOTING

This product is simple in design, and most issues can be resolved with proper care.

- **Issue:** Food not staying cold/warm.
Solution: Ensure compartments are fully zipped. Use ice packs (for cold) or warm packs (for warm) to enhance insulation. Pre-chill/pre-warm the bag before use.
- **Issue:** Odor inside the bag.
Solution: Clean the interior thoroughly with mild soap and water. Air dry completely. For persistent odors, a baking soda solution can be used, followed by thorough rinsing and drying.

SPECIFICATIONS

Feature	Detail
Model Number	7105Q
Brand	Jocca
Dimensions (L x W x H)	19.5 x 13 x 26 cm
Material	Plastic (lining), Fabric (exterior)
Color	Black
ASIN	B01LQG7NBK
GTIN	08435253540591

WARRANTY AND SUPPORT

For warranty information or customer support, please contact your retailer or the manufacturer, Qualimax International, S.L. Refer to your purchase documentation for specific warranty terms and contact details.

For general inquiries, visit the Jocca website or contact their customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question